

# **Radian Series Inverter/Charger**

**GS8048A**

**GS4048A**



## **Operator's Manual**



## About OutBack Power Technologies

OutBack Power Technologies is a leader in advanced energy conversion technology. OutBack products include true sine wave inverter/chargers, maximum power point tracking charge controllers, and system communication components, as well as circuit breakers, batteries, accessories, and assembled systems.

## Grid/Hybrid™

As a leader in off-grid energy systems designed around energy storage, OutBack Power is an innovator in Grid/Hybrid system technology, providing the best of both worlds: grid-tied system savings during normal or daylight operation, and off-grid independence during peak energy times or in the event of a power outage or an emergency. Grid/Hybrid systems have the intelligence, agility and interoperability to operate in multiple energy modes quickly, efficiently, and seamlessly, in order to deliver clean, continuous and reliable power to residential and commercial users while maintaining grid stability.

## Contact Information

Address:	Corporate Headquarters 17825 – 59 <sup>th</sup> Avenue N.E. Suite B Arlington, WA 98223 USA	European Office Hansastraße 8 D-91126 Schwabach, Germany
Telephone:	+1.360.435.6030 +1.360.618.4363 (Technical Support) +1.360.435.6019 (Fax)	+49.9122.79889.0 +49.9122.79889.21 (Fax)
Email:	Support@outbackpower.com	
Website:	http://www.outbackpower.com	

## Disclaimer

UNLESS SPECIFICALLY AGREED TO IN WRITING, OUTBACK POWER TECHNOLOGIES:

(a) MAKES NO WARRANTY AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN ITS MANUALS OR OTHER DOCUMENTATION.

(b) ASSUMES NO RESPONSIBILITY OR LIABILITY FOR LOSS OR DAMAGE, WHETHER DIRECT, INDIRECT, CONSEQUENTIAL OR INCIDENTAL, WHICH MIGHT ARISE OUT OF THE USE OF SUCH INFORMATION. THE USE OF ANY SUCH INFORMATION WILL BE ENTIRELY AT THE USER'S RISK.

OutBack Power Technologies cannot be responsible for system failure, damages, or injury resulting from improper installation of their products.

Information included in this manual is subject to change without notice.

## Notice of Copyright

*Radian Series Inverter/Charger Operator's Manual* © 2014 by OutBack Power Technologies. All Rights Reserved.

## Trademarks

OutBack Power, the OutBack Power logo, FLEXpower ONE, and Grid/Hybrid are trademarks owned and used by OutBack Power Technologies, Inc. The ALPHA logo and the phrase "member of the Alpha Group" are trademarks owned and used by Alpha Technologies Inc. These trademarks may be registered in the United States and other countries.

## Date and Revision

February 2014, Revision A (firmware revision 001.005.xxx)

## Part Number

900-0161-01-00 Rev A



# Table of Contents

<b>Introduction .....</b>	<b>5</b>
Audience .....	5
Symbols Used .....	5
General Safety .....	5
Welcome to OutBack Power Technologies.....	6
Inverter Functions .....	7
GS8048A.....	7
GS4048A.....	7
Inverter Controls.....	8
On/Off Switch.....	8
MATE3 System Display and Controller .....	8
<b>Commissioning .....</b>	<b>9</b>
Functional Test.....	9
Pre-startup Procedures.....	9
Startup .....	9
Powering Down.....	11
Adding New Devices .....	11
Firmware Updates .....	12
<b>Operation .....</b>	<b>13</b>
Inverter Functionality .....	13
Description of AC Input Modes.....	13
Generator.....	14
Support.....	14
Grid Tied.....	15
UPS .....	17
Backup .....	17
Mini Grid.....	18
Grid Zero .....	19
Description of Inverter Operations .....	21
Inverting.....	21
DC and AC Voltages .....	21
AC Frequency .....	22
Search .....	23
Input .....	23
AC Current Settings.....	24
AC Source Acceptance .....	24
Generator Input.....	25
Transfer .....	25
Battery Charging .....	27
Charge Current .....	27
Charge Cycle.....	27
Charging Graphs .....	28
Charging Steps.....	29
New Charging Cycle.....	31
Equalization .....	33
Battery Temperature Compensation .....	33
Offset .....	35
Multiple-Inverter Installations (Stacking) .....	36

# Table of Contents

Parallel Stacking (Dual-Stack and Larger).....	37
Power Save.....	38
Auxiliary Terminals.....	41
System Display-Based Functions.....	45
Advanced Generator Start (AGS).....	45
Grid Functions.....	45
High Battery Transfer (HBX).....	45
Grid Use Time.....	46
Load Grid Transfer.....	46
<b>Metering.....</b>	<b>47</b>
MATE3 Screens.....	47
Inverter Screens.....	47
Battery Screen.....	48
<b>Troubleshooting.....</b>	<b>49</b>
Basic Troubleshooting.....	49
Module Select.....	54
Error Messages.....	55
Warning Messages.....	56
Temperature Events.....	57
Disconnect Messages.....	58
Sell Status.....	59
<b>Specifications.....</b>	<b>61</b>
Electrical Specifications.....	61
Mechanical Specifications.....	62
Environmental Specifications.....	62
Temperature Derating.....	63
Regulatory Specifications.....	63
Listings.....	63
Certifications.....	63
Compliance.....	63
FCC Information to the User.....	64
Specification Compliance.....	64
Firmware Revision.....	65
Default Settings and Ranges.....	65
Definitions.....	68
<b>Index.....</b>	<b>69</b>

# List of Tables

Table 1	Summary of Input Modes .....	20
Table 2	Charge Currents for Radian Models .....	27
Table 3	Offset Interaction with AC Source .....	35
Table 4	Changing Master Power Save Levels (GS8048A) .....	41
Table 5	Aux Mode Functions .....	44
Table 6	Troubleshooting.....	49
Table 7	Error Troubleshooting .....	55
Table 8	Warning Troubleshooting.....	56
Table 9	Temperature Events .....	57
Table 10	Disconnect Troubleshooting.....	58
Table 11	Sell Status Messages.....	59
Table 12	Electrical Specifications for Radian Models .....	61
Table 13	Mechanical Specifications for Radian Models .....	62
Table 14	Environmental Specifications for Radian Models.....	62
Table 15	Interconnection Response Times to Abnormal Voltages or Frequencies.....	64
Table 16	Radian Inverter Settings.....	65
Table 17	Terms and Definitions.....	68

# List of Figures

Figure 1	Radian Series Inverter/Charger.....	6
Figure 2	MATE3 System Display and Controller.....	8
Figure 3	AC Test Points .....	10
Figure 4	Charging Stages Over Time .....	28
Figure 5	Charging Stages Over Time (24/7).....	28
Figure 6	Repeated Charging Cycles .....	32
Figure 7	OutBack HUB4 and MATE3.....	36
Figure 8	Example of Parallel Stacking Arrangement (Three Inverters).....	37
Figure 9	Power Save Levels and Loads.....	38
Figure 10	GS4048A Power Save Priority .....	39
Figure 11	GS8048A Power Save Priority .....	40
Figure 12	Home Screen.....	47
Figure 13	Inverter Screens .....	47
Figure 14	Battery Screen .....	48
Figure 15	AC Test Points.....	49
Figure 16	Temperature Derating.....	63

## **Table of Contents**

**This page intentionally left blank.**






# Introduction

## Audience

This manual provides instructions for setup and operation of the product. It does not cover installation. The manual is intended to be used by anyone required to operate the Radian Series Inverter/Charger. Operators must be familiar with all the safety regulations pertaining to operating power equipment of this type as required by local code. Operators are advised to have basic electrical knowledge and a complete understanding of this equipment's features and functions. Do not use this product unless it has been installed by a qualified installer in accordance with the *Radian Series Inverter/Charger Installation Manual*.

## Symbols Used




	<b>WARNING: Hazard to Human Life</b> This type of notation indicates that the hazard could be harmful to human life.
	<b>CAUTION: Hazard to Equipment</b> This type of notation indicates that the hazard may cause damage to the equipment.
	<b>IMPORTANT:</b> This type of notation indicates that the information provided is important to the installation, operation and/or maintenance of the equipment. Failure to follow the recommendations in such a notation could result in voiding the equipment warranty.



### MORE INFORMATION

When this symbol appears next to text, it means that more information is available in other manuals relating to the subject. The most common reference is to the *Radian Series Inverter/Charger Installation Manual*. Another common reference is the system display manual.

## General Safety

	<b>WARNING: Limitations on Use</b> This equipment is NOT intended for use with life support equipment or other medical equipment or devices.
	<b>WARNING: Reduced Protection</b> If this product is used in a manner not specified by GS product literature, the product's internal safety protection may be impaired.
	<b>CAUTION: Equipment Damage</b> Only use components or accessories recommended or sold by OutBack Power Technologies or its authorized agents.

# Welcome to OutBack Power Technologies

Thank you for purchasing the OutBack Radian Series Inverter/Charger. It is designed to offer a complete power conversion system between batteries and AC power. As part of an OutBack Grid/Hybrid™ system, it can provide off-grid power, grid backup power, or grid-interactive service which sells excess renewable energy back to the utility.



**Figure 1      Radian Series Inverter/Charger**



# Inverter Functions

- Battery-to-AC inverting which delivers power to run backup loads and other functions
  - ~ Provides split-phase output
  - ~ Adjustable range of output voltage
  - ~ Settable nominal output frequency
- AC-to-battery charging (OutBack systems are battery-based)
  - ~ Accepts a wide variety of AC sources
  - ~ Requires split-phase input
- Uses battery energy stored from renewable resources
  - ~ Can utilize stored energy from many sources (PV arrays, wind turbines, etc.)
  - ~ OutBack FLEXmax charge controllers will optimize PV power production as part of a Grid/Hybrid system
- Dual AC inputs allow direct connection to utility grid and AC generator
- Rapid transfer between AC source and inverter output with minimal delay time
- Uses MATE3 System Display and Controller (sold separately) for user settings as part of a Grid/Hybrid system
- Stackable in parallel configuration up to ten inverters
- Certified by ETL to UL1741, CSA C22.2, and IEC 62109-1
- Field-upgradeable firmware
- Seven selectable input modes for different applications
  - ~ **Generator**
  - ~ **Support**
  - ~ **Grid Tied**
  - ~ **UPS**
  - ~ **Backup**
  - ~ **Mini Grid**
  - ~ **Grid Zero**

## GS8048A

- 8000 watts (8 kW) continuous power at 48 Vdc
- 16.97 kVA peak surge capacity
- Modular internal design allows low idle consumption, high efficiency at both high and low power operation

## GS4048A

- 4000 watts (4 kW) continuous power at 48 Vdc
- 8.48 kVA peak surge capacity



### IMPORTANT:

The Radian inverter is not intended for use with the OutBack MATE or MATE2 System Display and Controller. It is only compatible with the MATE3 system display.

**NOTE:** This product has a settable AC output range. In this book, many references to the output refer to the entire range. However, some references are made to 120/240 Vac or 60 Hz output. These are intended as examples only.

# Inverter Controls

The Radian inverter has no external controls. It can operate normally without an external control or interface. Basic modes and settings are pre-programmed at the factory. (See page 65 for default settings.) However, certain external devices can be used to operate or program the Radian.


## On/Off Switch

The inverter can be equipped with a switch to turn it on and off. This switch is not sold as an inverter accessory; a common toggle switch can be used. It is wired to the **Switch INV** auxiliary terminals. (See the *Radian Series Inverter/Charger Installation Manual* for more information on wiring the switch.) This switch controls the inverting function only; it does not control the charger or any other function.

## MATE3 System Display and Controller

The Radian inverter has no display or LED indicators. It is not possible to monitor its status or operating mode without a metering device. The MATE3 System Display and Controller (sold separately) is designed to accommodate programming and monitoring of a Grid/Hybrid power system. The MATE3 provides the means to adjust the factory default settings to correctly match the installation where needed. It provides the means to monitor system performance and troubleshoot fault or shutdown conditions. It also has data logging and interface functions using the Internet.


Once settings are modified using a MATE3, the MATE3 can be removed from the installation. The settings are stored in the nonvolatile memory of the Radian inverter. However, it is highly recommended to include a MATE3 as part of the system. This provides the means to monitor system performance and respond quickly should it be necessary to correct a fault or shutdown condition.

The MATE3's Configuration Wizard is capable of automatically configuring inverters to a series of preset values. This is often more efficient than attempting to manually program each setting in each inverter. Affected fields include system type, battery charging, and AC source configuration. 

**NOTE:** Radian models GS8048A and GS4048A can only be used with MATE3 firmware revision 002.017.xxx or higher.



### IMPORTANT:

Some functions are not based in the inverter, but are part of the MATE3 system display's firmware. They will not function if the system display is removed. These functions are listed beginning on page 45. 



**Figure 2** MATE3 System Display and Controller



# Commissioning

## Functional Test



### **WARNING: Shock Hazard and Equipment Damage**

The inverter cover must be removed to perform these tests. The components are close together and carry hazardous voltages. Use appropriate care to avoid the risk of electric shock or equipment damage.

## Pre-startup Procedures

1. Ensure all DC and AC overcurrent devices are opened, disconnected, or turned off.
2. Double-check all wiring connections.
3. Confirm that the total load does not exceed the inverter's wattage. (See pages 21 and 55.)
4. Inspect the work area to ensure tools or debris have not been left inside.
5. Using a digital voltmeter (DVM) or standard voltmeter, verify battery voltage. Confirm the voltage is correct for the inverter model. Confirm the polarity.
6. Connect the MATE3 system display, if present.



### **CAUTION: Equipment Damage**

Incorrect battery polarity will damage the inverter. Excessive battery voltage also may damage the inverter. This damage is not covered by the warranty.



### **CAUTION: Equipment Damage**

Use of a three-phase AC source may damage the inverter. This damage is not covered by the warranty.



### **IMPORTANT:**

Prior to programming (see Startup), verify the operating frequency of the AC source. This is necessary for correct AC operation. The default setting is 60 Hz, but this can be changed to 50 Hz.

## Startup

It is highly recommended that all *applicable* steps be performed in the following order. However, if steps are inapplicable, they can be omitted.


If the results of any step do not match the description, see the Troubleshooting section on page 49.

### **To start a single-inverter system:**

1. Close the main DC circuit breakers (or connect the fuses) from the battery bank to the inverter.


Confirm that the system display is operational, if present.





Metal pads are located at these locations. In commissioning, AC voltages can be measured at this series of test points.


**Figure 3 AC Test Points**

2. If a system display is present, perform all programming for all functions.   
These functions may include AC input modes, AC output voltage, input current limits, battery charging, generator starting, and others.

AC input modes are described beginning on page 13 and are summarized on page 20. The inverter's individual operations are described beginning on page 21.

3. Turn on the inverter using the system display (or external switch, if one has been installed). The Radian's default condition is Off. Do not turn on any AC circuit breakers at this time.
4. Using a DVM or voltmeter, verify 120 Vac (or appropriate voltage) between the "L1" and "N" OUT terminals, and between the "L2" and "N" OUT terminals. (See Figure 3 for AC test points.) The inverter is working correctly if the AC output reads within 10% of 120 Vac or the programmed output voltage.
5. Proceed past the items below to Step 6 on the next page.

### **To start a multiple-inverter (stacked) system:**

1. Close the main DC circuit breakers (or connect the fuses) from the battery bank to the inverter. Repeat for every inverter present. Confirm that the system display is operational.
2. With the system display, perform any programming for stacking and all other functions.   
These functions may also include AC input modes, AC output voltage, input current limits, battery charging, generator starting, and others. When stacking in parallel, all slave inverters will observe the programming settings for the master. They do not need to be programmed individually.

AC input modes are described beginning on page 13 and are summarized on page 20. The inverter's individual operations are described beginning on page 21. Stacking is described beginning on page 35. The MATE3 Configuration Wizard may be used to assist programming.

3. Turn on the master inverter using the system display (or external switch, if one has been installed). The Radian's default condition is Off. Do not turn on any AC circuit breakers at this time.

4. Using a DVM or voltmeter, verify 120 Vac (or appropriate voltage) between the master inverter's "L1" and "N" OUT terminals, and between the "L2" and "N" OUT terminals. (See Figure 3 for AC test points.) The inverter is working correctly if the AC output reads within 10% of 120 Vac or the programmed output voltage. If necessary, confirm appropriate voltages from one unit to the next.
5. Using the system display, temporarily bring each slave out of Silent mode by raising the Power Save Level of the master. (See page 38.)
  - As each slave is activated, it will click and create an audible hum.
  - Confirm that the system display shows no fault messages. Confirm that the output voltages are still correct. Individual inverter voltage readings are not necessary since all inverters are in parallel.
  - When this test is finished, return the master to its previous settings.

### After output testing is completed, perform the following steps:

6. Close the AC output circuit breakers. If AC bypass switches are present, place them in the normal (non-bypass) position. *Do not connect an AC input source or close any AC input circuits.*
7. Use a DVM to verify correct voltage at the AC load panel.
8. Connect a small AC load and test for proper functionality.
9. Close the AC input circuit breakers and connect an AC source.
  - Using a DVM or voltmeter on the correct input, check all "L1", "L2", and "N" input terminals for 120 Vac and 240 Vac (or appropriate voltage) from the AC source.
  - If a system display is present, confirm that the inverter accepts the AC source as appropriate for its programming. (Some modes or functions may restrict connection with the source. If one of these selections has been used for the system, it may not connect.) Check the system display indicators for correct performance.
10. If the charger is activated, the inverter will perform a battery charging cycle after powering up. This can take several hours. If restarted after a temporary shutdown, the inverter may skip most or all of the charging cycle. Confirm that it is charging as appropriate by using the system display.
11. Test other functions which have been enabled, such as generator start, selling, or search mode.
12. Compare the DVM's readings with the system display meter readings. If necessary, the system display's readings can be calibrated to match the DVM more accurately. Calibrated settings include AC input voltage for the **Grid** and **Gen** inputs, AC output voltage, and battery voltage.

## Powering Down

If steps are inapplicable, they can be omitted. However, it is highly recommended that all *applicable* steps be performed in the following order. These steps will completely isolate the inverter.

### To remove power from the system:

1. Turn off all load circuits and AC input sources.
2. Turn off all renewable energy circuits.
3. Turn each inverter OFF using the MATE3 system display or external switch.
4. Turn off the main DC overcurrent devices for each inverter.

## Adding New Devices

When adding new devices to the system, first turn off the system according to the preceding instructions. After adding new devices, perform another functional test, including programming.

## Firmware Updates



### IMPORTANT:

All inverters will shut down during firmware updates. If loads need to be run while updating the firmware, bypass the inverter with a maintenance bypass switch. Communication cables must remain connected and DC power must remain on. Interrupted communication will cause the update to fail and the inverter(s) may not work afterward. Inverters automatically update one at a time beginning with Port 1. Each requires about 5 minutes.

Updates to the Radian's internal programming are periodically available at the OutBack website [www.outbackpower.com](http://www.outbackpower.com). If multiple inverters are used in a system, all units must be upgraded at the same time. All units must be upgraded to the same firmware revision.

If multiple stacked Radian inverters are used with different firmware revisions, any inverter with a revision different from the master will not function. (See the stacking section on page 35.) The MATE3 will display the following message:

*An inverter firmware mismatch has been detected. Inverters X, Y, Z<sup>1</sup> are disabled. Visit [www.outbackpower.com](http://www.outbackpower.com) for current inverter firmware.*

### NOTES:

<sup>1</sup> The port designations for the mismatched inverters are listed here.




# Operation

## Inverter Functionality

The inverter is capable of being used for many applications. Some of the inverter's operations occur automatically. Others are conditional or must be enabled manually before they will operate.

Most of the inverter's individual operations and functions can be programmed using the system display. This allows customization or fine tuning of the inverter's performance.

The Radian inverter has two sets of input connections, which are labeled **Grid** and **Gen**. Two different AC sources can be connected during inverter installation. 

### Before operating the inverter:


The operator needs to define the application and decide which functions will be needed. The Radian inverter is programmed with seven AC input modes. Each mode has certain advantages which make it ideal for a particular application. Some modes contain functions unique to that mode.

The modes are described in detail following this section. To help decide which mode will be used, the basic points of each mode are compared in Table 1 on page 20.

Apart from the input modes, Radian inverters possess a set of common functions or operations. These operations are described in detail beginning on page 21. Most of these items operate the same regardless of which input mode is selected. The exceptions are noted where appropriate.

**NOTE:** The Radian's battery charger uses the same programming and settable limits regardless of which input is used. It does not have independent charger settings on each input.

Each distinct mode, function, or operation is accompanied by a symbol representing the inverter and that operation:



These items represent the input from the AC source, the output to the AC loads, DC functions (inverting, charging, etc.), and the transfer relay. Arrows on each symbol represent power flow.

The symbols may have other features depending on the operation.

## Description of AC Input Modes

These modes control aspects of how the inverter interacts with AC input sources. Each mode is intended to optimize the inverter for a particular application. The names of the modes are **Generator**, **Support**, **Grid Tied**, **UPS**, **Backup**, **Mini Grid**, and **Grid Zero**. The modes are summarized and compared in Table 1.

Both of the Radian's inputs, **Grid** and **Gen**, can be programmed for separate modes.

- The **Grid** input can be set in the **Grid AC Input Mode and Limits** menu.
- The **Gen** input can be set in the **Gen AC Input Mode and Limits** menu.

**NOTE:** The input terminals are labeled for grid and generator due to common conventions, not because of inverter requirements. Each input can accept any AC source as long as it meets the

## Operation


requirements of the Radian inverter and the selected input mode. If necessary, the **Gen** terminals can accept grid power. The opposite is also true.

However, if using the **Gen Alert** or **AGS** functions, the generator must use the **Gen** terminals. See page 41 (**Gen Alert**) and page 45 (**AGS**).

When multiple inverters are stacked together in parallel, the master inverter's input mode is imposed on all slaves. (See the stacking section on page 35.) The slave settings are not changed; they retain any mode that was previously programmed. However, the slave will ignore its programmed mode and use that of the master. This also applies to any parameters in the mode menu (**Voltage Limit**, **Connect Delay**, and so on).

The following pages compare the various features of each input mode.

### Generator



The **Generator** mode allows the use of a wide range of AC sources, including generators with a rough or imperfect AC waveform. In other modes, a “noisy” or irregular waveform may not be accepted by the inverter. (Self-excited induction generators may require this mode when used with the Radian.) **Generator** allows these waveforms to be accepted. The charging algorithm of this mode is designed to work well with AC generators regardless of power quality or regulation mechanism. The generator must still comply with the inverter's nominal input specifications. (See page 23.)


#### BENEFITS:

- The Radian inverter will charge the batteries from the generator even when the generator is undersized, of low quality, or has other problems. See page 25 for recommended parameters for sizing a generator.
- In cases where utility grid power is unstable or unreliable, **Generator** mode may allow the Radian inverter to accept the power.
- A programmable delay time is available which will allow a generator to stabilize before connection. In the MATE3, this menu item is **Connect Delay**. It is available in both the **Grid AC Input Mode and Limits** and the **Gen AC Input Mode and Limits** menus, depending on which input is being programmed.

#### NOTES:

- Any AC fluctuations that are accepted by the inverter will be transferred to the output. The loads will be exposed to these fluctuations. It may not be advisable to install sensitive loads under these conditions.
- The name of **Generator** mode does not mean that the Radian requires a generator input when using this mode. The use of this mode does not require the use of the **Gen** input; either input can be used. Conversely, the Radian is not required to be placed in this mode just because a generator is installed.

### Support



The **Support** mode is intended for systems that use the utility grid or a generator. In some cases the amount of current available from the source is limited due to size, wiring, or other reasons. If large loads need to be run, the Radian inverter augments (supports) the AC source. The inverter uses battery power and additional sources to ensure that the loads receive the power they demand.



In the MATE3 system display, the **Grid Input AC Limit** dictates the maximum AC draw for the Grid input. The **Gen Input AC Limit** sets the maximum draw for the Gen input. The Support function takes effect if the AC demand on either input exceeds the **AC Limit** setting.



## BENEFITS:


- Large inverter loads can be powered while staying connected to the AC input, even if the input is limited. The added battery power prevents overload of the input source, but the batteries are not in constant use.
- The Radian inverter will offset the loads with excess renewable energy if it is available from the batteries. See page 35 for more information.


## NOTES:

	<p><b>IMPORTANT:</b></p> <p>The inverter will draw energy from the batteries when the loads exceed the appropriate <b>AC Limit</b>. With sustained loads and no other DC source, the batteries may discharge to the Low Battery Cut-Out point. The inverter will shut down with a Low Battery error. (See pages 21 and 55.) To prevent the loss of power, load use should be planned accordingly.</p>
	<p><b>IMPORTANT:</b></p> <p>A “noisy” or irregular AC source may prevent <b>Support</b> from working normally. The inverter will transfer the power, but will not support the source, charge the batteries, or interact with the current in any other way. This problem is more common with generators smaller than the wattage of the inverter.</p>

- A programmable delay time is available which will allow an AC source to stabilize before connection. In the MATE3, this menu item is **Connect Delay**. It is available in both the **Grid AC Input Mode and Limits** and the **Gen AC Input Mode and Limits** menus, depending on which input is being programmed.
- Because the inverter limits the current draw from the AC source, it will reduce the charge rate as necessary to support the loads. If the loads equal the appropriate **AC Limit** setting, the charge rate will be zero.
- If the AC loads **exceed** the **AC Limit** setting, the Support function is activated by operating the charger in reverse. It will take power **from** the batteries and use it to support the incoming AC current.
- The **Support** function is not available in any other input mode.

## Grid Tied




	<p><b>IMPORTANT:</b></p> <p>Selling power to the utility company requires the authorization of the local electric jurisdiction. How the utility company accommodates this will depend on their policies on the issue. Some may pay for power sold; others may issue credit. Some policies may prohibit the use of this mode altogether. <i>Please check with the utility company and obtain their permission before using this mode.</i></p>
---	--

The **Grid Tied** mode allows the Radian inverter to become grid-interactive. This means that in addition to using power from the utility grid for charging and loads, the inverter can also convert excess battery power and sell it to the utility grid. Excess battery power usually comes from renewable energy sources, such as PV arrays, hydroelectric turbines, and wind turbines.

The grid-interactive function is integrally tied with Offset operation and with the battery charger. See pages 35 and 27 for more information on these items.

### BENEFITS:

Excess power is returned to the utility grid.

- The inverter will offset the loads with excess renewable energy if it is available from the batteries.
  - If the excess energy is greater than the AC demand (the load size), the excess will be sold to the grid.
  - Due to varying requirements in different locations around the world, the grid-interactive settings are adjustable. These adjustments are made in the **Grid Interface Protection** menu.
    - ~ This menu is only available to operators with installer-level access. There are firm rules concerning the acceptable voltage range, frequency range, clearance time during power loss, and reconnect delay when exporting power to the utility. Generally it is expected that the end user cannot alter the settings.
    - ~ The installer password must be changed from the default in order to get access to these settings. Once this password has been changed, the settings can only be accessed by using the installer password. See pages 65 and 67 for more information.
    - ~ The inverter's operating frequency can be changed between 50 and 60 Hz using the **Grid Interface Protection** menu. This setting changes the inverter's input acceptance parameters, as well as its output.
- See Table 16 beginning on page 65 for the locations of all menu items in the MATE3 menus. 

### NOTES:

- The inverter has a delay before selling will begin. This delay has a default setting of five minutes. *During this time, the inverter will not connect to the utility grid.* This setting is adjustable in the **Grid Interface Protection** menu. Upon initial connection to the utility grid, the inverter may be required to perform a battery charging cycle. This may delay the operation of the grid-interactive function.
- The grid-interactive function only operates when excess DC (renewable) power is available.
- The grid-interactive function is not available in any of the other input modes.
- When power is returned to the utility grid, it may be possible to reverse the utility meter. However, this depends on other loads in the system. Loads on the main panel (not on the inverter's output) may consume power as fast as it is sold. The meter would not run backwards, even if the system display showed the inverter selling power. The result of selling would be to reduce AC power consumption, not reverse it.
- The amount of power an inverter can sell is not equal to its specified output wattage. The **Maximum Sell Current** can be decreased if it is necessary to limit the power sold. This item is available in the **Grid Interface Protection** menu.
  - ~ The amount of power that is sold is controlled by the utility grid voltage. The wattage sold equals this voltage multiplied by the current. For example, if the inverter sells 30 amps and the voltage is 231 Vac, the inverter will sell 6.93 kVA. If the voltage is 242 Vac, the inverter will sell 7.26 kVA. Additionally, output will vary with inverter temperature, battery type, and other conditions.
  - ~ This recommendation is specifically for the inverter's grid-interactive function. In some cases, the source may be sized larger to account for environmental conditions or the presence of DC loads. This depends on individual site requirements.
- The grid-interactive function can only operate while the utility grid power is stable and within specific limits.
  - ~ In **Grid Tied** mode, the inverter will operate in accordance with the **Grid Interface Protection** settings. The default settings and ranges are listed in Table 16, which begins on page 65.
  - ~ If the AC voltage or frequency vary outside the **Grid Interface Protection** limits, the inverter will disconnect from the utility grid to prevent selling under unacceptable conditions. These limits override the AC source acceptance limits described on page 24, which are used in other input modes.
  - ~ If the inverter stops selling or disconnects due to **Grid Interface Protection**, the MATE3 will show the reason. Sell Status messages are listed on page 59. Disconnect messages are listed on page 58. Often these messages will be the same.

- ~ Before operating in **Grid Tied** mode, contact the utility company that provides power to the installation. They can provide information regarding the rules that must be followed in order to export power back to the utility. The items in the following list are the selectable **Grid Interface Protection** options. The utility company may need to review these items to make certain their standards are met.

The utility may simply name a standard to be followed, as with UL1741 for the United States. It may be necessary to look up the requirements for a local standard and program them accordingly.

## STAGE 1 Voltage (basic settings)

- Over Voltage Clearance Time (seconds)
- Over Voltage Trip (AC Voltage)
- Under Voltage Clearance Time (seconds)
- Under Voltage Trip (AC Voltage)

## STAGE 2 Voltage (if required by utility)

- Over Voltage Clearance Time (seconds)
- Over Voltage Trip (AC Voltage)
- Under Voltage Clearance Time (seconds)
- Under Voltage Trip (AC Voltage)

## Frequency Trip


- Over Frequency Clearance Time (seconds)
- Over Frequency Trip (Hertz)
- Under Frequency Clearance Time (seconds)
- Under Frequency Trip (Hertz)

**NOTE:** The **Frequency Trip** settings are dependent on the inverter's operating frequency, which must be set correctly. See pages 9 and 67.

## Mains Loss

- Clearance Time (seconds)
- Reconnect Delay (seconds)

See Table 16 on page 65 for the default settings and ranges.




In **UPS** mode, the Radian's parameters have been optimized to reduce the response time. If the utility grid becomes unstable or is interrupted, the Radian can transfer to inverting with the fastest possible response time. This allows the system to support sensitive AC loads without interruption.

## BENEFITS:

- Constant power is provided to the loads with virtually no drop in voltage or current.

## NOTES:

- Due to the need for the Radian inverter to react quickly to AC source fluctuations, it must remain fully active at all times. The inverter requires a continuous consumption of 42 watts.
- For this reason, the Search function does not operate in this mode. (See page 23.)




The **Backup** mode is intended for systems that have utility grid available as the primary AC source. This source will pass through the Radian inverter's transfer circuit and will power the loads unless utility power is lost. If utility grid power is lost, then the Radian inverter will supply energy to the loads from the battery bank. When the utility power returns, it will be used to power the loads again.

## BENEFITS:

- This mode will continuously maintain the batteries in a fully-charged state, unlike the **Support** mode. It does not have the overhead consumption of the **UPS** mode.

### Mini Grid




In **Mini Grid** mode, the Radian inverter automatically rejects an AC source and runs solely from battery (and renewable) energy. The inverter only connects to the AC source (usually the utility grid) when the batteries run too low.

The Radian inverter runs on battery-supplied power for as long as the batteries can be sustained. It is expected that the batteries will also be charged from renewable sources such as PV. When the batteries become depleted, the system reconnects to the utility grid to operate the loads.

The inverter will reconnect to the utility grid if the battery voltage decreases to the **Connect to Grid** set point and remains there for the **Delay** time period. These items are shown in Table 16 on page 65.

While connected to the utility grid, the inverter's charger can be set either on or off. If the charger is turned on, the inverter will proceed through a full charging cycle. Upon reaching float stage, the inverter will disconnect from the grid.

If the inverter is connected to the utility grid and the charger is turned off, another DC source such as renewable energy should be present to charge the batteries. The inverter will observe the batteries as if it was performing the charge. When the batteries reach the required voltages and charging times to achieve float stage, the inverter will disconnect from the grid. This means that the regulator for the renewable source must be set to the same settings as the Radian (or higher). Check the settings of both devices as needed. 

See page 27 for more information on the battery charging cycle.

#### BENEFITS:


- **Mini Grid** mode allows a system to minimize or eliminate dependence on the utility grid. This is only possible if certain conditions are met. See below.

#### NOTES:


- The Radian inverter will offset the loads with excess renewable energy if it is available from the batteries. See page 35 for more information on Offset operation. However, the Offset function is inapplicable when the Radian disconnects from an AC source. The renewable energy supports the inverting function instead.
- This mode has similar priorities to the high-battery transfer (**HBX**) function used by the MATE3 system display. However, it is not compatible with **HBX** and cannot be used at the same time. When using **Mini Grid** mode, the system display should disable **HBX** to prevent conflicts.

**Mini Grid** mode is also incompatible with the **Grid Use Time** and **Load Grid Transfer** functions of the MATE3 system display. These functions do not have similar priorities to **Mini Grid** or **HBX**, but they do control the inverter's connection and disconnection with the grid. **Mini Grid** should not be used with these functions.

- When deciding whether to use **Mini Grid** mode or **HBX**, the user should consider the aspects of each.
  - ~ **Mini Grid** logic is based in the Radian inverter and can function in the absence of the MATE3. **HBX** logic is based in the MATE3 and cannot function unless the MATE3 is installed and operating.
  - ~ **Mini Grid** can use utility grid power to fully recharge the batteries every time it reconnects to the grid. **HBX** can only do so under specific circumstances.
  - ~ **HBX** set points have a wide range of settings. **Mini Grid** uses settings intended to protect the batteries from excessive discharge; however, most of its settings are automatic and do not allow customization.
  - ~ **HBX** works more efficiently with a larger renewable source, but there is no specification for renewable size. **Mini Grid** cannot work properly unless the source is larger than the size of the loads. If this condition is not met, **Mini Grid** will not disconnect the inverter from the utility grid.

- ~ HBX can be combined with the settings of any other input mode (**Generator**, **UPS**, etc.). The **Mini Grid** input mode is limited to its own settings and does not have access to certain functions of other modes.
- ~ See page 45 for more information on **HBX**, **Grid Use Time**, and **Load Grid Transfer**. 

## Grid Zero



In **Grid Zero** mode, the Radian inverter runs primarily from battery (and renewable) energy while remaining connected to an AC source. The inverter only draws on the AC source (usually the utility grid) when no other energy is available. Using the DC sources, the inverter attempts to decrease the use of the AC source to zero.

In the MATE3 system display, the selectable options are **DoD Volts** and **DoD Amps**. Any time the batteries exceed the **DoD Volts** setting, the Radian will send power from the batteries to the loads. As the battery voltage decreases to the **DoD Volts** setting, the inverter will reduce the rate of flow toward zero. It will maintain the batteries at this setting.

The Radian inverter can manage large quantities of power. To prevent damage to the batteries from rapid discharge, the rate of discharge can be limited using the **DoD Amps** setting. This item should be set lower than the amperage provided by the renewable source.

- When **DoD Volts** is set low, this mode allows more renewable energy to be delivered from the batteries to the loads. However, it will also leave less of a battery reserve in the event of a grid failure.
- When **DoD Volts** is set high, the batteries will not be discharged as deeply and will retain more of a backup reserve. However, not as much renewable energy will be sent to the loads.

The renewable energy source needs to exceed the size of the loads after accounting for all possible losses. The renewable source is also required to charge the batteries after this mode discharges them. The inverter's battery charger does not function in **Grid Zero** mode.

### BENEFITS:

- **Grid Zero** mode allows a system to minimize or eliminate dependence on the utility grid. This is only possible if certain conditions are met. See the Notes section.
- This mode puts battery and renewable energy to the most effective use without selling power to the utility grid and without dependence on the grid.
- The inverter remains connected to the utility grid in case the grid is needed. If large loads require the use of grid power, no transfer is necessary to support the loads.

### NOTES:

- If the renewable energy source is not greater than the size of the inverter loads, this mode will not work well over time. The renewable source must be capable of charging the batteries as well as running the loads. This occurs when renewable energy production exceeds the **DoD Amps** setting.
- The inverter will offset the loads with excess renewable energy if it is available from the batteries. See page 35 for more information on Offset operation. However, the behavior of Offset in Grid Zero mode is different because it uses the **DoD Volts** exclusively.
- The inverter's battery charger cannot be used in this mode. However, the charger menu settings and timer operations are not changed when this mode is selected.
- The battery should be discharged whenever possible in the attempt to "zero" the grid usage. If the **DoD Amps** setting is limited or loads are not present, the batteries will be unable to accept much renewable recharging the next time it is available. The renewable energy will be wasted, leaving the system dependent on the utility grid more than necessary.

**Table 1 Summary of Input Modes**


Mode	Summary	Benefits	Cautions	Intended	Charger
<b>Generator</b>	Accepts power from an irregular or low-quality AC source	<ul style="list-style-type: none"> <li>➤ Can use AC that may be unusable in other modes</li> <li>➤ Can charge even with a poor generator or low-quality AC source</li> </ul>	<ul style="list-style-type: none"> <li>➤ Will pass irregular or low-quality power to the output; could damage sensitive loads</li> <li>➤ Offset unavailable</li> </ul>	<b>Source:</b> Generator <b>Loads:</b> Non-sensitive devices	Performs three-stage charge and goes silent as specified by settings.
<b>Support</b>	Adds battery power to augment an AC source that has limited output	<ul style="list-style-type: none"> <li>➤ Can use battery power in conjunction with AC source</li> <li>➤ Offset operation sends excess DC to loads</li> </ul>	<ul style="list-style-type: none"> <li>➤ Drains batteries during support; intended for intermittent use only</li> <li>➤ May not function with low-quality AC source</li> </ul>	<b>Source:</b> Grid or Generator <b>Loads:</b> Can be larger than AC source	Performs three-stage charge and goes silent as specified by user settings.
<b>Grid-Tied</b>	Inverter sells excess power (renewable) to utility	<ul style="list-style-type: none"> <li>➤ Bidirectional input</li> <li>➤ Can reduce utility bills and still provide backup</li> <li>➤ Offset operation sends excess DC to loads</li> <li>➤ Any additional Offset excess is sold to the grid</li> </ul>	<ul style="list-style-type: none"> <li>➤ Requires utility approval</li> <li>➤ Other approvals may be required depending on electrical codes</li> <li>➤ Has exact requirements for accepting AC input</li> <li>➤ Requires renewable energy source</li> </ul>	<b>Source:</b> Grid <b>Loads:</b> Any type	Performs three-stage charge and goes silent as specified by user settings.
<b>UPS</b>	In grid failure, unit switches to batteries with fastest possible response time	Quick backup for sensitive devices during grid outage	<ul style="list-style-type: none"> <li>➤ Uses higher idle power than other modes</li> <li>➤ Search function unavailable</li> <li>➤ Offset unavailable</li> </ul>	<b>Source:</b> Grid <b>Loads:</b> PC, audio, video, etc.	Performs three-stage charge and goes silent as specified by user settings.
<b>Backup</b>	In grid failure, unit switches batteries to support loads; this is the default mode	<ul style="list-style-type: none"> <li>➤ Simple use compared to other modes; often used with generators for this reason</li> <li>➤ Less idle power than <b>UPS</b></li> <li>➤ Does not drain battery as in <b>Support</b></li> </ul>	Has none of the special functions described in other modes	<b>Source:</b> Grid or Generator <b>Loads:</b> Any type	Performs three-stage charge and goes silent as specified by user settings.
<b>Mini Grid</b>	Stays off grid most of the time; only uses grid when batteries low	<ul style="list-style-type: none"> <li>➤ Can minimize/eliminate dependence on grid</li> <li>➤ Offset operation sends excess DC to loads (but only when on grid)</li> </ul>	<ul style="list-style-type: none"> <li>➤ Will not work properly unless renewable source is above a certain size</li> <li>➤ Conflicts with related modes in MATE3</li> </ul>	<b>Source:</b> Grid <b>Loads:</b> Any type	Performs three-stage charge on reconnect; if charger is disabled, inverter emulates charge cycle from external source and reacts accordingly
<b>Grid Zero</b>	On-grid but actual grid use is "zeroed out" with battery and renewable power; does not sell or charge	<ul style="list-style-type: none"> <li>➤ Can minimize/eliminate dependence on grid</li> <li>➤ Offset operation sends excess DC to loads at adjustable rate</li> <li>➤ Remains on-grid to avoid transfer problems</li> </ul>	<ul style="list-style-type: none"> <li>➤ Discharges batteries while remaining on grid</li> <li>➤ Will not work properly unless renewable source is above a certain size</li> <li>➤ Battery charger inoperative</li> </ul>	<b>Source:</b> Grid <b>Loads:</b> Any type	Charger inoperative; batteries must be charged using an external (renewable) energy source

# Description of Inverter Operations


The items in this section are operations common to all Radian inverters. These are used in most or all of the input modes described in the preceding section.

Some of the items in this section are functions which can be manually selected, enabled, or customized. Other items are general topics or applications for the inverter. These items may not have their own menus, but their activity can still be influenced or optimized by changing certain settings.

Any of these items may need to be adjusted so that the inverter is best matched to a particular application. The operator should review these items to see which are applicable.

All items described as settable or adjustable have set points which can be accessed using the  system display. The default settings and ranges of adjustment are listed in Table 16 beginning on page 65 of this manual.

## Inverting



This is the Radian inverter's primary task. The inverter converts DC voltage from batteries into AC voltage that is usable by AC appliances. It will continue to do this as long as the batteries have sufficient energy. The batteries can be supplied or recharged from other sources, such as solar, wind, or hydroelectric power.

The inverter's design uses transformers and high-frequency H-Bridge FET modules to achieve the required high-wattage output. In the GS8048A, the dual design allows half the inverter to shut down for lower idle consumption when not in use.

The Radian can deliver the rated wattage continuously at 25°C. The maximum output is derated at temperatures exceeding 25°C. See pages 61 and 63 for these wattages.


Measure the total load wattage so that it does not exceed the Radian's capacity. The Radian cannot maintain its AC voltage under an excessive load. It will shut down with a **Low Output Voltage** error.



### IMPORTANT:

- The Radian inverter cannot support severe output load imbalance. The GS8048A can maintain no more than 4 kVA continuously on either the L1 or L2 output, regardless of the load on the other output. For example, it cannot maintain 8 kVA on L1, even if the load on L2 is 0.
- Similarly, the GS4048A can maintain only 2 kVA on a single output, regardless of the state of the other output.
- Any greater loads (at 25°C) will cause a **Low Output Voltage** error.

## DC and AC Voltages



**The Radian inverter requires batteries to operate.** Other sources may not maintain DC voltages that are consistent enough for the inverter to operate reliably.




### CAUTION: Equipment Damage

Do not substitute other DC sources in place of the batteries. High or irregular voltages may damage the inverter. It is normal to use other DC sources with the batteries and the inverter, but not in place of the batteries.

## Operation

The following items will affect the inverter's operation. These are only used when the inverter is generating AC power on its own.

- **Low Battery Cut-Out:** This function prevents the inverter from draining the batteries completely. When the DC voltage drops below a specified level for 5 minutes, the inverter will stop functioning. The MATE3 will give a **Low Battery V** error. This is one of the error messages described on page 55. It appears as an event on the MATE3 system display. 


This function is intended to protect both the batteries and the inverter's output. (Continuing to invert on a low DC voltage may produce a distorted waveform.) This item is adjustable.

- **Low Battery Cut-In:** The recovery point from Low Battery Cut-Out. When the DC voltage rises above this point for 10 minutes, the error will clear and the inverter will resume functioning. This item is adjustable.
  - ~ Connecting an AC source for the Radian to charge the batteries will also clear a low battery error.
- **Output Voltage:** The AC output voltage can be adjusted. Along with small changes, this allows the inverter to be used for different nominal (split-phase) voltages such as 100/200 Vac and 120/240 Vac.




### IMPORTANT:

The output voltage can be adjusted to a different nominal value for a particular region. Making this change will not affect the default input voltage range accepted by the inverter from an AC source. The input range must be adjusted manually. These changes should be made at the same time. (See AC Source Acceptance on page 24.)

- The inverter is also controlled by a high battery cut-out limit. If the DC voltage rises above this limit, the inverter will immediately stop functioning and give a **High Battery V** error. This is one of the error messages described on page 55. The shutdown occurs to protect the inverter from damage due excessive DC voltage. It appears as an event on the MATE3 system display. 
  - ~ For the Radian inverter, the high battery cut-out voltage is 68 volts. It cannot be changed.
  - ~ If the voltage drops below this point, the inverter automatically recovers.


## AC Frequency



### CAUTION: Equipment Damage

Setting the inverter's output frequency to deliver 50 Hz to 60-Hz loads, or setting it to deliver 60 Hz to 50-Hz loads, could damage sensitive devices. Make certain the inverter's output frequency matches the installation.


The inverter's output can operate at a frequency of either 60 or 50 hertz. This output frequency (and the AC acceptance frequency) can be changed with the **Operating Frequency** menu item. This requires high-level access. Due to the possibility of damage, access to this setting was restricted by placing it in the **Grid Interface Protection** menu.

The installer password must be changed from the default in order to get access to this menu. Once this password has been changed, the **Grid Interface Protection** menu can only be accessed by using the installer password. This password can be changed in the system display. 

See page 17 for more information on the **Grid Interface Protection** menu. See Table 16, which begins on page 65, for the location of the **Operating Frequency** menu item.



## Search



An automated search circuit is available to minimize the power draw when no loads are present. When enabled, the inverter does not always deliver full output. The output is reduced to brief pulses with a delay between them. These pulses are sent down the output lines to see if a resistance is present. Basically, the pulses “search” for a load. If a load is detected on the output, the inverter’s output increases to full voltage so that it can power the load. When the load is turned off, the inverter “goes to sleep” and begins searching again.


The sensitivity of Search mode is in increments of approximately 0.1 Aac. The default is 6 increments, or about 0.6 Aac. A load which draws this amount or greater will “wake up” the inverter.

**NOTE:** Due to load characteristics, these increments are only approximate and may not function exactly as listed.

The pulse duration and the delay both have a time period that is measured in AC cycles. These two items and the load detection threshold are adjustable.

- Search mode may not be useful in larger systems with loads that require continuous power (e.g., clocks, answering machines, fax machines). Search mode may cause nuisance shutdowns, or it may sleep so rarely that there is no benefit.
- Some devices may not be easily detected by Search mode.
- Search is inoperative if the **UPS** input mode is in use. See page 17 for more information on this mode.

## Input



When the Radian inverter input terminals are connected to a stable AC source, the inverter will synchronize itself with that source and use it as the primary source of AC power. Its transfer relay will engage, linking the AC source directly with the inverter’s output. It can also use the source to charge batteries. (See Battery Charging on page 27.)


- Two sets of AC input terminals are available. Both inputs are identical and can be used for any AC source. However, for easy reference, the first input has been labeled **GRID** (for the utility grid). The second input is labeled **GEN** (for a generator). These designations are also used in the menus of the MATE3 system display.
  - ~ Each input has a separate set of input criteria and input modes.
  - ~ The criteria, modes, and other programming for each input contain identical content.
- The independent inputs are intended to simplify the connection to multiple AC sources; however, the inverter can only use one input at a time. If both inputs are powered, the default setting is for the inverter to accept the **GRID** input. This can be changed. In the MATE3 system display, these priorities are selected using **Input Priority** in the **AC Input and Current Limit** menu.
- Seven input modes are available which affect the Radian inverter’s interactions with AC input sources. The **Grid Tied** mode allows the Radian to sell power using the input connection. The **Support** mode can use battery power to assist a smaller AC source. See page 20 for descriptions of these and other input modes.
- The loads powered by the inverter **must not** exceed the size of the inverter’s transfer relay.




### CAUTION: Equipment Damage

Current draw in excess of the transfer relay rating can damage the transfer relay. This damage is not covered by warranty. Use protective devices of appropriate size.


## AC Current Settings



The AC current settings, **Grid Input AC Limit** and **Gen Input AC Limit**, control the amount of current that the inverter draws from the source(s). When using either of the Radian's AC inputs, the appropriate setting limits the input. Adjust these settings to match the input circuit breakers.

- The adjustment is meant to protect a generator or source that cannot supply enough current for both charging and loads. If the combined charging and loads exceed the setting, the inverter will reduce its charge rate and give priority to the loads. If the loads exceed this number on their own, the charge rate will be reduced to zero.
- The Radian's battery charger and grid-interactive function have individual settings. However, the **AC Limit** settings can also limit the charging or selling current.
- The **Support** input mode allows the Radian to support the AC source with battery power. See page 14.
- The AC input current is used to power both loads and battery charging. The combined amount should not exceed the size of the AC overcurrent device or AC source. These devices should be sized appropriately during planning and installation of the inverter system. 
- If multiple parallel inverters are installed with an AC source of limited amperage, the total combined amperage settings for all units must be less than the AC input circuit. The Configuration Wizard in the MATE3 can perform this calculation. However, the inverters do not perform this calculation. If the MATE3 or the Configuration Wizard are not used, divide the input size by the number of inverters and assign an equal part of the amperage to each port.

## AC Source Acceptance



The input source must meet the following specifications to be accepted. This is true in all modes except **Grid Tied**:

- Voltage (**GRID** input): 108 to 132 Vac (default for both L1 and L2)
- Voltage (**GEN** input): 108 to 140 Vac (default for both L1 and L2)
- Frequency (both inputs): If the output frequency is set to 60 Hz (default), the input acceptance range is 54 to 66 Hz. If output frequency is set to 50 Hz, the input range of acceptance is 45 to 55 Hz.
- See Table 16 on page 65 for the available selections for these items.

When these conditions are met, the inverter will close its transfer relay and accept the input source. This occurs after a delay which is specified below. If the conditions are not met, the inverter will not accept the source. If it was previously accepted and then rejected, the inverter will open the relay and return to inverting power from the batteries. This occurs after a specified transfer delay, which is an adjustable menu item.



### IMPORTANT:

The Radian's output voltage can be adjusted to a different nominal value for a particular region. (See page 23.) If this occurs, the source acceptance range should be adjusted to match this nominal value or the inverter may not accept the new source normally.

- The voltage limits can be adjusted to allow (or exclude) a source with weak or irregular voltages. These items are adjustable in the appropriate menu of the MATE3 (**Grid AC Input Mode and Limits** or


**Gen AC Input Mode and Limits**). The settings are titled **Voltage Limit Lower** and **Upper**. When adjusted, they apply equally to L1 and L2. There can be side effects to changing the range of allowed voltages.

- Each of the AC inputs has a settable **Connect Delay**. This is intended as a warmup period which allows an input source to stabilize before connection.
  - ~ The default setting for the **Grid** input is 0.2 minutes (12 seconds).
  - ~ The default setting for the **Gen** input is 0.5 minutes (30 seconds).


These items are adjustable in the appropriate menu of the MATE3 (**Grid AC Input Mode and Limits** or **Gen AC Input Mode and Limits**).

## NOTES:

The **Grid Tied** input mode does not use these acceptance limits and uses the **Grid Interface Protection** settings instead. (See page 17 for more information.) The inverter may not accept AC power if it meets the settings noted here but does not meet the **Grid Interface Protection** settings.

- AC acceptance is controlled separately between the Radian inverter's two inputs. An AC source that is unacceptable on one input may be acceptable on the other if the input mode or settings are different.
- Certain input modes such as **Mini Grid** may prevent the inverter from accepting AC power even if electrical conditions are met. (See page 18.)
- Several items external to the inverter may prevent the inverter from accepting AC power even if electrical conditions are met. Some examples are the **High Battery Transfer**, **Grid Usage Time**, or **Load Grid Transfer** functions, all of which are operated by the MATE3 system display. (See page 45.) Another example is the MATE3's **AC INPUT** hot key menu, which can order all inverters to disconnect when set to **Drop**. 

## Generator Input




A generator should be sized to provide enough power for all inverters, both for loads and for battery charging. The generator's voltage and frequency must match the inverter's acceptance settings.

It is usually recommended that the generator be sized at twice the wattage of the inverter system. Many generators may not be able to maintain AC voltage or frequency for long periods of time if they are loaded more than 80% of rated capacity.

The generator is required to have a stable output before its power is accepted by the inverter. Some generators with less stable or uneven outputs may not be accepted. The use of the **Generator** input mode may assist with this problem.

## Transfer



The inverter uses a transfer relay to alternate between the states of inverting and of accepting an AC source. Until the relay energizes, the output terminals are electrically isolated from the input that is in use. When it closes, the input and output terminals become electrically common. (The terminals for the unused input remain isolated during this time.) When the relay changes states, the physical transfer delay is *approximately* 25 milliseconds.



### CAUTION: Equipment Damage

Current draw in excess of the transfer relay rating can damage the transfer relay. This damage is not covered by warranty. Use protective devices of appropriate size.

## Operation


The relay contacts are limited to 50 amps per phase or leg. The continuous loads on that output should never exceed this number. When connected to an AC source, the Radian inverter cannot limit the load current. An overload condition is possible.

The inverter does not filter or actively condition the AC source. The voltage and power quality received by the output loads is the same as that of the source. If the voltage or quality do not meet the inverter's input requirements, it will disconnect and return to the inverting mode.

### NOTES:

- To ensure a smoother transition, it may be advisable to raise the inverter's lower acceptance limit. The default setting is 108 Vac on both L1 and L2. A higher setting will cause the inverter to transfer sooner in the event of a quality problem.
- If the AC source meets the inverter's requirements but is irregular, any fluctuations will be transferred to the loads. If the loads are sensitive, it may be necessary to improve the quality of the AC source.
- The **Generator** input mode is intended to accept irregular or unfiltered AC sources and is more likely to do so than other modes. This should be considered before using this mode with sensitive loads. (See page 14.)

If the charging function is turned off, the inverter will transfer power from the source but will not use it to charge. If the inverting function is turned off, the inverter will transfer ("pass through") the source power when connected, but will not invert when the source is removed.

In a stacked system, slaves are ordered to transfer at the same time as the master. If a slave does not sense an AC source at the same time as the master, it will continue inverting, and will experience a **Phase Loss** warning (see page 56). This appears as an Event on the MATE3 system display. 

# Battery Charging



## IMPORTANT:

Battery charger settings need to be correct for a given battery type. Always follow battery manufacturer recommendations. Making incorrect settings, or leaving them at factory default settings, may cause the batteries to be undercharged or overcharged.

## Charge Current

Batteries or battery banks usually have a recommended limit on the maximum current used for charging. Often this is calculated as a percentage or fraction of the battery capacity, represented by "C". For example, C/5 would be a DC amperage figure that is 1/5 of the total amp-hours of the bank.

Any chargers must be set so that the peak charge current does not exceed the recommended maximum. If multiple chargers are present (including other chargers besides the Radian), this calculation must accommodate the total combined current. The Radian's charger may need to be set at less than maximum. The system display can be used to change charger settings.



## IMPORTANT:

Although the recommended current is generally represented in DC amperes, the **Charger AC Limit** setting is measured in AC amperes, which are not measured on the same scale. To convert the recommended DC current into a usable AC figure, divide the DC figure by 4 and round up. The result can be used as a charger setting for the Radian inverter.

Examples:

- 1) Battery bank consists of 8 x L16 FLA batteries in series. Recommended maximum charge current is 75 Adc.  
 $75 \div 4 = 18.75$  or 19 Aac.
- 2) Battery bank consists of 12 x OutBack EnergyCell 200RE VRLA batteries in series/parallel. Recommended maximum charge current is 90 Adc.  
 $90 \div 4 = 22.5$  or 23 Aac.

The maximum DC charge rate for Radian models is specified in Table 12 on page 61. The actual **Charger AC Limit** setting is available in the **AC Input and Current Limit** menu of the MATE3 system display. See Table 16 on page 65. These numbers are also summarized in Table 2 below. If multiple Radian inverters are installed, divide the total current by the number of inverters and program each with the resulting number.

**Table 2 Charge Currents for Radian Models**

Model	Maximum DC Output (sent to battery)	Maximum AC Input (used from source)
GS8048A	115 Adc	30 Aac
GS4048A	57.5 Adc	15 Aac

## Charge Cycle

The inverter uses a "three-stage" battery charging process which is designed around batteries using lead-acid chemistry. The three stages are Bulk, Absorption, and Float. These stages follow a series of steps, which are shown on graphs and described in text (see page 28). On the graphs, the transitions

## Operation

between steps are marked with vertical dotted lines. A circle ○ indicates that the inverter has begun charging to a new voltage setting. A square □ indicates that the inverter has reached the setting (a horizontal dotted line). A triangle △ indicates that the inverter has stopped charging and is no longer using the previous set point. (The charging may have stopped for any of several reasons.) The battery voltage must drop to one of several low set points before the inverter resumes charging.

## Specialized Charging

Lithium-ion, sodium-sulfur, and similar advanced battery technologies may require charger settings that are very different from the inverter's defaults or the three-stage cycle in general. The Charging Steps section describes the individual selections and behavior. All charger settings are adjustable. The selection range for each step allows very different priorities from the defaults. For example, the Float voltage could be set higher than the Absorption voltage, or a step could be completely skipped.

## Charging Graphs

Figure 4 shows the progression of steps of the three-stage charging cycle.





Figure 5 shows the charge cycle used by the inverter when the **Float Time** menu item is set to **24/7**. This setting eliminates the Silent and Float Timer steps. The charger remains in Float continuously. The Float stage lasts until the AC source is removed.



## Charging Steps

The following items describe the operation and intended use for each individual charging step as shown in the graphs. Note that some charging cycles may not follow this exact sequence. These include cycles which were previously interrupted, and also customized charging. Each step describes how to defeat or customize the step if specialized charging is required.

See page 31 for a description of multiple cycles when the charger is restarted after completion. This page also describes multiple cycles when the charger is restarted after being interrupted.

### For multiple inverters:

The charging of parallel stacked inverters is synchronized and is governed by the master. The charger settings of slave inverters are ignored; the slaves use the master inverter settings.

## No Charging

If the inverter is not charging, any of the following conditions may apply:

- The unit is not connected to a qualified AC source. If a generator is present, it may not be running.
- The unit is connected to an AC source but is in a mode or step (such as Silent) that does not use the charger.
- The unit is connected to an AC source but the charger has been turned off.

## Bulk Stage

This is the first stage in the three-stage charge cycle. It is a constant-current stage which drives the battery voltage up. This stage typically leaves the batteries at 75% to 90% of their capacity, depending on the battery type, the exact charger setting, and other conditions.

**Voltage Used:** *Absorb Voltage* setting. The default setting is 57.6 Vdc.


The initial DC current may be as high as the charger's maximum current, depending on conditions. It will begin at a high level, but will drop slightly as the voltage rises. This is not a decrease in charging; the charger delivers constant power in Bulk stage. It can be viewed as a wattage "tradeoff"; the increase in voltage results in a decrease in current for a constant wattage.

**To skip this step:** Setting *Absorb Voltage* equal to *Float Voltage* will cause the charger to proceed through the normal three-stage cycle, but at a single voltage. Setting *Absorb Time* to zero will cause the charger to skip both the Bulk and Absorption stages and proceed directly to Float. This may not be desired if the intent is to include the Bulk stage but skip Absorption.

## Absorption Stage

This is the second stage of charging. It is a constant-voltage stage. Current varies as needed to maintain the voltage, but will typically decrease to a very low number over time. This "tops off the tank", leaving the batteries at essentially 100% of capacity.

**Voltage Used:** *Absorb Voltage* setting. This setting is also used by Offset when in this stage. (See page 35.) For the three-stage cycle to proceed normally, this setting should be kept higher than the *Float Voltage* and *Re-Bulk Voltage* settings.

**Time limit:** *Absorb Time* setting. This timer counts down from the inception of the Absorption stage until it reaches zero. The time remaining can be viewed in the system display. 

The Absorption timer does not reset to zero when AC power is disconnected or reconnected. It only resets to zero if it runs out, or if an external STOP BULK command is sent; otherwise it retains any remaining time.

The *Absorb Time* setting is not a required minimum period for Absorption. It is only a maximum limit. The duration of Absorption is equal to the amount of time the *Re-Bulk Voltage* setting exceeds the

## Operation

battery voltage (up to the maximum Absorption limit). The counter adds more time to the Absorption period whenever the battery voltage decreases below this setting. (See page 31 for more information on how the timer works.)

**To skip this step:** Setting **Absorb Time** to a very short duration will cause the charger to spend minimal time in Absorption once the Bulk stage is complete. Setting **Absorb Time** to zero will cause the charger to skip both the Bulk and Absorption stages and proceed directly to Float. This may not be desired if the intent is to skip Absorption but retain the Bulk stage.

### Silent

This is not a charging stage, but a quiescent period between stages. The inverter remains on the AC source, but the charger is inactive. It enters this condition upon completing a timed stage such as Absorption, Float, or Equalize.

In Silent, the batteries are not in significant use by the inverter, but they are also not being charged. The battery voltage will naturally decrease when not maintained by another means such as a renewable source.

The term “Silent” is also used in an unrelated context regarding Power Save levels. See page 38.

**Voltage Used: Re-Float Voltage** setting. When the battery voltage decreases to this point, the charger becomes active again. The default set point is 50.0 Vdc.

**To skip this step:** Setting **Float Time** to **24/7** will the charger remain in Float continuously so that it does not proceed through the Silent, Bulk, Absorption, or Float timer steps.

### Float Stage

This is the third stage of charging. It is sometimes known as maintenance charging. Float stage is initially a constant-current stage. The initial DC current may be as high as the charger’s maximum current, depending on conditions. This current is only sustained until the charger reaches the **Float Voltage** setting, after which the charger switches to constant-voltage operation.

Float stage balances the batteries’ tendency to self-discharge (as well as balancing the draw of any other DC loads). It maintains the batteries at 100% of capacity.

**Voltage Used: Float Voltage** setting. The default set point is 54.4 Vdc. This setting is also used by Offset when in this stage. (See page 35.) For the charger to work normally, this setting needs to be higher than the **Re-Float Voltage** setting.

**Time limit:** This can vary. If the duration of the **Float Time** setting is less than the total time of the bulk and absorption stages, the charger will not enter Float and will go directly to Silent instead. See Float Timer.

**To skip this step:** As noted, the charger will not enter Float if the **Float Time** setting is less than the total bulk and absorption times. Decreasing the **Float Time** setting to zero will cause the inverter to enter Silent as soon as the absorption stage is complete. The inverter will perform neither the constant-current nor the constant-voltage portions of Float.

Setting **Float Voltage** equal to the **Absorb Voltage** level will cause the charger to proceed through the normal three-stage cycle, but at a single voltage.

### Float Timer

This is not a separate stage of charging. In Figure 4 on page 28, it is marked as a separate step to note when the charger switches from constant-current to constant-voltage charging. When this occurs, the current varies as needed to maintain the **Float Voltage**, but typically drops to a low number.



**NOTE:** The Float timer begins running any time the battery voltage exceeds the **Float Voltage** set point. This usually means that it begins running during the Bulk stage, once the battery voltage rises above that level. Often the timer will expire before the bulk and absorption stages are complete. If this happens, the charger will not enter Float but will go directly to Silent. The charger only spends time in Float stage if the timer is still running.

**Time limit: Float Time** setting. The charger will go Silent once the timer has expired (if another stage is not still in progress.) The Float timer is reset to its maximum amount whenever the batteries decrease to the **Re-Float Voltage** setting.

**To skip this step:** Setting **Float Time** to 24/7 will cause the charger remain in Float continuously so that the Float timer no longer applies. (The charger also skips Bulk, Absorption, and Silent.) However, the charger can initiate a single three-stage charge if the criteria are met, after which it will return to continuous Float again.

## Silent

Following the expiration of the Float timer, the unit enters (or re-enters) the Silent stage. The unit remains connected to the AC source, but the charger is inactive.

The unit will continue cycling between Float and Silent for as long as the AC source is present.

## New Charging Cycle

If the AC source is lost or disconnected, the unit will return to inverting mode if enabled. The battery voltage will begin to decrease due to loads or natural loss. When the AC source is restored, the inverter will return to the charging cycle.

## Re-Bulk

If the battery voltage decreases due to discharge, the inverter will restart the cycle as soon as the AC source is available, beginning at Bulk stage.

**Voltage Used: Re-Bulk Voltage** setting. The default set point is 49.6 Vdc.

If the batteries do not decrease to the Re-Bulk point, the charger will not enter the Bulk stage and will return to its previous stage.


## Absorption Timer

**Time limit: Absorb Time** setting. The charger will not necessarily run through its full duration, as this setting is not a required minimum period for Absorption. It is only a maximum limit. The duration of Absorption is equal to the amount of time the battery voltage was less than the **Re-Bulk Voltage** setting, up to the maximum limit.

If the Absorption timer expired on the previous cycle, it is not reset afterward and retains a “remaining run time” of zero. Whenever the battery voltage decreases to Re-Bulk or lower, the Absorption timer will begin gaining time. For as long as the batteries remain below this voltage, the Absorption timer will gain an equal amount of time. This controls the duration of the Absorption stage. The intent was to avoid a “blind” cycle that operates regardless of conditions. The charger avoids maintaining the batteries at high voltages for excessive or unnecessary time.

The Absorption timer continues this operation even if the charger is still on. For example, if the charger is in Float stage and there is a significant battery drain, the charger may not be able to maintain the batteries at the Float voltage. Once the batteries fall below the Re-Bulk point, the Absorption timer will begin accumulating time. (However, the accumulation will be minor, as this will also cause the charger to re-enter the Bulk stage.)

The remaining charging steps will proceed as described on the previous pages.



## Example of Multiple Cycles

- In Figure 6 (Cycle 1), the charger initially completes Absorption. When the Absorption timer expires, the charger goes Silent until battery voltage decreases to the **Re-Float** setting. The Float timer is reset to its maximum. The charger enters Float and proceeds until it is interrupted by a loss of AC power.
- Cycle 2 begins when the AC source is restored. During the AC loss, the battery voltage did not decrease to the **Re-Float** setting, so **Float Time** retains the remainder of the previous cycle. The charger returns to Float and completes the stage when its timer expires. It then goes Silent.

During the Silent period, AC is lost again. The battery voltage decreases until it reaches the Re-Bulk set point. This causes the charger to prepare a new three-stage cycle from the beginning, but it cannot do so until the AC source is restored.

In Cycle 1, **Absorb Time** had expired. It was not reset afterward and retained a “remaining run time” of zero. Whenever the battery voltage decreases to **Re-Bulk** or lower, the Absorption timer will begin accumulating run time. The first set of arrows below the graph show the length of time accumulated on the Absorption timer at the end of Cycle 2.

- Cycle 3 begins when the AC source is restored again. The charger begins a new cycle by entering Bulk stage. When it enters Absorption, the amount of time spent in this stage is equal to the amount of time accumulated at the end of Cycle 2. (The space between the first and second set of arrows is the same.) Absorption ends when the timer expires.

This means that the length of Absorption may be shorter than the **Absorb Time** setting. During intermittent AC loss, the batteries may not be used enough to require a total recharge.

In this example, the duration was also longer than the **Float Time** setting. Because the Float timer began running near the beginning of Cycle 3 (when the batteries exceeded the **Float Voltage** setting), the **Float Time** has also expired. The charger does not enter Float and goes Silent.

During the Silent period, AC is lost again. The battery voltage decreases until it reaches the **Re-Bulk** set point, prompting a new charge cycle. The Absorption timer accumulates run time while the batteries are below this set point.

The first set of barred arrows below the graph show the length of time accumulated on the Absorption timer. Note that the timer stops accumulating well before the beginning of Cycle 4 when the AC source is restored. The accumulation of the Absorption timer cannot exceed the **Absorb Time** setting.

- When Cycle 4 begins, the charger proceeds through the Bulk stage and then the Absorption stage. (The space between the first and second set of barred arrows is the same.) The duration of Absorption is equal to **Absorb Time**, which is the maximum time allowed. At the end of Cycle 4, the **Float Time** has expired, so the charger goes Silent.

## Equalization

Equalization is a controlled overcharge that is part of regular battery maintenance. Equalization brings the batteries to a much higher voltage than usual and maintains this high voltage for a period of time. This has the result of removing inert compounds from the battery plates, and reducing stratification in the electrolyte.

Equalization follows the same pattern as standard three-stage charging, as shown in the figures on page 28. However, instead of the Absorption voltage and time set points, it is controlled by the **Equalize Voltage** and **Equalize Time** settings in the MATE3.

The Radian inverter can perform Offset when equalizing. (See page 35.) **Equalize Voltage** is also the reference voltage for Offset during equalization.

This process must be started manually using the system display. The inverter cannot be programmed for automatic battery equalization. This is a safety measure.

Equalization is normally performed only on flooded lead-acid batteries. The schedule for equalization varies with battery use and type, but it is usually performed every few months. If performed correctly, this process can extend battery life by a considerable amount.

Equalization is not normally performed on nickel-technology batteries or any sort of sealed battery.



### CAUTION: Battery Damage

- Do not equalize OutBack EnergyCell batteries of any model.
- Do not equalize any sealed battery types (VRLA, AGM, Gel, or other) unless approved by the manufacturer. Some batteries may suffer severe damage from equalization.
- Contact the battery manufacturer for recommendations on equalization voltage, duration, schedule, and/or advisability. Always follow manufacturer recommendations for equalization.


## Battery Temperature Compensation

Battery performance will change when the temperature varies above or below room temperature (77°F or 25°C). Temperature compensation is a process that adjusts battery charging to correct for these changes.

When a battery is cooler than room temperature, its internal resistance goes up and the voltage changes more quickly. This makes it easier for the charger to reach its voltage set points. However, while accomplishing this process, it will not deliver all the current that the battery requires. As a result, the battery will tend to be undercharged.

Conversely, when a battery is warmer than room temperature, its internal resistance goes down and the voltage changes more slowly. This makes it harder for the charger to reach its voltage set points. It will continue to deliver energy as time passes until the charging set points are reached. However, this tends to be far more than the battery requires, meaning it will tend to be overcharged.

## Operation

The Radian inverter, when equipped with the Remote Temperature Sensor (RTS) will compensate for changes in temperature. The RTS is attached to a single battery near the center of the bank, to achieve a representative temperature. The Radian inverter has a designated port for installing the RTS. 

If installed in a multiple-inverter system, only a single RTS is necessary. It must be plugged into the master inverter and will automatically control the charging of all slaves and all charge controllers.

When charging, an inverter system with an RTS will adjust the charging voltage inversely with changes in temperature. It will **increase** the charge voltage by 5 mV for every decrease of 1 degree Celsius per battery cell. Similarly, it will **decrease** the voltage 5 mV for every increase of 1°C per cell.


This setting affects the **Absorption**, **Float**, and **Equalization** set points. The **Sell Voltage** and **Re-Float Voltage** set points are not temperature compensated. The **Equalization** set points are not compensated in OutBack charge controllers.

- In a 48 Vdc system (24 cells, 2 volts each), this means 0.12 volts per degree Celsius above or below 25°C. Maximum compensation is  $\pm 2.4$  Vdc.

### EXAMPLES:

- A 48 Vdc system with batteries at 15°C will compensate its charging to 1.2 Vdc **higher** than the set points.
- A 48 Vdc system with batteries at 40°C will compensate its charging to 1.8 Vdc **lower** than the set points.


## Slope

Some batteries require different amounts of compensation. The OutBack FLEXmax Extreme charge controller has an adjustable rate of compensation ("slope") and is not limited to 5 mV. The FLEXmax Extreme can be networked with the Radian with the HUB Communications Manager. If this is done, the Radian can import the slope setting from the FLEXmax Extreme charge controller. 

### NOTE:

Temperature compensation only applies to the battery charging function. Other set points in the inverter, such as the AUX functions, are not compensated for temperature.

# Offset



This operation is designed to use excess battery energy to power the loads when an AC source is present. This allows the system to take advantage of renewable energy sources, in effect “offsetting” dependence on the AC source.

A renewable energy source will raise the battery voltage as it charges the batteries. When the voltage exceeds a designated reference voltage, the Radian inverter begins drawing power from the batteries (discharging them) and using that power to offset usage of the AC source. The batteries are kept at equilibrium and are maintained at the reference voltage.

The Radian inverter uses excess DC energy for offset under the following rules:

- If the load demand is higher than the exported power, the inverter’s use of the AC source is reduced. The exported amount of power has “offset” the same amount of demand on the AC source. (This is sometimes known as “selling to the loads”.)
- If the excess DC energy (and exported power) is equal or greater than the load demand, and the Radian is in the **Grid Tied** input mode, the inverter will sell the additional power to the utility grid. This is the key priority of the **Grid Tied** mode.

The Radian inverter uses several set points as reference voltages for the Offset operation, particularly the battery charger settings.

- The charger settings **Absorb Voltage**, **Float Voltage**, and **Equalize Voltage** (as shown in the system display) are all used as reference voltages. Normally the charger regulates to these set points by adding power to the batteries. Offsetting does the opposite; it uses the same set points but regulates the voltage by removing power from the batteries.
- If none of the battery charger’s timers are active, the Offset voltage is **Sell Voltage** in the **Grid-Tie Sell** menu. This is true in any input mode where Offset is used, not just the **Grid Tied** input mode.
- The **Grid Zero** mode only uses a single reference voltage for Offset, the **DoD Volts** setting.

## NOTES:

- Offset operation is not available in the **Generator**, **UPS**, and **Backup** input modes.
- Offset operation is available in the **Support**, **Grid Tied**, and **Grid Zero** modes.
- Offset operation is available in the **Mini Grid** mode. However, it may not be used often since the **Mini Grid** priority is to avoid grid use.
- The **Grid-Tie Enable** menu item must be set to **Y** (yes) for Offset to work. This is true even if the inverter is not used in a grid-tied mode or application.

**Table 3 Offset Interaction with AC Source**

Mode	Excess DC $\geq$ loads	Excess DC $<$ loads
<b>Generator</b>	N/A; Offset operation does not function	
<b>Support</b>	Offsets load use, but also uses DC and batteries to support the AC source based on <b>Support</b> mode settings	
<b>Grid Tied</b>	Sells excess to AC source (grid); remains connected	Offsets loads with whatever power is available
<b>UPS</b>	N/A; Offset operation does not function	
<b>Backup</b>	N/A; Offset operation does not function	
<b>Mini Grid</b>	Offsets loads with whatever power is available; inapplicable if disconnected from utility grid	
<b>Grid Zero</b>	Offsets load use, but only according to the <b>DoD Volts</b> setting	

## Multiple-Inverter Installations (Stacking)


Multiple inverters in a single system can support larger loads than a single inverter can handle. Installing inverters in this configuration is called “stacking”. Stacking inverters refers to how they are wired within the system and then programmed to coordinate activity. Stacking allows all units to work together as one system. The GS8048A and GS4048A models can stack up to ten units in parallel for increased capacity.

Stacking requires an OutBack HUB Communications Manager, as well as a MATE3 system display.

There are usually other specialized stacking instructions during installation. 

- A system of four or fewer units may use the HUB4.
- Systems of up to ten units require the HUB10 or HUB10.3.
- All interconnections between the products are made using CAT5 non-crossover cable.

Each inverter needs to be assigned a status — “master” or “slave”. The master is the primary and most heavily used unit. Slave inverters provide assistance when the loads are more than the master can handle alone. Programming involves using the MATE3 to assign a status and stacking value to the inverter on each port.



### IMPORTANT:

- The master inverter must always be connected to port 1 on the HUB product. Connecting it elsewhere, or connecting a slave to port 1, will result in backfeed or output voltage errors which will shut the system down immediately.
- All stacked Radian inverters must have the same firmware revision. If inverters are stacked with different firmware revisions, any unit with a revision different from the master will not function. The MATE3 will display the following message:  
An inverter firmware mismatch has been detected. Inverters X, Y, Z <sup>2</sup> are disabled.  
Visit [www.outbackpower.com](http://www.outbackpower.com) for current inverter firmware.
- Installing multiple inverters without stacking them (or stacking them incorrectly) will result in similar errors and shutdown.
- Neither the GS8048A nor the GS4048A can stack with the previous model GS8048. The GS8048 can share a HUB Communications Manager with the current models

<sup>2</sup> The port designations for the mismatched inverters are listed here.


without being stacked as long as it is wired independently.

- The GS8048A can be parallel-stacked with the GS4048A.
- Although stacking allows greater capacity, the loads, wiring, and overcurrent devices must still be sized appropriately. Additional terminations or bus bars may be required. Overloading may cause circuit breakers to open or inverters to shut down.

## Parallel Stacking (Dual-Stack and Larger)

In parallel stacking, two or more inverters are stacked to create a single, common set of AC outputs.

- All inverters share a common input (AC source) on both L1 and L2. The inverters run loads on common L1 and L2 output buses. The master inverter provides the primary output. The slaves are connected to the same L1 and L2 outputs and assist the master.
- The slave outputs are controlled directly by the master and cannot operate independently.
- Slave inverters can go into Power Save mode when not in use. The master will activate individual slaves based on load demand. This reduces idle power consumption and improves system efficiency.
- Up to ten inverters may be installed in a parallel arrangement.



**Figure 8 Example of Parallel Stacking Arrangement (Three Inverters)**

## Power Save


Each inverter consumes approximately 30 watts of idle power while it remains on, even if it is not actively inverting or charging. The Power Save function allows the option to put part of a parallel system into a quiescent state known as Silent mode. This mode minimizes the idle consumption. The inverters will come on again when the loads require power. (The term “Silent” is also used in an unrelated context during battery charging. See page 30.)

- When the load increases by approximately 2.5 kW, the master inverter activates one or more additional modules for assistance. When the load decreases to a lesser wattage (as detected by the master), the modules deactivate and return to Silent mode. Additional load increments of approximately 2.5 kW will activate additional modules.
- The first module in the master does not enter Silent mode. It remains active unless specifically turned off.
- The order in which additional modules activate (or return to Silent mode) is controlled by programming in the MATE3. The inverters are given a “rank”, or level number. Lower rank numbers activate when lesser loads are applied. Higher ranks only activate when the load increases to a high level.



### IMPORTANT:

Power Save functionality is different between Radian models. The Radian GS4048A contains only one 4kW module. Activating one module is the same as activating the full inverter. The GS8048A contains two modules and operates differently. Do not confuse the behavior of each. See Figure 10 and Figure 11 for differences.



The actual watt and ampere thresholds for activating each model are depicted on the following pages.




### IMPORTANT:

It is highly recommended to use the MATE3 Configuration Wizard to set up this function. It is essential to set the slave Power Save Levels in sequential order. Failure to set them up correctly will cause erratic system performance. The Configuration Wizard automatically programs the correct priorities. (See the MATE3 owner’s manual.)

### To set these items manually without the Configuration Wizard:

In the MATE3 system display, the **Power Save Ranking** screen uses **Power Save Level** selections to assign inverter ranks. The screen reads **Master Power Save Level** or **Slave Power Save Level**,



depending on the inverter's stacking designation. 

- **Master Power Save Level** appears on an inverter which is set as master (the default setting). In a stacked system, this selection should only appear on the inverter using Port 1 of the communications manager. The range of rank numbers is 0 to 31. The default value is 0. The master is normally left at this value.
- **Slave Power Save Level** appears on an inverter which is set as slave. The range of rank numbers is 1 to 31. (The default value for all ports is 1.)
- The ranks are prioritized so that lower-numbered ranks turn on sooner and higher ranks turn on later. The lowest-ranked unit will not go silent and will remain on unless ordered otherwise. The lowest-ranked unit is expected to be the master. The priorities are the same across both screens; thus, if P01 (master) is set at 0 and P02 (slave) is set at 1, the slave will turn on later. Since the **Master** item is the only one that goes to 0, it is easy to ensure that all other units besides the master go silent.



	<p><b>IMPORTANT:</b></p> <p>Set the master rank at 0 and arrange the slave ranks in order (1, 2, 3, 4, etc.). Another order may defeat the purpose of Power Save mode. Leaving the master at 0 makes 4 kW of power available from the master; the other inverters should not be active. If a slave is ranked lower (prioritized higher) than the master, that slave will not go silent.</p> <p><b>NOTE:</b> Disregard this rule if the installation requires some of the slaves to be continuously active.</p>
	<p><b>IMPORTANT:</b></p> <p>Do not give slave inverters the same rank numbers. If, for example, multiple slaves were all ranked at 1, they would all come on at the same time. Once they came on, the divided load would cause the master to detect a minimal load on its output, so it would shut off all the slaves, at which point the master would read a high load again. This could quickly escalate into a rapid on/off cycling of inverters and could cause long-term system problems.</p>

Figure 10 shows a system of four GS4048A inverters (the master and three slaves) in a parallel system with a common load bus. The labels at the top indicate the ranking of each unit. The notations at the bottom show how the units are activated in sequence as loads of approximately 2.5 kW are applied.



The last line indicates that loads of approximately 7 to 8 kW are present on the system, causing all four inverters to be activated.

## Additional Notes for the Radian GS8048A


The GS8048A has two modules. The modules are controlled individually. The Power Save function will activate one module at a time, making an additional 4 kW of power available for every load increase of approximately 2.5 kW.

Figure 11 shows a system of four GS8048A inverters (the master and three slaves) in a parallel system with a common load bus. The labels at the top indicate the ranking of each unit. The notations at the bottom show how the units are activated in sequence as loads of approximately 2.5 kW are applied.

- The first line shows little load and only the first module in Master is activated.
- The second line shows load beginning to be applied. The second module in Master is activated.
- The third line shows increasing load. The first module in Slave 1 is activated.
- The fourth line shows even higher load. Slave 1 is completely activated.

In general, roughly 5 kW of loads are applied to fully activate an additional slave inverter.

- In the example shown in Figure 11, an 8-kW load has been applied, fully activating the first slave.
- In this example, loads of approximately 17 to 18 kW would be needed to turn on all inverters.



### Forcing Specific Slaves to be Active:

It is possible to raise the priority of a slave and force it to activate. This is done by setting the master rank higher than that slave. However, the **Master Power Save Level** scale is not the same as the **Slave** level. **Slave** level settings apply to the whole inverter. **Master** level settings are applied per module.

This means that increasing the master by one rank will only turn on one additional module. To completely turn on a slave inverter, the master must be increased two ranks. See the next page.

In Table 4, instead of loads, the number on the far left of each line shows the master increased by one rank. (This example is otherwise the same as Figure 11.)

The last line of the table shows the master increased to 3, which is the same as the rank of the highest slave. However, this only activates the first of the three slaves. The master would need to be set to rank 7 to activate all slaves.


**Table 4 Changing Master Power Save Levels (GS8048A)**

Master			Slave 1			Slave 2			Slave 3		
Power Save	Module 1	Module 2	Power Save	Module 3	Module 4	Power Save	Module 5	Module 6	Power Save	Module 7	Module 8
0	On	Off	1	Off	Off	2	Off	Off	3	Off	Off
1	On	On	1	Off	Off	2	Off	Off	3	Off	Off
2	On	On	1	On	Off	2	Off	Off	3	Off	Off
3	On	On	1	On	On	2	Off	Off	3	Off	Off

## Auxiliary Terminals

The Radian inverter has two sets of terminals which can respond to different criteria and control many operations. The 12V AUX terminals provide a 12 Vdc output that can deliver up to 0.7 Adc to control external loads. The RELAY AUX terminals are “dry” relay contacts rated up to 10 amps (at 250 Vac or 30 Vdc). Each set of terminals has its own set of programmed criteria. Each has identical options available. (When the options described below refer generically to the “AUX output”, it can mean either set of terminals.)

Each AUX output has three states: continuous **Off**, continuous **On**, and **Auto**, which allows that output to be activated using the automatic auxiliary functions. (All functions are defaulted to **Auto**.) These items are based in the Radian and accessed using the system display. The system display and other devices also have programming, such as AGS, that can control the AUX outputs. To avoid conflicts, the output should be turned **Off** when the AGS function is active. (See page 45.)

For the Radian automatic functions, typical applications include signaling a generator to start, sending a fault alarm signal, or running a small fan to ventilate the batteries. When considering these applications, plan for both connection requirements and programming with the system display. 

The AUX terminals have a series of set points which are used by various functions. Both sets of terminals have the same options available, but they are programmed independently. Not all set points are used by all functions. Each AUX mode description below will detail the set points that are used for that function.

- ~ Low DC voltage settings
- ~ High DC voltage settings
- ~ On delay settings, in increments of 0.1 minutes
- ~ Off delay settings, in increments of 0.1 minutes

These settings are not temperature compensated. Compensation is only used for inverter battery charging.

There are nine functions, each geared toward a different application. (The 12V AUX and RELAY AUX outputs are defaulted to different selections.) These functions are summarized in Table 5 on page 44.

- **Load Shed** can perform load management. It is intended to turn off designated loads during low battery periods to conserve remaining battery power.

When battery voltage rises above a settable high voltage level, the AUX output is activated after a settable delay. The AUX output is used to energize a larger external relay (normally open) which is connected to non-vital loads. The AUX output will be deactivated once the battery voltage falls below a low voltage setting for a settable delay period.

- ~ **Load Shed** will also turn off when the inverter enters a high-temperature condition or when the AC

## Operation

output voltage drops below a specific AC voltage for more than 3 seconds. This voltage limit is 30 volts below the setting of the inverter's output voltage. For the Radian's default output voltage of 240 Vac, the limit is 210 Vac, or 105 Vac if output L1 or L2 decrease in voltage independently. (See page 67.) The limit is not otherwise settable.

- ~ **Load Shed** will also turn off if the input current exceeds the **Input AC Limit** setting while the inverter is using an AC source.
- ~ Settable parameters include:
  - Low and high DC voltage
  - On and off delay
- **Gen Alert** is used as a controller for an AC generator with a remote start feature, although it has limited functionality. (The generator recharges batteries using the inverter's battery charger.)
  - ~ Either set of AUC terminals may be used to start the generator by closing the appropriate circuit. The specific choice of RELAY AUX or 12V AUX may depend on the generator's starting circuitry. Different examples are illustrated in the *Radian Series Inverter/Charger Installation Manual*.
  - ~ The AUX output will activate to start the generator when the battery voltage falls to a low set point for a settable delay. The AUX output is deactivated, shutting off the generator, once the battery voltage rises to a high voltage setting for a settable delay period.
  - ~ Settable parameters include:
    - Low and high DC voltage
    - On and off delay
  - ~ Gen Alert control logic is located in the inverter. It has the advantage of functioning when the system display is removed. However, it may not completely charge the batteries and does not have all the advantages of the Advanced Generator Start (**AGS**) function that is found in the system display. For many users, the **AGS** function may prove more useful than **Gen Alert**. **Gen Alert**, however, could be used as a literal "Generator Alert", a signal to the user to manually start a generator.

**NOTE:** **Gen Alert** is the default selection for the RELAY AUX settings.



### IMPORTANT:

When using **Gen Alert** (or AGS), the generator must be connected to the inverter's **GEN** terminals. If the input priority is set to **GRID** and the **GRID** terminals are energized, an automatically controlled generator will shut down. This prevents an automatic generator from working correctly when using the **GRID** terminals.

- **Fault** activates the AUX output when the inverter shuts down due to an error condition (see page 55). It can activate a light or alarm to show that the inverter has failed. With the appropriate devices, it could send an alarm signal through a radio, pager, or telephone dialer.
  - ~ This function does not have settable parameters.
- **Vent Fan** activates the AUX output in response to a high DC (battery) voltage set point. It can run a small fan to ventilate the battery compartment to eliminate gases that result from battery charging. (This is illustrated in the *Radian Series Inverter/Charger Installation Manual*.) When the voltage falls below this set point for a settable delay period, the AUX output turns off.
  - ~ Settable parameters include:
    - High DC voltage
    - Off delay

**NOTE:** **Vent Fan** is the default selection for the 12V AUX settings.

- **Cool Fan** activates the AUX output when the inverter reaches a high internal temperature. It is intended to trigger a small external fan for additional cooling. See the Warning Troubleshooting table on page 56 for a description of the fan criteria.
  - ~ This function does not have settable parameters.
- **DC Divert** activates the AUX output to divert (or “dump”) excess renewable energy to a DC load, such as a resistor, a heater, or a fuel cell. This prevents overcharging of the batteries. This function can serve as rough charge regulation for an external charging source.
  - ~ When battery voltage rises above a settable high voltage level, the AUX output is activated after a settable delay. The AUX output controls a larger, external relay. When energized, the relay allows current to flow from the batteries to a dedicated DC load. (This is illustrated in the *Radian Series Inverter/Charger Installation Manual*.) The resistor or load must be sized to dissipate all of the energy from the renewable source if necessary. Diversion will turn off following a delay when a low DC voltage setting is reached.
  - ~ Settable parameters include:
    - Low and high DC voltage
    - On and off delay
- **GT Limits** activates the AUX output as an alert that the utility grid does not meet Grid Interface Protection parameters for the grid-interactive function (see page 15). It can activate a light or alarm to show that the grid-interactive function has shut down and that there may be problems with the grid. The AUX output will cycle on and off if grid parameters are met and the reconnection timer is counting down.
  - ~ This function does not have settable parameters other than those of the **Grid Interface Protection** menu (see Table 16 beginning on page 65).
- **Source Status** activates the AUX output whenever the inverter accepts an AC source. It can activate a light or alarm to show that the utility grid is present or that a generator has started. Alternately, it could be used to show that the source has disconnected.
  - ~ This function does not have settable parameters.
- **AC Divert** activates the AUX output to divert (or “dump”) excess renewable energy to an AC load, usually an AC device powered by the inverter itself. This prevents overcharging of the batteries. This function can serve as rough charge regulation for an external charging source.
  - ~ When battery voltage rises above a settable high voltage level, the AUX output is activated after a settable delay. The AUX output controls a larger relay, which allows current to flow from the batteries to a dedicated AC load when energized. Diversion is usually used to regulate battery charging. The AC device is usually wired to the output or load panel and must be left on. It must be sized to dissipate all of the energy from the renewable source if necessary. Diversion will turn off following a delay when a low DC voltage setting is reached.
  - ~ The AUX output will automatically turn on to run the loads if the inverter accepts an AC source.
  - ~ Settable parameters include:
    - Low and high DC voltage
    - On and off delay
  - ~ During variable conditions, the AUX output is triggered no more than once per minute (if voltage conditions are still met). This prevents rapid nuisance cycling of the AC load.
  - ~ AC Divert should not be used as the sole source of battery regulation. If the inverter shuts down or fails, the batteries could suffer severe damage. This function should be supported by an external regulator.
    - If the inverter shuts down due to overload, the AUX output will also shut down. If the inverter load exceeds 30 Aac, the AUX output will turn off to prevent an overload condition.
    - If either the FETs or the capacitors (see page 56) become too hot, the AUX will turn off due to diminished inverter wattage capacity.

## Operation


Note that even if every function in the menu is set to **Off**, external programming from other devices may still activate the AUX output. An example is the system display's AGS function (see page 45).

The AUX functions are summarized in Table 5.

**Table 5      Aux Mode Functions**

Name	Purpose	Triggers		Settable Points
		Start	Stop	
<b>Load Shed</b>	Operates designated loads normally; turns off loads in severe conditions	➤ High Vdc	➤ Low Vdc ➤ High temp ➤ Low output Vac ➤ High input Aac	➤ Low & high Vdc ➤ On & Off delay
<b>Gen Alert</b>	Starts generator to charge batteries	➤ Low Vdc	➤ High Vdc	➤ Low & high Vdc ➤ On & Off delay
<b>Fault</b>	Signals that the Radian shut down due to error	➤ Error present	➤ Error cleared	None
<b>Vent Fan</b>	Runs fan to vent batteries while charging	➤ High Vdc	➤ Below high Vdc	➤ High Vdc ➤ Off delay
<b>Cool Fan</b>	Runs fan to cool Radian	➤ Internal sensor > 60°C	➤ Internal sensor < 49°C	None
<b>DC Divert</b>	Turns on DC dump load to prevent overcharging	➤ High Vdc	➤ Low Vdc	➤ Low & high Vdc ➤ On & Off delay
<b>GT Limits</b>	Signals disconnect of grid-tied Radian due to AC conditions	➤ GIP parameters not met	➤ GIP parameters met	None
<b>Source Status</b>	Signals that the Radian accepted an AC source	➤ AC source accepted	➤ AC source disconnected	None
<b>AC Divert</b>	Turns on AC dump load to prevent overcharging	➤ High Vdc ➤ AC source accepted	➤ Low Vdc ➤ High output load ➤ High temperature	➤ Low & high Vdc ➤ On & Off delay

## System Display-Based Functions

A system display such as the OutBack MATE3 can provide functions not available in the inverter. These functions are summarized here to provide a better idea of overall system capabilities. 

The system display must be present for these functions to operate. If a function is set up (or already in operation) but the system display is removed, the function will not operate.

### Advanced Generator Start (AGS)

As noted under the **Gen Alert** function (see Table 5), the system is capable of starting a generator. **Gen Alert** simply starts and stops the generator based on battery voltage. For more advanced control, the inverter system can use the Advanced Generator Start (AGS) function, which utilizes the entire three-stage charging cycle. It can start according to battery voltage, inverter load, time of day, and other criteria. AGS has a quiet time application which restricts the generator from starting at inconvenient times. Additional applications are also available.



#### IMPORTANT:

This function is higher-priority than **Gen Alert** or any other inverter function. It can activate the 12V AUX or RELAY AUX even if the inverter has disabled them. When AGS is in use, **Gen Alert** and other AUX functions should be disabled on that AUX output by setting it to **OFF**. This will avoid programming conflicts.

#### IMPORTANT:

When using AGS (or **Gen Alert**), the generator must be connected to the inverter's **GEN** terminals. If the input priority is set to **GRID** and the **GRID** terminals are energized, an automatically controlled generator will shut down. This prevents an automatic generator from working correctly when using the **GRID** terminals.

## Grid Functions

The following functions affect the transfer of the Radian inverter to and from an AC source (usually the utility grid). These functions are based in the system display because they are system-wide. They affect the transfer of all inverters on the system.

### High Battery Transfer (HBX)

In HBX mode, the system is connected to the utility grid. However, it will use battery power as the first priority. The utility grid is locked out until needed.

The system runs on battery-supplied power for as long as the batteries can be sustained. It is expected that the system will be supplied by renewable sources such as PV power. When the batteries become depleted, the system reconnects to the utility grid to operate the loads.

The batteries may be recharged during this time using the renewable source. When the batteries are recharged to a high enough voltage, the system transfers back to the batteries as the primary source (hence the name High Battery Transfer).

**NOTE:** The inverter's charger should be off. High Battery Transfer mode is intended to use only the renewable source for charging batteries. Renewable charging is the motivator for returning to battery (and renewable) operation. Use of the inverter's charger interferes with this priority. It also may not charge effectively.

## Operation

**HBX** mode has similar priorities to the **Mini Grid** input mode contained within the Radian inverter. Either mode may achieve similar results, but they are not identical. See page 18 for the advantages and disadvantages of each mode.

## Grid Use Time

The inverter system is capable of connecting to, or disconnecting from, the utility grid based on time of day. It can also be programmed to connect at different times on weekdays and on weekends.

## Load Grid Transfer

The inverter system is capable of connecting to, or disconnecting from, the utility grid based on load size. This avoids undesirable battery discharge from excessive loads. It can also be programmed to connect to the grid when the batteries reach a low voltage due to excessive discharge.

[illegible]







# Metering

## MATE3 Screens


The MATE3 system display can monitor the GS inverter and other networked OutBack devices.

From the Home screen, the Inverter “soft” key accesses the screens for monitoring the inverter. 



## Inverter Screens

The Inverter soft key opens a series of screens showing the inverter operating mode, battery voltage, and status of several AC operations. The first screen displays AC information on the inverter’s L1 input and output. The **<Next>** soft key proceeds to a screen that shows the same information for L2. The **<Port>** soft key will select other networked OutBack inverters, if present.




### Screen items:

- The upper left corner is the Inverter Mode (see above). When **Charging** is indicated, the Charge Mode specifies the stage.
- **Invert** displays the kilowatts and AC amperage generated by the inverter. It may go to loads, or in a grid-interactive system it may be sold back to the utility grid.


## Metering

- **Charge** displays the kilowatts and AC amperage consumed for the inverter to charge the battery bank. This line also shows the present charging stage.
- **Load** displays kilowatts and AC amperage consumed by devices on the inverter's output. It can be the same as **Invert**.
- **Buy** displays the kilowatts and AC amperage brought into the inverter's input for both charging and loads. This is usually a total of **Charge** and **Load**.
- **Battery** displays the uncompensated battery voltage.
- **AC Out** displays the AC voltage measured at the inverter's output (the sum of the L1 and L2 readings). If an AC source is present, this reading is usually the same as **AC In**.
- **AC In** displays the AC voltage measured at the inverter's input from an AC source (the sum of the L1 and L2 readings). This number may be erratic or inaccurate upon first connection until the inverter synchronizes with the input source.
- **AUX** displays the current status of the inverter's Auxiliary (AUX) 12-volt output. **Relay** displays the current status of the inverter's Auxiliary relay contacts. (See page 41.)
- A diode symbol may appear to the left of the screen name to indicate "diode charging" mode. This is a mode that allows fine control of charging, selling, and load support. It does not visibly affect operation.

From either **L1 Phase** or **L2 Phase**, the **<Graph>** soft key brings up a series of screens which plot various types of data over time on the MATE3 screen. 

## Battery Screen

From the **L2 Phase** screen, the **<Next>** soft key brings up a screen showing charger status, charger settings, and battery voltage and temperature information.



### Screen items:

- **Actual** displays the uncompensated battery voltage.
- **Absorb** displays the charger's Absorption voltage setting. (See page 29.)
- **Float** displays the charger's Float voltage setting. (See page 30.)
- **Equalize** displays the charger's Equalization voltage setting. (See page 33.)
- **Temp Comp** displays the corrected battery voltage using temperature readings from the Remote Temperature Sensor (RTS). If no RTS is present, **Temp Comp** and **Actual** will read the same. (See page 33.)
- **Batt Temp** displays the battery temperature in degrees Celsius, as measured by the RTS. It is only valid for port 1 on the HUB. If other ports are selected, or if no RTS is present, the characters ### will be displayed.
- **Re-Float** displays the Re-Float setting which was programmed into the inverter's charger. This is the voltage used for the inverter to return from Silent mode to the float stage. (See page 30.)
- **Sell RE** voltage is the target voltage used by the inverter for both the Offset and grid-interactive functions when the charger is otherwise inactive. (See pages 15 and 35.)


The **<Warn>** and **<Error>** keys bring up screens with various fault information. See the next section.



# Troubleshooting

## Basic Troubleshooting

Table 6 is organized in order of common symptoms, with a series of possible causes. Each cause also shows possible troubleshooting remedies, including system display checks where appropriate.



Metal pads are located at these locations. In troubleshooting, AC voltages can be measured at this series of test points.

**Figure 15 AC Test Points**



### WARNING: Shock Hazard

During an error shutdown, the inverter's output terminals are not live. However, if the inverter recovers from a shutdown, the terminals will become live without notice. Several error shutdowns can be recovered automatically, including **Low Battery V**, **High Battery V**, and **Over Temperature**. See page 55.

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
No AC output (will not invert).	No DC voltage.	Use a DC voltmeter to check the voltage directly on the DC terminals. If not present, the problem is external. If present, the inverter could be damaged. Contact OutBack Technical Support. <sup>3</sup>
	Jumper J3 missing.	See the Installation Manual for the location of J3. Confirm the jumper is present. If missing, replace the jumper. Or follow the Installation Manual instructions to install an external switch.
	Unit defaulted off (No MATE3 present; initial install; J3 confirmed present).	The Radian inverter is given an initial Off command in the factory. With DC present, use narrow pliers to remove jumper J3 from its pins. Once removed, install it again. This is the equivalent of "jiggling the switch."
	Inverter set to <b>Off</b> .	<i>MATE3 system display only:</i> Set to <b>On</b> with the <b>INVERTER</b> hot key.

<sup>3</sup> See inside front cover of this manual.

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
	Inverter set to <b>Search</b> (Search mode).	<i>MATE3 system display only:</i> If constant power is required, set to <b>On</b> with the <b>INVERTER</b> hot key. (If this setting was intentional, then no action is required.)
One or more units have no output but others do (in multi-inverter system).	Unit is slave and is in Power Save mode.	<i>MATE3 system display only:</i> Check Power Save levels in the <b>Inverter Stacking</b> menu and test with loads. Determine if the inverter comes on at the appropriate levels. (If this setting was intentional, then no action is required.)
Will not connect to the AC source.	No AC input.	Check the AC voltage on the inverter's input test points. (See page 49.) If not present, the problem is external. If present, the inverter could be damaged. Contact OutBack Technical Support. <sup>4</sup>
	The L1 output is wired to its L2 input, or the other way around. The problem is accompanied by shifts in frequency.	Disconnect the wires from the inverter's AC input terminals or AC output terminals, or both. If the problem immediately disappears, it is an external wiring issue. The inverter's input and output terminals must remain isolated from each other.
	AC source does not meet requirements.	<i>MATE3 system display only:</i> Check the <b>Last AC Disconnect</b> screen (using the <b>AC INPUT</b> hot key and the <b>Discon</b> selection) for the reason for disconnection. If the unit never originally connected, check the <b>Warning</b> menu (using the Inverter soft key from the Home screen). Confirm source voltage and frequency.
	AC source meets requirements but is "noisy" or irregular.	<i>MATE3 system display only:</i> The <b>Generator</b> input mode can accept irregular AC power. Select that mode for that input.
	Inverter was manually set to disconnect from AC.	<i>MATE3 system display only:</i> Change the AC Input Control setting from <b>Drop</b> to <b>Use</b> with the <b>AC INPUT</b> hot key. (If this setting was intentional, then no action is required.)
	Grid use function has disconnected from AC.	<i>MATE3 system display only:</i> If activated prematurely, check the MATE3's <b>Grid Use Time</b> settings and the MATE3 clock settings. (If this setting was intentional, then no action is required.)
	High Battery Transfer ( <b>HBX</b> ) mode has disconnected from AC.	<i>MATE3 system display only:</i> Check the <b>AC INPUT</b> hot key screen to see if <b>HBX</b> mode is in use. If activated prematurely, check the settings of <b>HBX</b> mode. (If this setting was intentional, then no action is required.)
	<b>Mini Grid</b> input mode has disconnected from AC.	<i>MATE3 system display only:</i> Check the <b>Inverter</b> part of the <b>Settings</b> menu to see if <b>Mini Grid</b> mode is in use. If activated prematurely, check the settings of <b>Mini Grid</b> mode. (If this setting was intentional, then no action is required.)
	Conflicting programming.	<i>MATE3 system display only:</i> Check to see if more than one of these is enabled: <b>Mini Grid</b> , <b>HBX</b> , <b>Grid Use Time</b> , <b>Load Grid Transfer</b> . These have conflicting priorities. Only one can be used at a time.
	<b>Grid Tied</b> mode has disconnected from AC.	AC source does not meet requirements; see related entry under "Will not sell power to the utility grid" (next page).

<sup>4</sup> See inside front cover of this manual.

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
	Conflicting AC sources. Priority input is interfering with secondary input.	If AC is present on the priority input, the inverter will not connect to AC on the second input. This is true even if the first input is not connected for other reasons (programming, low power quality).
Low charge rate.	Charge complete or nearly complete.	Check the DC voltage and charging stage using the MATE3, if present. Confirm with DC voltmeter.
	MATE3's DC meter reads significantly higher than actual battery voltage.	Check the DC voltage on the inverter's DC terminals. If different from the MATE3 reading, the inverter could be damaged. Otherwise, check the DC voltage on batteries with a voltmeter. If different from the reading on the inverter, this could be a DC connection problem.
	High output loads.	If total loads and charge exceed the AC input setting, charge rate decreases to give priority to the loads. Turn off some of the output loads and test the charge rate again.
	High temperature.	The inverter will reduce the current rate for charging and other activities if the internal temperature exceeds a certain level. Check temperature readings and allow the inverter to cool if necessary. (See page 57.) External cooling may also be applied.
Will not charge.	No AC input.	See "Will not connect to AC" category.
	Charger set to <b>Off</b> .	<i>MATE3 system display only:</i> Check the <b>Charger Mode</b> screen with the <b>CHARGER</b> hot key and set to <b>On</b> or <b>Auto</b> . (If this setting was intentional, then no action is required.)
	<b>Grid Zero</b> mode in use.	<i>MATE3 system display only:</i> The charger is inoperative in <b>Grid Zero</b> mode. (If this setting was intentional, then no action is required.)
Will not sell power to the utility grid.	Grid-tied function has been manually disabled.	<i>MATE3 system display only:</i> Check the <b>Grid-Tie Enable</b> setting in the <b>Grid-Tie Sell</b> menu. Confirm it is set to <b>Y</b> .
	<b>Grid Tied</b> mode not in use on the appropriate input.	<i>MATE3 system display only:</i> Check the <b>Inverter</b> part of the <b>Settings</b> menu to see if <b>Grid Tied</b> mode is in use. Confirm that it has been selected for the correct Radian input terminals.
	AC source does not meet requirements; this item is usually accompanied by disconnecting from the utility grid when in <b>Grid Tied</b> mode.	Verify grid voltage and frequency. Determine if they are within the inverter's approved limits. If not, the inverter is operating correctly. Contact the utility company if necessary. <i>MATE3 system display only:</i> The program limits are found in the inverter's <b>Grid Interface Protection</b> menu. See the <b>Grid Tied</b> mode beginning on page 15 for more information on this menu.
	The inverter has other criteria besides the AC source which must be met, such as the qualifying time.	<i>MATE3 system display only:</i> Check <b>Sell Status</b> screen using the Home screen's soft keys. The inverter may be operating correctly. Depending on the conditions which need to be met, the delay may be temporary,
	The inverter will perform the Offset function before attempting to sell.	Output loads can consume all excess renewable power if they are large enough. (The Offset function "sells to the loads.") Turn off some output loads and observe the sell operation.

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
Reduced power sold to the utility grid.	AC source voltage is driven high when the inverter sells large amounts of power.	When the inverter senses a rise in grid voltage while selling, it reduces the sell current, to avoid forcing the voltage to unacceptable levels. Check AC input voltage while selling. The inverter may be operating correctly.
	High temperature.	The inverter will reduce the current rate for selling and other activities if the internal temperature exceeds a certain level. Check temperature readings and allow the inverter to cool if necessary. (See page 57.) External cooling may also be applied.
Inverter does not perform the Offset function when expected.	Incorrect input mode.	Offset does not function in <b>Generator</b> , <b>UPS</b> , and <b>Backup</b> modes.
	Specific mode only offsets under particular conditions.	<b>Support</b> mode will perform the Support function based on load. This may appear as Offset without reaching the reference voltage. <b>Grid Zero</b> mode will perform Offset based on the <b>DoD Volts</b> setting. Other reference voltages are not used.
Unusual voltage on hot or neutral output line.	System neutral and ground may not be bonded.	Test <b>L1 OUT</b> , <b>L2 OUT</b> , and <b>N OUT</b> test points with AC voltmeter. (See page 49.) These measurements should give full voltage. Test neutral and ground connections. This measurement should read zero volts. Any other result means neutral and ground are not bonded correctly. If this is the case, the hot line often reads 60 to 75 Vdc and the neutral reads 45 to 60 Vdc with respect to ground. (If bonding is not required or is prohibited by national or local codes, then no action may be required.)
Unusual and different voltages on AC hot input lines.	Input neutral is not connected correctly. The inverter also may not connect to the AC source.	Test L1 input and neutral connections with AC voltmeter. Test L2 input and neutral connections with AC voltmeter. (This can be on <b>Grid</b> or <b>Gen</b> input, depending on where the symptoms appear.) Test L1 to L2 input. From hot to neutral should be approximately 120 Vac unless the output has been adjusted. L1 to L2 should be approximately 240 Vac. If the two outputs are different voltages but still add up to 240 Vac, the neutral is not connected to the inverter.
	Inverter has not synchronized with input source.	<i>MATE3 system display only:</i> The <b>AC In</b> reading accessed by the Inverter soft key may be erratic or inaccurate after initial connection until the inverter has synchronized with the AC source. This may require a short time.
Loads drop out or crash during transfer.	Erratic AC source voltage.	Check AC voltage on the inverter's input test points. (See page 49.) If not consistent, the problem is external. <i>MATE3 system display only:</i> AC source voltage may have dipped or hovered at a low enough point to crash a sensitive load before the inverter could take over. This can happen if the inverter's <b>Grid AC Input Voltage Limits</b> or <b>Gen AC Input Voltage Limits</b> were turned down to accommodate a problematic AC source. To make the inverter respond sooner, raise the lower limit setting in the appropriate menu. (If this setting was intentional, then no action is required.)
	Inverter set to <b>Search</b> (Search mode).	The unit will take a moment to come out of Search mode after transferring. <i>MATE3 system display only:</i> If constant power is required, set to <b>ON</b> with the <b>INVERTER</b> hot key. (If this setting was intentional, then no action is required.)

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
	Loads sensitive to inverter's transfer time. <b>UPS</b> mode not in use on the appropriate input.	<i>MATE3 system display only:</i> Most of the inverter's input modes feature a small but noticeable response time during transfer. Certain loads (such as highly sensitive computers) may not respond well. The <b>UPS</b> input mode has a faster response time. Select this mode for the appropriate input. (See page 17.)
	Loads too large.	The unit can transfer more power than it can invert. If loads are oversized, the unit will falter or crash when switching to batteries. Reduce the size of the loads.
	Undersized battery cables.	Battery cables smaller than recommended will cause a significant voltage drop when switching to batteries, acting like either an overload or a low-battery condition. Size all cables correctly.
Unit reads AC input, even though no source is present.	Internal transfer relay may be damaged. May be accompanied by <b>AC Relay Fault</b> error and shutdown.	Disconnect AC input wires and turn inverter on. Test the AC input and neutral test points with an AC voltmeter. (See page 49.) If voltage appears there, the transfer relay may be jammed. Contact OutBack Technical Support. <sup>5</sup> This problem is not common. If this occurs, it is usually on only the Grid or Gen input — not both.
	False reading due to noise.	Electrical noise can cause false readings on the metering circuits when no voltage is present. The readings are usually less than 30 Vac. If this is the case, no action is required.
Inverter clicks repeatedly. AC output voltage rises or drops to unusual levels with every click.	Inverter's output has been connected to its input. Voltage shifts are the result of trying to match its own voltage.	Disconnect the wires from the inverter's AC input or AC output terminals, or both. If the problem immediately disappears, it is an external wiring issue. The inverter's <b>AC IN</b> and <b>AC OUT</b> must remain isolated from each other.
	Low AC input voltage. Can be caused by weak AC source, or by faulty input connection.	Test AC hot and neutral input test points with an AC voltmeter. (See page 49.) If low or fluctuating, this is an external problem.
	A generator is connected to the input terminals while the unit is in the <b>Grid Tied</b> input mode.	The inverter is not intended to sell power to a generator. The selling activity will drive the generator voltage up to the disconnection point. It will then reconnect to the generator and try again. Change input modes, or move the generator to an input with a different mode selected.
Inverter hums loudly. System display may show messages for high battery voltage, low battery voltage, or backfeed error.	Inverter output is being fed with an external AC source that is out of phase.	Disconnect AC output wires. Turn the inverter off and then on. If the problem clears, reconnect the AC output wires. If the problem recurs when reconnected, an external AC source is connected to the output.
	Inverter has been incorrectly stacked with another unit on the same output. All units come defaulted as master.	Check HUB ports and make certain the master inverter is plugged into port 1. <i>MATE3 system display only:</i> Check stacking settings in the <b>Inverter Stacking</b> menu. Only one master is allowed per system.

<sup>5</sup> See inside front cover of this manual.

**Table 6 Troubleshooting**

Symptom	Possible Cause	Possible Remedy
Generator, external fan, etc. fails to start when signal is provided by AUX output.	AUX output is not connected.	Test the generator or device to confirm functionality. Test the appropriate AUX terminals with a DVM. (If the RELAY AUX terminals are in use, test for continuity. If the 12V AUX terminals are in use, test for 12 Vdc.) If the proper results are present when the menu indicates the function is <b>On</b> (and the device still does not work), then there is an external connection problem. If the proper results are not present with the function <b>On</b> , the AUX circuit may be damaged. Contact OutBack Technical Support. <sup>6</sup>
	Wrong AUX terminals have been programmed.	<i>MATE3 system display only:</i> Confirm that the AUX menu that was programmed matches the terminals that are in use. The <b>Auxiliary Output</b> menu programs the 12V AUX terminals. The <b>Auxiliary Relay</b> menu programs the RELAY AUX terminals.
	Wrong AUX terminals are in use.	If generator or external device requires 12 Vdc, confirm the 12V AUX terminals have been connected. The RELAY AUX terminals do not provide voltage.
Advanced Generator Start ( <b>AGS</b> ) fails to activate when conditions are met (or starts when conditions are not met).	<i>MATE3 system display only:</i> <b>AGS</b> function does not work if another valid input is present.	Check both inputs for a second AC source (utility grid). If the inverter detects an acceptable AC source, it will not allow <b>AGS</b> . This is true even if it is internally disconnected from the source (due to <b>HBX</b> mode, <b>Mini Grid</b> mode, or similar programming).
	MATE3 system display is not present.	<b>AGS</b> programming is located in the MATE3 and cannot function if the MATE3 is removed.
	Other AUX functions are in operation.	<b>Gen Alert</b> or another AUX function may try to start or stop the generator using the wrong criteria. Make sure all other AUX functions are disabled.
<b>AGS</b> or <b>Gen Alert</b> functions start the generator, but the inverter does not accept the power and shuts off the generator again.	The inverter's <b>GRID</b> input is in use and the input priority is set to <b>GRID</b> .	If the input priority is set to <b>GRID</b> and the <b>GRID</b> terminals are energized, an automatically controlled generator will shut down. This could indicate that the generator has been wired to the <b>GRID</b> input, or it could indicate that another AC source is active on the <b>GRID</b> input while the generator is using the <b>GEN</b> input. The <b>GEN</b> input must be the only terminals in use when automatically controlling a generator.  Either the <b>GRID</b> or <b>GEN</b> input can be used when <i>manually</i> controlling a generator.

## Module Select

The GS8048A uses two high-frequency H-Bridge FET modules. The dual design allows half the inverter to shut down for lower idle consumption. Normally this is automatically selected. If one module fails or if troubleshooting is otherwise needed, the module selection can be performed manually. The GS8048A can be directed to use a single, specified module (left or right), or it can be directed to turn on both modules continuously. This procedure should only be performed if directed by OutBack Technical Support<sup>6</sup>.

Although the GS4048A has only a single module, this command is still available. The default setting is **Left**, which is the location of the module. Do not change this setting in the GS4048A.

The Module Select menu options are displayed as part of Table 16, which begins on page 65.

<sup>6</sup> See inside front cover of this manual.



# Error Messages

An error is caused by a critical fault. In most cases when this occurs, the unit will shut down. The MATE3 system display will show an event and a specific error message. This screen is viewed using the MATE3 Home screen's soft keys. (See the MATE3 manual for more instructions.) One or more messages will display **Y** (yes). If a message says **N** (no), it is not the cause of the error.

**NOTE:** The Radian series has no external indicators and requires a system display to identify an error. Some errors will reset automatically when the cause is resolved. These are noted.

It is possible to clear an error by resetting the inverter. The inverter must be turned off, and then on, to reset it. Other possible steps are shown below. Each should be followed by resetting the inverter.

**Table 7 Error Troubleshooting**

Message	Causes	Possible Remedy
<b>Low Output Voltage</b>	Inverter's AC regulation cannot be maintained under high load conditions. <b>NOTE:</b> The GS8048A can maintain only 4 kVA on L1 when L2 has loads between 0 and 4 kVA (at 25°C). The opposite is also true. The GS4048A has similar limits at half this wattage.	Check loads and measure current draw. Remove loads as necessary.
<b>AC Output Shorted</b>	Inverter exceeded its maximum surge current due to severe overload.	Check the loads and wiring. This issue is usually the result of a wiring problem (a short), as opposed to a poorly-sized load.
<b>AC Output Backfeed</b>	Usually indicates another AC power source (out of phase with the inverter) was connected to the unit's AC output.	Disconnect the AC OUT wires from the inverter. Check the wires (not the inverter) with an AC voltmeter. If an AC source is present, shut it off.
<b>Stacking Error</b>	Programming problem among stacked units. (Often occurs if there is no master.) Can also occur if <b>AC Output Backfeed</b> occurs.	<ul style="list-style-type: none"> <li>➤ Check stacking programming and designation of master. (See page 35.)</li> <li>➤ Check for output backfeed from an external source. Disconnect output if necessary.</li> </ul>
<b>Low Battery V<sup>7</sup></b>	DC voltage is below low battery cut-out set point, usually due to battery discharge. This error can be triggered by other causes. It can appear along with <b>Low Output Voltage</b> , <b>AC Output Shorted</b> , or <b>AC Output Backfeed</b> errors.	<ul style="list-style-type: none"> <li>➤ If this error accompanies other errors, treat those conditions as appropriate.</li> <li>➤ If it occurs by itself: Recharge the batteries. The error will clear automatically if an AC source is connected and the charger turns on.</li> </ul>
<b>High Battery V<sup>7</sup></b>	DC voltage exceeded acceptable level. See page 21.	Check the charging source. This problem is usually the result of external charging.
<b>Over Temperature<sup>7</sup></b>	Inverter has exceeded its maximum allowed operating temperature. See page 57.	Allow the inverter to remain off to reduce the temperature, or add external cooling.
<b>Comm Fault</b>	The inverter has suffered an internal communication failure.	Contact OutBack Technical Support. <sup>8</sup>
<b>Loose DC Neg Terminals (L or R)</b>	Loose DC connection on left (L) or right (R) internal power module.	Tighten all DC connections between inverter and battery. If this error is not resolved, contact OutBack Technical Support. <sup>8</sup>
<b>AC Relay Fault</b>	AC transfer relay damaged.	Contact OutBack Technical Support. <sup>8</sup>

<sup>7</sup> This error will clear automatically when the cause of the error is resolved. The inverter will begin functioning again when this occurs.

<sup>8</sup> See inside front cover of this manual.

## Warning Messages

A warning message is caused by a non-critical fault. When this occurs, the unit will not shut down, but the MATE3 system display will show an event and a specific warning message. This screen is viewed using the MATE3 Home screen's soft keys. (See the MATE3 manual for more instructions.) One or more messages will display **Y** (yes). If a message says **N** (no), it is not the cause of the warning.

**NOTE:** The Radian series has no external indicators and requires the MATE3 system display to identify a warning.

Some warnings can become errors if left unattended. Frequency and voltage warnings are meant to warn of a problematic AC source. Often the inverter will disconnect from the source. This will occur if the condition lasts longer than the inverter's transfer delay settings. If the inverter disconnects, the warning will display as long as the source is present, accompanied by a disconnect message. (See page 58.)

Warning screens can only display warnings; they cannot clear them. The way to correct the fault may be obvious from the message.

**Table 8 Warning Troubleshooting**

Message	Definition	Possible Remedy
<b>AC Freq Too High</b>	The AC source is above the upper acceptable frequency limit and prevents connection.	Check the AC source. If it is a generator, reduce its speed.
<b>AC Freq Too Low</b>	The AC source is below the lower acceptable frequency limit and prevents connection.	Check the AC source. If it is a generator, increase its speed.
<b>Voltage Too High</b>	The AC source is above the upper acceptable voltage limit and prevents connection.	Check the AC source. The inverter's acceptance range is adjustable. <b>NOTE:</b> Adjusting the range may accommodate a problematic AC source, but it will not fix it.
<b>Voltage Too Low</b>	The AC source is below the lower acceptable voltage limit and prevents connection.	Check the AC source. Check the AC wiring. The inverter's acceptance range is adjustable. <b>NOTE:</b> Adjusting the range may accommodate a problematic AC source, but it will not fix it.
<b>Input Amps &gt; Max</b>	AC loads are drawing more current from the AC source than allowed by the input setting.	Check the loads. Oversized loads can open circuit breakers. If they exceed the inverter's transfer relay size, the relay can be damaged. This issue is usually the result of a poorly-sized load, as opposed to a wiring problem.
<b>Temp Sensor Bad</b>	An internal inverter temperature sensor may be malfunctioning. One of the three internal sensor meters may give an unusual reading.	In the MATE3, the three readings are labeled <b>Transformer</b> , <b>Output FETs</b> , and <b>Capacitors</b> . These values are given in degrees Celsius. See next page.
<b>Phase Loss</b>	A slave was ordered to transfer to an AC source by the master, but the AC source is the wrong phase or no AC source is present.	Check the AC voltage on the inverter input terminals. If AC voltage is not present, problem is external. If AC voltage is present, the unit may be damaged. Contact OutBack Technical Support. <sup>9</sup>

<sup>9</sup> See inside front cover of this manual.

**Table 8 Warning Troubleshooting**

Message	Definition	Possible Remedy
<b>Fan Failure</b>	The inverter's internal cooling fan is not operating properly. Lack of cooling may result in derated inverter output wattage.	Turn the battery disconnect off, and then on, to determine if the fan self-tests. After this test, contact OutBack Technical Support for the next step. (The next step will depend on the results of the test.)  <b>NOTE:</b> The system can continue to operate if the inverter can be run at reasonable levels. External cooling may also be applied.
<b>Transformer</b> (in <b>Temps</b> menu)	Displays the ambient temperature around the inverter's transformer.	In the MATE3, these values are given in degrees Celsius.  If any reading does not seem to reflect the inverter's temperature or conditions, contact OutBack Technical Support. <sup>10</sup>
<b>Output FETs</b> (in <b>Temps</b> menu)	Displays the temperature of the FETs (Field Effect Transistors) and heat sink.	
<b>Capacitors</b> (in <b>Temps</b> menu)	Displays the temperature of the inverter's ripple capacitors.	

## Temperature Events


The temperature sensor readings shown in Table 8 are used to limit the inverter operation in high temperatures. Table 9 shows the effects on the inverter and the temperature used by each sensor to cause the effect.

**Table 9 Temperature Events**

Effect	Temperature Reading		
	<i>Transformer</i>	<i>Output FETs</i>	<i>Capacitors</i>
<b>Over Temperature</b> error	>125°C	>80°C	>80°C
Reduced charging or selling	=120°C	=80°C	=80°C
Fan turns on	>60°C	>60°C	>60°C
Fan turns off	<49°C	<49°C	<49°C

<sup>10</sup> See inside front cover of this manual.

## Disconnect Messages

Disconnect messages explain why the inverter has disconnected from an AC source after previously being connected. The unit returns to inverting mode if turned on. This screen is viewed using the **AC INPUT** hot key on the MATE3. One or more messages will display **Y** (yes). If a message says **N** (no), it is not the cause of the disconnection. The MATE3 system display may generate a concurrent event and warning message following the disconnection. (See page 56.) If the AC source is removed, the warning will be blank, but the cause of the last disconnection will remain. 

Disconnect messages only display the reason for the disconnection; they cannot correct it. It is usually the result of external conditions, not an inverter fault. If the condition is corrected, the inverter will reconnect. A few settings can be changed to accommodate problems with the AC source.

The reasons shown in the Sell Status menu for ceasing to sell power (see next page) may be the same as disconnect messages. If the Grid Interface Protection settings are exceeded (see page 12), the inverter will disconnect from the utility grid.

Table 10 shows the primary seven reasons for disconnection. An eighth field may be visible, but it can feature several different messages which vary with conditions. A list of these messages and their definitions is featured on the OutBack website at [www.outbackpower.com](http://www.outbackpower.com).

**Table 10 Disconnect Troubleshooting**

Message	Definition	Possible Remedy
<b>Frequency Too High</b>	The AC source has exceeded acceptable frequency levels.	Check AC source. If it is a generator, reduce speed.
<b>Frequency Too Low</b>	The AC source has dropped below acceptable frequency levels.	Check AC source. If it is a generator, increase speed.
<b>Voltage &gt; Maximum</b>	The AC source has exceeded acceptable voltage levels.	Check AC source. The inverter's acceptance range is adjustable. <b>NOTE:</b> Adjusting the range may accommodate a problematic AC source, but it will not fix it.
<b>Voltage &lt; Minimum</b>	The AC source has dropped below acceptable voltage levels.	Check AC source. The inverter's acceptance range is adjustable. <b>NOTE:</b> Adjusting the range may accommodate a problematic AC source, but it will not fix it.
<b>Backfeed</b>	Usually indicates that another AC power source (out of phase with the inverter) was connected to the AC output. Can also occur if an out-of-phase AC source is connected to the AC input.	Disconnect the AC OUT wires. Check the wires (not the inverter) with an AC voltmeter. If an AC source is present, shut it off. (This is more often accompanied by an <b>AC Output Backfeed</b> error.) Check input source and wiring. This can be caused by a source with phase problems.
<b>Phase Lock</b>	The unit cannot remain in phase with an erratic AC source.	Check AC source. This can be caused by a generator with a poorly regulated output. Some generators perform this way when low on fuel. If necessary, use the <b>Generator</b> input mode. (See page 14.)
<b>Island Detect</b>	The grid seems to be present but normal grid conditions are not detected. This can occur if the Radian's input is powered by another inverter instead of the grid. It may be the result of an open main disconnect.	Check all input disconnects or circuit breakers for an open circuit. Check for any other inverters installed in the system and disable them. This may (rarely) occur with a generator. If necessary, use the <b>Generator</b> input mode. (See page 14.)

# Sell Status

Sell Status messages describe conditions relating to the inverter's grid-interactive mode. This screen is viewed using the MATE3 Home screen's soft keys. (See the MATE3 manual for more instructions.) One or more messages will display **Y** (yes). If a message says **N** (no), it is not the cause of the disconnection.

If the inverter has stopped selling or charging unexpectedly, this screen may identify the reason. More often these messages are used by a normally functioning inverter to identify external conditions that are preventing selling or charging. (If nothing has stopped, the messages will indicate that as well.)

The acceptable limits for AC source voltage and frequency are controlled by the Grid Interface Protection settings, which are shown on page 67. If the AC source exceeds these limits, the inverter will stop selling and display the appropriate code. (At the same time it will disconnect from the utility grid, with an appropriate message in Table 10 as shown on page 58.) After the source returns to the acceptable range, the screen will begin its reconnection timer (with a default setting of five minutes). When the timer expires, the inverter will reconnect to the utility grid and begin selling power again.

If the AC source is unstable, it may become unacceptable before the timer expires. This may cause the timer to continually reset. It is possible for brief fluctuations to occur that are too fast to be seen on a DVM. If this happens, the appropriate message will still appear on the system display for a short time to help troubleshoot the problem.

Additionally, undersized wires or bad connections can result in local voltage problems. If a **Voltage Too Low** or **Voltage Too High** message is accompanied by voltage changes that do not appear at the main utility connection, check the wiring.

**Table 11 Sell Status Messages**

<b>Sell Status</b>	<b>Definition</b>
<b><i>Selling Disabled</i></b>	The <b>Grid-Tie Enable</b> command has been set to <b>N</b> (no).
<b><i>Qualifying Grid</i></b>	All utility grid conditions are acceptable. The inverter is running a timed test during which it confirms the grid quality. The timer is shown on the screen. At the end of that time, the inverter may be ready to sell.
<b><i>Frequency Too Low</i></b>	The utility grid's AC frequency is below the acceptable range for selling.
<b><i>Frequency Too High</i></b>	The utility grid's AC frequency is above the acceptable range for selling.
<b><i>Voltage Too Low</i></b>	The utility grid's AC voltage is below the acceptable range for selling.
<b><i>Voltage Too High</i></b>	The utility grid's AC voltage is above the acceptable range for selling.
<b><i>Battery &lt; Target</i></b>	The battery voltage is below the target voltage for that stage (Float, Selling, etc.). No excess energy is available to sell.





# Specifications

## Electrical Specifications

**NOTE:** Items qualified with “default” can be manually changed using the system display.

**Table 12 Electrical Specifications for Radian Models**

Specification	GS8048A	GS4048A
Continuous Output Power at 25°C	8000 VA	4000 VA
Continuous AC Output Current at 25°C	33.3 Aac	16.7 Aac
AC Output Voltage (default)	120/240 Vac	120/240 Vac
AC Output Frequency (default)	60 Hz	60 Hz
AC Output Type	Split-phase	Split-phase
AC Waveform	True Sinewave	True Sinewave
Typical Efficiency	93%	93%
CEC Weighted Efficiency	92.5%	92.5%
Total Harmonic Distortion (maximum)	< 5%	< 5%
Harmonic Distortion (maximum single voltage)	< 2%	< 2%
AC Output Voltage Regulation	± 2%	± 2%
Appliance Protective Class (IEC)	Class I	Class I
Power Factor	–1 to 1	–1 to 1
Inrush Current	None	None
AC Maximum Output Current (1 ms peak)	100 Aac @240 Vac	50 Aac @240 Vac
AC Maximum Output Current (100 ms RMS)	70.7 Aac @240 Vac	35.35 Aac @240 Vac
AC Overload Capability (100 ms surge)	16.97 kVA	8.48 kVA
AC Overload Capability (5 second)	12.0 kVA	6.0 kVA
AC Overload Capability (30 minute)	9.0 kVA	4.5 kVA
AC Maximum Output Fault Current and Duration	109 Aac for 0.364 seconds	54.5 Aac for 0.364 seconds
Power Consumption (idle) – Invert mode, no load	34 watts	34 watts
Power Consumption (idle) – Search mode	10 watts	10 watts
Power Consumption – Off	4 watts	4 watts
AC Input Voltage Range	(L1 or L2) 85 to 140 Vac	(L1 or L2) 85 to 140 Vac
AC Input Frequency Range	54 to 66 Hz at 60-Hz setting 45 to 55 Hz at 50-Hz setting	54 to 66 Hz at 60-Hz setting 45 to 55 Hz at 50-Hz setting
AC Input Current (maximum continuous)	50 Aac	50 Aac
Grid-Interactive Voltage Range (default)	(L1 or L2) 106 to 132 Vac	(L1 or L2) 106 to 132 Vac
Grid-Interactive Frequency Range (default)	59.3 to 60.5 Hz	59.3 to 60.5 Hz
DC Input Voltage (nominal)	48 Vdc	48 Vdc
DC Input Voltage Range	40 to 64 Vdc	40 to 64 Vdc
DC Maximum Input Voltage	68 Vdc	68 Vdc

## Specifications

**Table 12 Electrical Specifications for Radian Models**

Specification	GS8048A	GS4048A
DC Input Power (continuous)	9.5 kVA	4.8 kVA
DC Input Maximum Current (continuous full power)	200 Adc	100 Adc
DC Input Maximum Current (surge)	424.2 Adc	212.1 Adc
DC Input Maximum Current (short-circuit)	8975 Adc	4488 Adc
Battery Charger Maximum AC Input	30 Aac at 240 Vac	15 Aac at 240 Vac
Battery Charger Maximum DC Output	115 Adc	57.5 Adc
DC Output Voltage Range (charging)	44 to 68 Vdc	44 to 68 Vdc
Auxiliary Output	0.7 Adc at 12 Vdc	0.7 Adc at 12 Vdc
Auxiliary Relay	10 A at 250 Vac or 30 Vdc	10 A at 250 Vac or 30 Vdc

## Mechanical Specifications

**Table 13 Mechanical Specifications for Radian Models**

Specification	GS8048A	GS4048A
Inverter Dimensions (H x W x D)	28 x 16 x 8.75" (71.1 x 40.6 x 22.2 cm)	28 x 16 x 8.75" (71.1 x 40.6 x 22.2 cm)
Shipping Dimensions (H x W x L)	14.5 x 21 x 34.5" (36.8 x 53.3 x 87.6 cm)	14.5 x 21 x 34.5" (36.8 x 53.3 x 87.6 cm)
Inverter Weight	125 lb (56.8 kg)	82 lb (37.2 kg)
Shipping Weight	140 lb (63.5 kg)	89 lb (40.3 kg)
Accessory Ports	RJ11 (batt temp) and RJ45 (remote)	RJ11 (batt temp) and RJ45 (remote)
Non-volatile Memory	Yes	Yes
Neutral-Ground Bond Switching	No	No
Chassis Type	Vented	Vented

## Environmental Specifications

**Table 14 Environmental Specifications for Radian Models**


Specification	Value
Rated Temperature Range (meets component specifications; however, please note that the inverter output wattage is derated above 25°C)	–4°F to 122°F (–20°C to 50°C)
Operational Temperature Range (functions, but not rated for operation; does not necessarily meet all component specifications)	–40°F to 140°F (–40°C to 60°C)
Storage Temperature Range	–40°F to 140°F (–40°C to 60°C)
IP (Ingress Protection) Rating of Enclosure	IP20
Environmental Category	Indoor unconditioned
Wet Locations Classification	Wet locations: No
Relative Humidity Rating	93%
Pollution Degree Classification	PD 2
Maximum Altitude Rating	6561' (2000 m)
Overvoltage Category (AC Input)	3
Overvoltage Category (DC Input)	1



## Temperature Derating

All Radian inverters can deliver their full rated wattage at temperatures up to 25°C (77°F). The Radian maximum wattage is rated less in higher temperatures. Above 25°C, the GS8048A is derated by a factor of 80 VA for every increase of 1°C. The GS4048A is derated by 40 VA per 1°C.

Figure 16 is a graph of wattage over temperature, showing the decrease in rated wattage with increased temperature. The graph ends at 50°C (122°F) because the Radian inverter is not rated for operation above that temperature.



## Regulatory Specifications

### Listings

This product carries a listing report by ETL. It is listed to the following standards:

- UL 1741 — Inverters, Converters, Controllers and Interconnection System Equipment for Use With Distributed Energy Resources (2nd Edition, 1/28/2010)
- CSA C22.2 — General Use Power Supplies, No. 107.1-01 Issue: 2001/09/01 Ed:3 (R2006)

### Certifications

This product has been certified by ETL to meet the following standards:

- UL 1778 — Uninterruptible Power Systems, Annex FF (normative): Backfeed Protection Test
- IEC 62109-1:2010 — Safety of Power Converters for use in Photovoltaic Systems

### Compliance

- RoHS: per directive 2011/65/EU
- FCC Part 15.109(G): 2012 Class B



## FCC Information to the User

This equipment has been tested and found to comply with the limits for a Class B digital device when powered by a DC source, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Specification Compliance

Inverters intended for grid-interactive use in the United States and Canada must comply with the established standards of UL 1741 and IEEE 1547 and 1547.1. These standards provide regulation for acceptable output voltage ranges, acceptable output frequency, total harmonic distortion (THD) and anti-islanding performance when the inverter is exporting power to a utility source.


The OutBack grid-interactive models are tested using the procedures listed in IEEE 1547.1 to the standards listed in both UL 1741 and IEEE 1547. The following specifications have been validated through compliance testing and refer to exporting power to a simulated utility source of less than 1% voltage total harmonic distortion (THD).

- The inverter output exceeds the minimum power factor of 0.85 with a typical power factor of 0.96 or better.
- The individual harmonics do not exceed the limits specified in Table 3 of IEEE 1547 Section 4.3.3.
- The THD of the root mean square (RMS) current is less than 5%.
- The inverter ceases to export power to the simulated utility source under islanding conditions specified in IEEE 1547 Section 4.4.1.
- The inverter also ceases to export power to the simulated utility source after the output voltage or frequency of the simulated utility source are adjusted to each of the conditions specified in IEEE 1547 Section 4.2.3 Table 1 and Section 4.2.4 Table 2 within the times specified in those tables. All GS8048A and GS4048A inverters are tested to comply with the table below.

**Table 15 Interconnection Response Times to Abnormal Voltages or Frequencies**

Voltage Range (AC Volts)	Frequency (Hz)	Seconds Allowed	Cycles Allowed
$V < 60.0$	60.0	0.16	9.6
$60.0 < V < 105.6$	60.0	2.0	120.0
$105.6 < V < 132.0$	60.0	no cessation	no cessation
$132.0 < V < 144.0$	60.0	1.0	60.0
$V > 144.0$	60.0	0.16	9.6
120.0	$< 59.3$	0.16	9.6
120.0	$> 60.5$	0.16	9.6

The reconnection delay has a default setting of 5 minutes. The grid-interactive default settings are shown in the **Grid Interface Protection Menu** portion of Table 16.

The **Grid Interface Protection** settings are adjustable. However, this is only available to operators with installer-level access. The reason for this limitation is that there are firm rules concerning the acceptable voltage range, frequency range, clearance time during power loss, and reconnect delay when exporting power back to the utility. The rules differ in different locations around the world, although generally it is expected that the settings cannot be altered by the end user. For this reason, the installer password must be changed from the default to get access to these settings. 

Once this password has been changed, the **Grid Interface Protection** settings can be accessed by using the installer password.

See the **Grid Tied** mode on page 15 for more information. Also see **Default Settings and Ranges**.

## Firmware Revision

This manual applies to inverter models GS8048A and GS4048A with Revision 001.005.xxx or higher.

Updates to the Radian's firmware are periodically available. These can be downloaded from the OutBack website [www.outbackpower.com](http://www.outbackpower.com). See page 12.

## Default Settings and Ranges

**NOTES:** Certain items are retained at the present setting even when the inverter is reset to factory defaults. These items are noted with the letter "X" in the Item column.

Certain items, particularly those in the Auxiliary menus, share common set points. If one of these items is changed in a mode menu, the change will appear in other menus that use the same set point.

Certain menus are only visible when the installer password is used, particularly the Grid Interface Protection menu. These menus are bordered in the table with a double line of this style: **=====**

**Table 16 Radian Inverter Settings**

Field	Item		Default	Minimum	Maximum
<b>INVERTER</b> Hot Key	Inverter Mode		<i>Off</i>	<i>On, Off, or Search</i>	
<b>CHARGER</b> Hot Key	Charger Control		<i>On</i>	<i>On or Off</i>	
<b>AC Input</b> Hot Key	AC Input Mode		<i>Use</i>	<i>Drop or Use</i>	
<b>Search</b>	<i>Sensitivity</i> (see page 23 for increments)		10	0	250
	<i>Pulse Length</i>		8 AC Cycles	4 AC Cycles	20 AC Cycles
	<i>Pulse Spacing</i>		60 AC Cycles	4 AC Cycles	120 AC Cycles
<b>AC Input and Current Limit</b>	<i>Input Priority</i>		<i>Grid</i>	<i>Grid or Gen</i>	
	<i>Grid Input AC Limit</i>		50 Aac	5 Aac	55 Aac
	<i>Gen Input AC Limit</i>		50 Aac	5 Aac	55 Aac
	<i>Charger AC Limit</i>	GS8048A	30 Aac	0 Aac	30 Aac
		GS4048A	15 Aac	0 Aac	15 Aac
<b>Grid AC Input Mode and Limits</b>	<i>Input Mode</i>		<i>Grid Tied</i>	<i>Generator, Support, Grid Tied, UPS, Backup, Mini Grid, Grid Zero</i>	
	<i>Voltage Limit Lower</i>		108 Vac	85 Vac	110 Vac
	(Voltage Limit) <i>Upper</i>		132 Vac	125 Vac	140 Vac
	<i>Transfer Delay</i>		1.0 second	0.12 seconds	4.0 seconds
	<i>Connect Delay</i>		0.2 minutes	0.2 minutes	25.0 minutes
	If <i>Mini Grid</i> mode is selected:	<i>Connect to Grid</i>	48.0 Vdc	44.0 Vdc	64.0 Vdc
		(Connect) <i>Delay</i>	10 minutes	2 minutes	200 minutes
	If <i>Grid Zero</i> mode is selected:	<i>DoD Volts</i>		48.0 Vdc	64.0 Vdc
		<i>DoD Amps</i>	GS8048A	5 Aac	30 Aac
			GS4048A	5 Aac	15 Aac

# Specifications

**Table 16      Radian Inverter Settings**

Field	Item		Default	Minimum	Maximum
Gen AC Input Mode and Limits	<b>Input Mode</b>		<b>Generator</b>	<b>Generator, Support, Grid Tied, UPS, Backup, Mini Grid, Grid Zero</b>	
	<b>Voltage Limit Lower</b>		108 Vac	85 Vac	110 Vac
	(Voltage Limit) <b>Upper</b>		140Vac	125 Vac	140 Vac
	<b>Transfer Delay</b>		1.0 second	0.12 seconds	4.0 seconds
	<b>Connect Delay</b>		0.5 minutes	0.2 minutes	25.0 minutes
	If <b>Mini Grid</b> mode is selected:	<b>Connect to Grid</b>	48.0 Vdc	44.0 Vdc	64.0 Vdc
		(Connect) <b>Delay</b>	10 minutes	2 minutes	200 minutes
	If <b>Grid Zero</b> mode is selected:	<b>DoD Volts</b>	48.0 Vdc	44.0 Vdc	64.0 Vdc
		<b>DoD Amps</b>	GS8048A	5 Aac	30 Aac
			GS4048A	5 Aac	15 Aac
AC Output	<b>Output Voltage</b>	X	120 Vac	100 Vac	130 Vac
	<b>AC Coupled Mode</b>		<i>This selection is inoperative</i>		
Low Battery	<b>Cut-Out Voltage</b>		42.0 Vdc	36.0 Vdc	48.0 Vdc
	<b>Cut-In Voltage</b>		50.0 Vdc	40.0 Vdc	56.0 Vdc
Battery Charger	<b>Absorb Voltage</b>		57.6 Vdc	44.0 Vdc	64.0 Vdc
	(Absorb) <b>Time</b>		1.0 hours	0.0 hours	24.0 hours
	<b>Float Voltage</b>		54.4 Vdc	44.0 Vdc	64.0 Vdc
	(Float) <b>Time</b>		1.0 hours	0.0 hours	24/7
	<b>Re-Float Voltage</b>		50.0 Vdc	44.0 Vdc	64.0 Vdc
	<b>Re-Bulk Voltage</b>		49.6 Vdc	44.0 Vdc	64.0 Vdc
Battery Equalize	<b>Equalize Voltage</b>		58.4 Vdc	44.0 Vdc	68.0 Vdc
	(Equalize) <b>Time</b>		1.0 hours	0.0 hours	24.0 hours
Auxiliary Output	<b>Aux Control</b>		<b>Auto</b>	<b>Off, Auto or On</b>	
	<b>Aux Mode</b>		<b>Vent Fan</b>	<b>Load Shed, Gen Alert, Fault, Vent Fan, Cool Fan, DC Divert, GT Limits, Source Status, AC Divert</b>	
	(Load Shed) <b>ON: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Load Shed ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Load Shed) <b>OFF: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(Load Shed OFF) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Gen Alert) <b>ON: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(Gen Alert ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Gen Alert) <b>OFF: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Gen Alert OFF) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Vent Fan) <b>ON: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Vent Fan) <b>Off Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(DC Divert) <b>ON: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(DC Divert ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(DC Divert) <b>OFF: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(DC Divert OFF) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(AC Divert) <b>ON: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(AC Divert ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(AC Divert) <b>OFF: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(AC Divert OFF) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
Auxiliary Relay	<b>Aux Control</b>		<b>Auto</b>	<b>Off, Auto or On</b>	
	<b>Aux Mode</b>		<b>Gen Alert</b>	<b>Load Shed, Gen Alert, Fault, Vent Fan, Cool Fan, DC Divert, GT Limits, Source Status, AC Divert</b>	
	(Load Shed) <b>ON: Batt &gt;</b>		56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Load Shed ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Load Shed) <b>OFF: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(Load Shed OFF) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes
	(Gen Alert) <b>ON: Batt &lt;</b>		44.0 Vdc	40.0 Vdc	56.0 Vdc
	(Gen Alert ON) <b>Delay</b>		0.5 minutes	0.1 minutes	25.0 minutes

**Table 16 Radian Inverter Settings**

Field		Item		Default	Minimum	Maximum
	(Gen Alert) <b>OFF: Batt &gt;</b>			56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Gen Alert OFF) <b>Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
	(Vent Fan) <b>ON: Batt &gt;</b>			56.0 Vdc	40.0 Vdc	72.0 Vdc
	(Vent Fan) <b>Off Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
	(DC Divert) <b>ON: Batt &gt;</b>			56.0 Vdc	40.0 Vdc	72.0 Vdc
	(DC Divert ON) <b>Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
	(DC Divert) <b>OFF: Batt &lt;</b>			44.0 Vdc	40.0 Vdc	56.0 Vdc
	(DC Divert OFF) <b>Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
	(AC Divert) <b>ON: Batt &gt;</b>			56.0 Vdc	40.0 Vdc	72.0 Vdc
	(AC Divert ON) <b>Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
	(AC Divert) <b>OFF: Batt &lt;</b>			44.0 Vdc	40.0 Vdc	56.0 Vdc
	(AC Divert OFF) <b>Delay</b>			0.5 minutes	0.1 minutes	25.0 minutes
Inverter Stacking		Stack Mode		Master	Master, Slave	
Power Save Ranking	Mode = Master:	Master Power Save Level		0	0	31
	Mode = Slave:	Slave Power Save Level		1	1	31
Grid-Tie Sell	Grid-Tie Enable			Y	Y or N	
	Sell Voltage			52.0 Vdc	44.0 Vdc	64.0 Vdc
Module Control	Module Control	GS8048A	Auto	Auto, Left, Right, Both		
		GS4048A	Left	Auto, Left, Right, Both		
Calibrate	Grid AC Input Voltage		X	0 Vac	-7 Vac	7 Vac
	Gen AC Input Voltage		X	0 Vac	-7 Vac	7 Vac
	Output Voltage		X	0 Vac	-7 Vac	7 Vac
	Battery Voltage		X	0.0 Vdc	-0.8 Vdc	0.8 Vdc
Grid Interface Protection Menu						
Operating Frequency		Operating Frequency	X	60 Hz	50 Hz, 60 Hz	
Stage 1 Voltage Trip	Over Voltage Clearance Time		X	1.0 seconds	0.12 seconds	5.0 seconds
	Over Voltage Trip		X	132 Vac	120 Vac	150 Vac
	Under Voltage Clearance Time		X	2.0 seconds	0.12 seconds	5.0 seconds
	Under Voltage Trip		X	106 Vac	80 Vac	120 Vac
Stage 2 Voltage Trip	Over Voltage Clearance Time		X	0.16 seconds	0.12 seconds	5.0 seconds
	Over Voltage Trip		X	144 vac	120 Vac	150 Vac
	Under Voltage Clearance Time		X	0.16 seconds	0.12 seconds	5.0 seconds
	Under Voltage Trip		X	60 Vac	60 Vac	120 vac
Frequency Trip	Over Frequency Clearance Time		X	0.16 seconds	0.12 seconds	5.0 seconds
	Over Frequency Trip	60-Hz system	X	60.5 Hz	60.1 Hz	65.0 Hz
		50-Hz system		50.5 Hz	50.1 Hz	55.0 Hz
	Under Frequency Clearance Time		X	0.16 seconds	0.12 seconds	5.0 seconds
	Under Frequency Trip	60-Hz system	X	59.3 Hz	55.0 Hz	59.9 Hz
50-Hz system		49.3 Hz		45.0 Hz	49.9 Hz	
Mains Loss	Clearance Time		X	2.0 seconds	1.0 seconds	5.0 seconds
	Reconnect Delay		X	300 seconds	2 seconds	302 seconds
Sell Current Limit	Maximum Sell Current	GS8048A	X	30 Aac	5 Aac	30 Aac
		GS4048A		15 Aac	5 Aac	15 Aac

## Definitions

The following is a list of initials, terms, and definitions used in conjunction with this product.

**Table 17 Terms and Definitions**

Term	Definition
12V AUX	Auxiliary connection that supplies 12 Vdc to control external devices
AC	Alternating Current; refers to voltage produced by the inverter, utility grid, or generator
AGS	Advanced Generator Start
CSA	Canadian Standards Association; establishes Canadian national standards and the Canadian Electrical Code, including C22.1 and C22.2
DC	Direct Current; refers to voltage produced by the batteries or renewable source
DVM	Digital Voltmeter
FCC	Federal Communications Commission
GND	Ground; a permanent conductive connection to earth for safety reasons; also known as Chassis Ground, Protective Earth, PE, Grounding Electrode Conductor, and GEC
Grid/Hybrid™	System technology which optimizes both grid-interactive and off-grid options
Grid-interactive, grid-intertie, grid-tie	Utility grid power is available for use and the inverter is a model capable of returning (selling) electricity back to the utility grid
HBX	High Battery Transfer; a function of the remote system display
IEEE	Institute of Electrical and Electronics Engineers; refers to a series of standards and practices for the testing of electrical products
IEC	International Electrotechnical Commission; an international standards organization
LBCO	Low Battery Cut-Out; set point at which the inverter shuts down due to low voltage
NEC	National Electric Code
NEU	AC Neutral; also known as Common
Neutral-to-ground bonding	A mechanical connection between the AC neutral (Common) bus and the ground (PE) bus; this bond makes the AC neutral safe to handle
Off-grid	Utility grid power <b>is not</b> available for use
PV	Photovoltaic
RELAY AUX	Auxiliary connection that uses switch (relay) contacts to control external devices
RTS	Remote Temperature Sensor; accessory that measures battery temperature for charging
Split-phase	A type of utility electrical system with two "hot" lines that typically carry 120 Vac with respect to neutral and 240 Vac with respect to each other; common in North America
System display	Remote interface device (such as the MATE3), used for monitoring, programming and communicating with the inverter; also called "remote system display"
Three-phase, 3-phase	A type of utility electrical system with three "hot" lines, each 120° out of phase; each carries the nominal line voltage with respect to neutral; each carries voltage with respect to each other equaling the line voltage multiplied by 1.732
Utility grid	The electrical service and infrastructure supported by the electrical or utility company; also called "mains", "utility service", or "grid"



# Index

## 1

12V AUX ..... 41

## A

Absorption Stage ..... 29  
AC Input ..... 23  
AC Source Acceptance ..... 24  
AC Test Points ..... 10, 49  
Adding New Devices ..... 11  
AGS ..... 45  
Audience ..... 5  
AUX ..... 41, 68  
AUX Functions  
    Cool Fan ..... 43  
    Diversion Control ..... 43  
    Fault ..... 42  
    GenAlert ..... 42, 45  
    GT Limits ..... 43  
    LoadShed ..... 41  
    Source Status ..... 43  
    Summary Table ..... 44  
    Vent Fan ..... 42

## B

Backup ..... 17  
Battery Charging ..... 27  
    Current ..... 27  
    Graphs ..... 28, 32  
    Steps ..... 28  
Battery Charging Graph ..... 33

## C

Caution Symbol ..... 5  
Charging  
    Absorption Stage ..... 29  
    Current ..... 27  
    Float Stage ..... 30  
    Float Timer ..... 30  
    New Bulk ..... 32  
    None ..... 29

Silent ..... 30  
Steps ..... 29, 31  
Commissioning ..... 9  
Cool Fan ..... 43

## D

Default Settings ..... 65  
Definitions ..... 68  
Design ..... 21  
Disconnect ..... 58  
Diversion Control ..... 43  
DVM ..... 9, 11

## E

Equalization ..... 33  
Errors ..... 55

## F

FCC ..... 64, 68  
Features ..... 6  
Firmware ..... 12, 65  
Float Stage ..... 30  
Functional Test ..... 9  
Functions ..... 6  
    AC Input Limit ..... 23  
    AC Transfer ..... 25  
    Inverting ..... 21  
    LBCO ..... 22  
    Offset ..... 35  
    Search ..... 23

## G

GenAlert ..... 42, 45  
Generator ..... 14  
    Sizing ..... 25  
Generator Acceptance ..... 24  
Grid Acceptance ..... 24  
Grid Interface Protection ..... 16, 25, 65, 67  
Grid Tied ..... 15  
Grid Use Time ..... 18, 46  
Grid Zero ..... 19

# Index

Grid-Interactive .....	15, 68
GT Limits .....	43

## H

High Battery Cut-Out .....	22
High Battery Transfer (HBX) .....	18, 45

## I

IEC .....	68
Important Symbol .....	5
Input Modes .....	6, 13, 23, 35
Summary Table .....	20
Input Priorities .....	23
Inverting .....	21

## L

LBCO (Low Battery Cut-Out) .....	22
Load Grid Transfer .....	18, 46
LoadShed .....	41
Low Battery Cut-In .....	22

## M

MATE or MATE2 .....	7
MATE3 .....	7, 8, 47, 49
Mini Grid .....	18, 45
Modes .....	6
Backup .....	17
Generator .....	14
Grid Tied .....	15
Grid Zero .....	19
Mini Grid .....	18, 45
Summary Table .....	20
Support .....	14
UPS .....	17
Module Select .....	54
Modules .....	38

## O

Offset .....	35
Output .....	
Frequency .....	22
Voltage .....	22

## P

Parallel Stacking .....	37
Power Save .....	38
Powering Down .....	11

## R

Ranks, Power Save .....	38
Regulatory .....	63
Relay AUX .....	41
Remote System Display .....	68
Remote Temperature Sensor (RTS) .....	33, 68

## S

Safety .....	5
Search .....	23
Sell Status .....	59
Settings .....	65
Silent .....	
Charging .....	30
Power Save .....	38
Source Status .....	43
Specifications .....	
Electrical .....	61
Environmental .....	62
Mechanical .....	62
Regulatory .....	63
Stacking .....	36
Parallel .....	37
Startup .....	9
Support .....	14
Switch .....	8
Symbols Used .....	5
System Display .....	47, 49, 68

## T

Temperature .....	57, 62, 63
Temperature Compensation .....	33
Terms and Definitions .....	68
Test .....	9
Test Points .....	10, 49
Timers .....	
Absorption .....	29
Equalize .....	33
Float .....	31
Transfer Relay .....	23, 25
Troubleshooting .....	49
Disconnect Messages .....	58
Error Messages .....	55
Sell Status Messages .....	59
Warning Messages .....	56

## U

Updating Firmware .....	12, 65
UPS .....	17
Utility Grid .....	68



***V***

Vent Fan Control..... 42

***W***

Warning Symbol..... 5

Warnings .....56

Website ..... 12, 65

**This page intentionally left blank.**

**This page intentionally left blank.**



**Masters of the Off-Grid.™ First Choice for the New Grid.**

Corporate Headquarters  
17825 – 59<sup>th</sup> Avenue N.E.  
Suite B  
Arlington, WA 98223 USA  
+1.360.435.6030

European Office  
Hansastraße 8  
D-91126  
Schwabach, Germany  
+49.9122.79889.0