

ProStar MPPT™

Solar Charging System Controller

Installation and Operation Manual



MORNINGSTAR

World's Leading **Solar Controllers & Inverters**

www.morningstarcorp.com



MODELS:


PS-MPPT-25

PS-MPPT-25M

PS-MPPT-40

PS-MPPT-40M

DIMENSIONS [inches (centimeters)]



SPECIFICATION SUMMARY

| | PS-MPPT-25 | PS-MPPT-40 |
|-------------------------------|------------|-------------|
| Nominal Battery Voltage | 12/24V | 12/24V |
| Max. PV Open-Circuit Voltage* | 120V | 120V |
| Maximum Operating Power** | 350 / 700W | 550 / 1100W |
| Max. Battery Charging Current | 25A | 40A |
| Rated Load Current | 25A | 30A |

*Array voltage should never exceed this limit

**These power levels refer to the maximum wattage the PS-MPPT can process. Higher power arrays can be used without damaging the controller.

TABLE OF CONTENTS

| | | |
|------------|--|-----------|
| 1.0 | Important Safety Instructions..... | 1 |
| 2.0 | General Information.... | 8 |
| 2.1 | Overview..... | 8 |
| 2.2 | Regulatory Information..... | 9 |
| 2.3 | Versions and Ratings..... | 11 |
| 2.4 | Features..... | 12 |
| 2.5 | Optional Accessories..... | 14 |
| 3.0 | Installation..... | 16 |
| 3.1 | General Installation Notes..... | 16 |
| 3.2 | Configuration..... | 17 |
| 3.3 | Mounting..... | 20 |
| 3.4 | Wiring..... | 21 |
| 4.0 | Operation..... | 31 |
| 4.1 | TrakStar MPPT Technology..... | 31 |
| 4.2 | Battery Charging Information..... | 33 |
| 4.3 | Load Control Information..... | 43 |
| 4.4 | LED Indications..... | 45 |
| 4.4.1 | Power-up..... | 45 |
| 4.4.2 | Status LED..... | 45 |
| 4.4.3 | State-of-charge LEDs..... | 46 |
| 4.5 | Push-button Use in Non-Metered Version..... | 46 |
| 4.6 | Alarms..... | 47 |
| 4.7 | Custom Settings..... | 49 |
| 4.7.1 | Programming with Meter Display..... | 49 |
| 4.7.2 | Programming in MSView..... | 50 |
| 4.7.3 | Meter Display Operation..... | 50 |
| 4.7.3.1 | Directional Key Use and Operation / Navigating the Meter Map..... | 50 |
| 4.7.3.2 | Adjusting the Meter Display..... | 50 |

- 4.7.4 Using the Meter Display to Program Charging Set-points, Load Control, Communications, and Advanced Settings.....51
- 4.7.5 Lighting Control / Programming Overview..... 51
- 4.7.6 Lighting Programming Using Meter Display..... 51
- 4.8 Inspection and Maintenance..... 53
- 5.0 Troubleshooting.....55**
- 5.1 LED Fault Indications..... 55
- 5.2 Battery Charging and Performance Issues..... 60
- 6.0 Warranty and Policies..... 61**
- 7.0 Technical Specifications.....65**
- Appendix A - Efficiency..... 68**
- Appendix B - De-rating Graphs.....70**
- Appendix C - Wire Sizing Charts..... 71**
- Certifications..... 77**

SAVE THESE INSTRUCTIONS.

This manual contains important safety, installation and operating instructions for the ProStar MPPT solar controller.

The following symbols are used throughout this manual to indicate potentially dangerous conditions or mark important safety instructions:



WARNING: Indicates a potentially dangerous condition. Use extreme caution when performing this task.



CAUTION: Indicates a critical procedure for safe and proper operation of the controller.



NOTE: Indicates a procedure or function that is important to the safe and proper operation of the controller.

CONSIGNES IMPORTANTES DE SÉCURITÉ CONSERVEZ CES INSTRUCTIONS:

Ce manuel contient des instructions importantes de sécurité, d'installations et d'utilisation du contrôleur solaire ProStar MPPT.

Les symboles suivants sont utilisés dans ce manuel pour indiquer des conditions potentiellement dangereuses ou des consignes importantes de sécurité.



AVERTISSEMENT: Indique une condition potentiellement dangereuse. Faites preuve d'une prudence extrême lors de la réalisation de cette tâche.



PRUDENCE: Indique une procédure critique pour l'utilisation sûre et correcte du contrôleur.



REMARQUE: Indique une procédure ou fonction importante pour l'utilisation sûre et correcte du contrôleur.

Safety Information

- Read all of the instructions and cautions in the manual before beginning installation.
- There are no user serviceable parts inside the ProStar MPPT. Do not disassemble or attempt to repair the controller.
- **CAUTION:** RISK OF ELECTRIC SHOCK. NO POWER OR ACCESSORY TERMINALS ARE ELECTRICALLY ISOLATED FROM DC INPUT, AND MAY BE ENERGIZED WITH HAZARDOUS SOLAR VOLTAGE. TEST BETWEEN TERMINALS AND GROUND BEFORE TOUCHING.
- External solar and battery disconnects are required.
- Disconnect all sources of power to the controller before installing or adjusting the ProStar MPPT.
- There are no fuses or disconnects inside the ProStar MPPT. Do not attempt to repair.

Informations de Sécurité

- Lisez toutes les instructions et les avertissements figurant dans le manuel avant de commencer l'installation.
- Le ProStar MPPT ne contient aucune pièce réparable par l'utilisateur. Ne démontez pas ni ne tentez de réparer le contrôleur.
- **PRUDENCE:** RISQUE DE CHOC ÉLECTRIQUE. NON ALIMENTATION OU AUX BORNES D'ACCESSOIRES SONT ISOLÉS ÉLECTRIQUEMENT DEPUIS LE COURANT CONTINU D'ENTRÉE ET DOIT ÊTRE ALIMENTÉ À DANGEREUX TENSION SOLAIRE. ENTRE BORNES ET LA MASSE D'ESSAI AVANT DE TOUCHER.
- External solaire et la batterie se déconnecte sont nécessaires.
- Déconnectez toutes les sources d'alimentation du contrôleur avant d'installer ou de régler le ProStar MPPT.
- Le TriStar MPPT ne contient aucun fusible ou interrupteur. Ne tentez pas de réparer.


- Installez des fusibles/coupe-circuits externes selon le besoin.

Installation Safety Precautions



WARNING: *This unit is not provided with a GFDI device. This charge controller must be used with an external GFDI device as required by the Article 690 of the National Electrical Code for the installation location.*

- Mount the ProStar MPPT indoors. Prevent exposure to the elements and do not allow water to enter the controller.
- Install the ProStar MPPT in a location that prevents casual contact. The ProStar MPPT heatsink can become very hot during operation.
- Use insulated tools when working with batteries.
- Avoid wearing jewelry during installation.
- The battery bank must be comprised of batteries of same type, make, and age.
- UL/IEC 62109 certified for use in negative ground or floating systems only
- Do not smoke near the battery bank.
- Power connections must remain tight to avoid excessive heating from a loose connection.
- Use properly sized conductors and circuit interrupters.
- The grounding terminal is located in the wiring compartment and is identified by the symbol below.



Ground Symbol

- This charge controller is to be connected to DC circuits only. These DC connections are identified by the symbol below:



Direct Current Symbol

The ProStar MPPT controller must be installed by a qualified technician in accordance with the electrical regulations of the country where the product is installed. A means of disconnecting all power supply poles must be provided. These disconnects must be incorporated in the fixed wiring. A permanent, reliable earth ground must be established with connection to the ProStar MPPT wiring compartment ground terminal.

The grounding conductor must be secured against any accidental detachment. The knock-outs in the ProStar MPPT wiring compartment must protect wires with conduit or rubber rings.

Précautions de Sécurité D'installation

.....




AVERTISSEMENT: *L'appareil n'est pas fourni avec un dispositif GFDI. Ce contrôleur de charge doit être utilisé avec un dispositif GFDI externe tel que requis par l'Article 690 du Code électrique national de l'emplacement de l'installation.*

- ontez le ProStar MPPT à l'intérieur. Empêchez l'exposition aux éléments et la pénétration d'eau dans le contrôleur.
- Installez le MPPT ProStar dans un endroit qui empêche le contact occasionnel. Le dissipateur de chaleur ProStar MPPT peut devenir très chaud pendant le fonctionnement.
- Utilisez des outils isolés pour travailler avec les batteries.
- Évitez le port de bijoux pendant l'installation.
- Le groupe de batteries doit être constitué de batteries du même type, fabricant et âge.
- UL/IEC 62109 certifié pour utilisation au négatif à la

masse ou les systèmes flottants seulement.

- Ne fumez pas à proximité du groupe de batteries.
- Les connexions d'alimentation doivent rester serrées pour éviter une surchauffe excessive d'une connexion desserrée.
- Utilisez des conducteurs et des coupe-circuits de dimensions adaptées.
- La borne de mise à la terre se trouve dans le compartiment de câblage et est identifiée par le symbole ci-dessous estampillé dans le boîtier



- Ce contrôleur de charge ne doit être connecté qu'à des circuits en courant continu. Ces connexions CC sont identifiées par le symbole ci-dessous:



Le contrôleur ProStar MPPT doit être installé par un technicien qualifié conformément aux réglementations électriques du pays où est installé le produit.

Un moyen d'assurer la déconnexion de tous les pôles de l'alimentation doit être fourni. Cette déconnexion doit être incorporée dans le câblage fixe.

À l'aide de la borne de mise à la masse du ProStar MPPT (dans le compartiment de câblage), un moyen permanent et fiable de mise à la terre doit être fourni. La fixation de la mise à la terre doit être fixée contre tout desserrage accidentel. Les ouvertures d'entrée au compartiment de câblage du ProStar MPPT doivent être protégées avec conduit ou anneaux.

Battery Safety



WARNING: A battery can present a risk of electrical shock or burn from large amounts of short-circuit current, fire, or explosion from vented gases. Observe proper precautions.



CAUTION: When replacing batteries, use properly specified sizes, types, and ratings based on application and system design.



CAUTION: Proper disposal of batteries is required. Refer to local regulations or codes for requirements.



AVERTISSEMENT: Une batterie peut présenter a risque de choc électrique ou de brûlure de grandes quantités de court-circuit curlouer, incendie ou explosion de ventilé gaz.



PRUDENCE: Observer les précautions adéquates. Quand remplacer l'utilisation de piles correctement spécifié tailles, types, et cotes fondées sur l'application et conception des systèmes.



PRUDENCE: Élimination appropriée des batpiles est nécessaire. Se ré férer au local réglements ou codes pour exigentments.

- Be very careful when working with large lead-acid batteries. Wear eye protection and have fresh water available in case there is contact with the battery acid.
- Remove rings and jewelry when working with batteries.
- Use insulated tools and avoid placing metal objects in the work area.
- Carefully read the battery manuals before installing and connecting the controller.
- Be very careful not to short circuit the cables connected to the battery.
- Have someone nearby to assist in case of an accident.
- Explosive battery gasses can be present during charging. Be certain there is enough ventilation to release the gases.
- Never smoke in the battery area.

- If battery acid comes into contact with the skin, wash with soap and water. If the acid contacts the eye, flood with fresh water and get medical attention.
- Be sure the battery electrolyte level is correct before starting charging. Do not attempt to charge a frozen battery.
- Recycle the battery when it is replaced.
- Soyez très prudent quand vous travaillez avec des grandes batteries au plomb. Portez des lunettes de protection et ayez de l'eau fraîche à disposition en cas de contact avec l'électrolyte.
- Retirez les bagues et les bijoux pour travailler avec les batteries.
- Utilisez des outils isolés et évitez de placer des objets métalliques dans la zone de travail.
- Lisez avec attention les manuels des batteries avant d'installer et de connecter le contrôleur.
- Veillez à ne pas court-circuiter les câbles connectés à la batterie.
- Ayez une personne à proximité qui puisse aider en cas d'accident.
- Des gaz explosifs de batterie peuvent être présents pendant la charge. Assurez-vous qu'une ventilation suffisante évacue les gaz.
- Ne fumez jamais dans la zone des batteries
- En cas de contact de l'électrolyte avec la peau, lavez avec du savon et de l'eau. En cas de contact de l'électrolyte avec les yeux, rincez abondamment avec de l'eau fraîche et consultez un médecin.
- Assurez-vous que le niveau d'électrolyte de la batterie est correct avant de commencer la charge. Ne tentez pas de charger une batterie gelée.
- Recyclez la batterie quand elle est remplacée.

2.1 Overview

Thank you for choosing the ProStar MPPT charge controller with TrakStar™ MPPT Technology. The ProStar MPPT is an advanced maximum power point tracking solar battery charger. The controller features a smart tracking algorithm that finds and maintains operation at the power source's peak power point, maximizing energy harvest.

The ProStar MPPT battery charging process has been optimized for long battery life and improved system performance. Self-diagnostics and electronic error protections prevent damage when installation mistakes or system faults occur. The controller also features eight (8) adjustable settings switches, several communication ports, and terminals for remote battery temperature and voltage measurement.

Please take the time to read this operator's manual to become familiar the many benefits the ProStar MPPT can provide for your PV systems, for example:

- Rated for 12 or 24 volt systems, and 25 or 40 amps of charging current
- Fully protected with automatic and manual recovery
- Seven standard charging programs selectable with DIP switches
- Continuous self-testing with fault notification
- LED indications and push-button or meter key functions
- Terminals sized for 35mm² (2 AWG) wire
- Includes battery voltage sense terminals
- Digital meter display options
- Optional remote battery temperature sensor
- 5-year warranty (see Section 6.0)

2.2 Regulatory Information



NOTE: This section contains important information for safety and regulatory requirements.

FCC requirements:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and,
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Morningstar for compliance could void the user's authority to operate the equipment.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer, or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

2.3 Versions and Ratings

PS-MPPT-25

- Rated for maximum 25 amps continuous current (battery or load)
- Designed for 12 or 24 VDC systems

PS-MPPT-25M

- Includes metering display
- Rated for maximum 25 amps continuous current (battery or load)
- Designed for 12 or 24 VDC systems

PS-MPPT-40

- Rated for maximum 40 amps of continuous battery current and 30 amps of continuous load current
- Designed for 12 or 24 VDC systems

PS-MPPT-40M

- Includes metering display
- Rated for maximum 40 amps continuous battery current and 30 amps of continuous load current
- Designed for 12 or 24 VDC systems

2.4 Features

The features of the ProStar MPPT are shown in Figure 2-1 below. An explanation of each feature is provided.




Figure 2-1. PS-MPPT Features

1 - Charging Status / Error LED

Shows charging current and error condition statuses.

2 - Heatsink

Aluminum heatsink (underneath) to dissipate controller heat (the ProStar MPPT is 100% passively cooled for reliability)

3 - Meter Display

Digital LCD monitoring and programming display

4 - Battery Status / Fault LED Indicators

Three state of charge (SOC) LED indicators show charging status and controller faults

5 - Solar Positive and Negative Terminals

Power connections for Solar (+) and (-) cable terminations

6 - Load Positive and Negative Terminals

Power connections for Load (+) and (-) cable terminations

7 - Battery Positive and Negative Terminals

Power connections for Battery (+) and (-) cable terminations

8 - Local Temperature Sensor

Compensates charging based on ambient temperature (not used if Remote Temperature Sensor is connected)

9 - Meter Directional Buttons

Used to navigate throughout meter map

10 - DIP Switches

Eight (8) settings switches to configure operation of the ProStar MPPT

11 - MeterBus™ Port

RJ-11 socket for Morningstar MeterBus™ network connections

12 - Grounding Terminal

A chassis ground terminal for system grounding

13 - Battery Sense Terminals

Connection points for battery voltage sensing wires

14 - Remote Temperature Sensor Terminals (RTS)

Connection points for a Morningstar RTS to remotely monitor battery temperature

15 - Wire Box for ProStar-MPPT

Optional accessory to route wiring through knock-outs

16 - Wire Box for ProStar-MPPT Knock-outs

Knock-outs for routing wires to conduit or wire gland terminations

2.5 Optional Accessories

The following accessories are available for purchase separately from your authorized Morningstar dealer:

Remote Temperature Sensor (Model: RTS)

The RTS measures battery temperature for accurate temperature compensation and is recommended when the ambient battery temperature differs from the ambient controller temperature by more than 5° C. The standard cable length is 33 ft (10m).



NOTE: *The use of a Remote Temperature Sensor is strongly recommended. Controller location, air flow, and system power can drastically affect the local temperature sensor reading. An RTS will provide optimal charging performance.*

RM-1 Meter

The digital Remote Meter displays system operating information, error indications, and self-diagnostic read-out. Information is displayed on a backlit 4-digit custom LCD display. The large numerical display and icons are easy to read and large buttons make navigating the meter menus easy. Additionally, a status LED and three (3) battery SOC LEDs provide system status at a glance.

The meter can be flush mounted in a wall or surface mounted using the mounting frame (included). The RM-1 is supplied with 33 ft (10.0 m) of cable, a mounting frame, and mounting screws. The RM-1 connects to the RJ- 11 Meter port on the ProStar MPPT.

RelayDriver (RD-1)

The Relay Driver™ accessory enables the ProStar MPPT to control external devices. Four (4) relay control ports can be configured (in various combinations) to perform the following tasks:

- generator control (2, 3, and 4-wire configurations)
- dry contacts for alarms and other signals

- advanced load control
- vent fan control
- DIN rail compatible or surface mount

Ground-fault Protection Device (GFPD-150V)

The GFPD-150V detects power source ground faults and interrupts current as required by the U.S. National Electrical Code.

Wire Box for ProStar MPPT

A modular wiring box that can be added to any version of ProStar MPPT controller. The box acts as a junction (using knock-outs) to run controller wiring to external conduit, if desired. The communications accessories / adaptors below should be housed in the Wire Box for ProStar MPPT.

Communications Support:

Ethernet Communications Adapter (EMC-1)

This product is an Ethernet gateway that provides web monitoring services, a Modbus TCP/IP server, and a local web page server. End users can collect information about their off-grid PV system remotely. One EMC-1 supports all products with MeterBus ports by bridging MODBUS TCP/IP requests to serve LiveView pages for each product.

USB Communications Adapter (UMC-1)

A modular unit that uses a USB-B plug, usually from a USB A-B computer cable, and an RJ-11 plug to connect with a Morningstar controller's MeterBus port, for monitoring and programming using MSView PC software.

PC MeterBus Adapter™ (Model: MSC)

The MSC converts the MeterBus RJ-11 electrical interface to an isolated standard RS-232 interface which enables communication between the ProStar MPPT and a personal computer (PC). The MSC is required for programming custom charging set-points, and for logging data. See Section 4.7 for information on programming.

3.0 INSTALLATION INSTRUCTIONS

3.1 General Installation Notes

- Read through the entire installation section first before beginning installation.
- Be very careful when working with batteries. Wear eye protection. Have fresh water available to wash and clean any contact with battery acid.
- Use insulated tools and avoid placing metal objects near the batteries.
- Explosive battery gases may be present during charging. Be certain there is sufficient ventilation to release the gases.
- Do not install in locations where water can enter the controller.
- Loose power connections and/or corroded wires may result in resistive connections that melt wire insulation, burn surrounding materials, or even cause fire. Ensure tight connections and use cable clamps to secure cables and prevent them from swaying in mobile applications.
- Preset charging profiles are generally designed for lead acid batteries. Custom settings can be used for varied charging requirements (see sections 3.2 and 4.5 for details). Note that some battery types may not be compatible.
- The ProStar MPPT battery connection may be wired to one battery, or a bank of batteries. The following instructions refer to a singular battery, but it is implied that the battery connection can be made to either one battery or a group of batteries in a battery bank.
- The ProStar MPPT uses stainless steel fasteners, an anodized aluminum heat sink, and conformal coating to protect it from harsh conditions. However, for acceptable service life, extreme temperatures and marine environments should be avoided.

- The ProStar MPPT prevents reverse current leakage at night, so a blocking diode is not required in the system.
- The ProStar MPPT is designed to regulate ONLY solar (photovoltaic) power. Connection to any other type of power source e.g. wind turbine or generator may void the warranty. However, other power sources can be connected directly to the battery.
- The connector terminals will accept a maximum wire size of AWG #6 / 16 mm² (solid/multistrand) or AWG #8 / 10 mm² (fine strand). Use a flathead insulated screwdriver, and torque tightly up to 35 in-lb.
- Solar and battery fuses or DC breakers are required in the system. These protection devices are external to the ProStar MPPT controller, and must be a maximum of 42.5 amps for the PS-MPPT-25/M and 60 amps for the PS-MPPT-40/M.
- Maximum battery short-circuit current rating must be less than the interrupt current rating of the battery over-current protection device referenced above.

3.2 Configuration

The DIP switch block shown in Figure 3.1 below is used to set the operating parameters for the ProStar MPPT.




Figure 3.1. DIP Switch Block to set charging parameters

Switch 1: Load / Lighting

| Mode | Switch 1 |
|----------|----------|
| Normal | OFF |
| Lighting | ON |

Switches 2, 3: System Voltage

Three (3) system voltage configurations are available as shown in the table below:

| System Voltage | Switch 2 | Switch 3 |
|----------------|----------|----------|
| Auto | OFF | OFF |
| 12 | OFF | ON |
| 24 | ON | OFF |

NOTE: Before connecting the battery, measure the open-circuit voltage. It must be over 10 volts to start the controller. If the system voltage Settings Switches are set to Auto-detect, battery voltage over 15.5V will be detected as a 24V nominal battery, and the unit will charge accordingly. The 12/24V auto selection is only done at start-up, and the detected system voltage will never change during operation.

Generally, the specific system voltage is known, and it is best to set DIPs 2,3 accordingly; the auto-detect setting should be used only in rare circumstances

Switches 4, 5, 6: Battery Type Selection

Preset ProStar MPPT battery charging options are shown in table 3-1 below. All voltage settings listed are for nominal 12 volt batteries. Multiply the voltage settings by two (2) for 24 volt systems.



NOTE: These settings are general guidelines for use at the operator’s discretion. The ProStar MPPT can be programmed to satisfy a wide range of charging parameters, but only the battery manufacturer can recommend optimal settings for their products.

| DIP Switch Settings 4-5-6 | Battery Type | Absorp. Stage (volts) | Float Stage (volts) | Equalize Stage (volts) | Absorp. Time (mins) | Equalize Time (mins) | Equalize Timeout (mins) | Equalize Interval (days) |
|---------------------------|-----------------|-----------------------|---------------------|------------------------|---------------------|----------------------|-------------------------|--------------------------|
| off-off-off | 1 - Sealed* | 14.00 | 13.70 | | 150 | | | |
| off-off-on | 2 - Sealed* | 14.15 | 13.70 | 14.40 | 150 | 60 | 120 | 28 |
| off-on-off | 3 - Sealed* | 14.30 | 13.70 | 14.65 | 150 | 60 | 120 | 28 |
| off-on-on | 4 - AGM/Flooded | 14.40 | 13.70 | 15.10 | 180 | 120 | 180 | 28 |
| on-off-off | 5 - Flooded | 14.60 | 13.50 | 15.30 | 180 | 120 | 180 | 28 |
| on-off-on | 6 - Flooded | 14.70 | 13.50 | 15.40 | 180 | 180 | 240 | 28 |
| on-on-off | 7 - L-16 | 15.40 | 13.40 | 16.00 | 180 | 180 | 240 | 14 |
| on-on-on | 8 - Custom | Custom | Custom | Custom | Custom | Custom | Custom | Custom |

* "Sealed" battery type includes gel and AGM batteries

Table 3.1. Battery charging settings for each selectable battery type

Switch 7: Battery Equalization

| Mode | Switch 7 |
|---------------------|----------|
| Manual Equalization | OFF |
| Auto Equalization | ON |

Switch 8: Meterbus / MODBUS Settings

| Mode | Switch 8 |
|----------|----------|
| Meterbus | OFF |
| MODBUS | ON |

3.3 Mounting

Inspect the controller for shipping damage. Mount the ProStar MPPT to a vertical surface (4-#8 stainless steel self-tapping screws are included). Tighten the mounting screws using care not to crack the plastic case. Do not install directly over an easily combustible surface since the heat sink may get hot under certain operating conditions.



NOTE: The heat sink must be in a vertical position (fins up and down).

For proper air flow, allow at least 15 cm (6 in) of space above and below the controller, and 50 mm (2 in) at the sides - see Figure 3-2 below. Install in an area protected from direct rain and sun.

If the controller is installed in an enclosure, some ventilation is recommended. Do not locate in an enclosure where battery gases can accumulate.




Figure 3-2. Proper Clearances for Passive Cooling

3.4 Wiring




Figure 3-3. Wiring the PS-MPPT

REFER TO FIGURE 3.3 IN THE FOLLOWING WIRING INSTRUCTIONS



NOTE: WIRING STRAIN RELIEF MUST BE PROVIDED if the THE OPTIONAL WIRE BOX FOR PROSTAR MPPT is not used.

STEP 1: Check Controller Limitations

Verify that the highest temperature compensated solar array open-circuit voltage (Voc), and load current do not exceed the ratings of the ProStar MPPT version being installed.

Multiple controllers can be installed in parallel on the same battery bank to achieve greater total charging current. In this type of system, each ProStar MPPT must have its own solar array. The load terminals of multiple controllers can only be wired together if the total load draw does not exceed the nameplate current of the LOWEST rated controller.

STEP 2: Battery Voltage Sense Wires

Due to connection and cable resistance, voltage drops are unavoidable in power cables that carry current, including the ProStar MPPT battery cables. If *Battery Sense* wires are not used, the controller must use the voltage reading at the battery power terminals for regulation. This voltage may differ from the actual battery bank voltage due to voltage drop.

Battery Voltage Sense is a high impedance connection that enables the ProStar MPPT to measure the battery terminal voltage precisely with small gauge wires that have no voltage drop. When connected directly to the battery, the sense wires will improve battery charging accuracy. Battery voltage sense wires are recommended if the controller is more than three meters (10 ft) from the battery.

Generally accepted wiring practice is to limit voltage drops between the charger and the battery to 2%. Even properly sized wiring with 2% drop can result in a 0.3 volt drop for 14.4V charging. Voltage drops will cause some undercharging of the battery. The controller will begin Absorption or limit equalization at a lower battery voltage because the controller measures a higher voltage at the controller's terminals than is the actual battery voltage. For example, if the controller is programmed to start Absorption at 14.4V, when the controller "sees" 14.4 volts at its battery terminals,

the true battery voltage would only be 14.1 volts, if there is a 0.3 volt drop between the controller and battery.

Note that the battery sense wires will not power the controller, and the sense wires will not compensate for losses in the power wires between the controller and the battery. The battery sense wires are used to improve the accuracy of the battery charging.

The two sense wires, can range in size from 1.0 to 0.25 mm² (16 to 24 AWG), and should be cut to length as required to connect the battery to the voltage sense terminals. A 2-position terminal (see figure 3.3) is used for the battery sense connection. A twisted pair cable is recommended but not required. Use UL rated 300 Volt conductors. The voltage sense wires may be pulled through conduit with the power conductors.

Observing correct polarity, connect both battery voltage sense wires to the ProStar MPPT at the 2-position *Battery Sense* terminal, and to battery (+) and (-) terminals. No damage will occur if the polarity is reversed, but the controller cannot read a reversed sense voltage.

Tighten the connector screws to 5 in-lb (0.56 Nm) of torque.

The maximum length allowed for each battery voltage sense wire is 98 ft (30 m).

Connecting the voltage sense wires to the RTS terminal will cause an alarm.

 **NOTE:** If the battery input voltage is greater than 5 volts different than the *Battery Sense*, due to voltage drops or faulty connections, the *Battery Sense* input will not be recognized by the ProStar MPPT.

A battery voltage sense connection is not required to operate the ProStar MPPT controller, but it is recommended for best performance.

STEP 3: Remote Temperature Sensor



CAUTION: *Risk of Fire.*

If no Remote Temperature Sensor (RTS) is connected, use the ProStar MPPT within 3m (10 ft) of the batteries. Internal Temperature Compensation will be used if the RTS is not connected. Use of the RTS is strongly recommended.



PRUDENCE: *Risque d'incendie.*

Si non Capteur de température distant (RTS) est connecté, utilisez le MPPT ProStar moins de 3m (10 pi) de les batteries. Compensation de la température interne sera utilisée si la RTS n'est pas connecté. Utilisation de la RTS est fortement recommandé.

All charging settings are based on 25°C (77°F). If the battery temperature varies by 5°C, the charging setting will change by 0.15 Volts for a 12 Volt battery. This is a substantial change in the charging of the battery, and the use of the optional Remote Temperature Sensor (RTS) is recommended to adjust charging to the actual battery temperature. The RTS can be added at any time after the system has been installed.

Connect the RTS to the 2-position terminal located between the battery (-) and chassis ground terminal lugs (see figure). The RTS is supplied with 33 ft (10 m) of 22 AWG (0.34 mm²) cable. There is no polarity, so either wire (+ or -) can be connected to either screw terminal. The RTS cable may be pulled through conduit along with the power wires. Tighten the connector screws to 5 in-lb (0.56 Nm) of torque. Separate installation instructions are provided inside the RTS bag.



CAUTION: *The ProStar MPPT will use the local temperature sensor for compensation if the RTS is not used.*



CAUTION: *Equipment Damage*

Never place the temperature sensor inside a battery cell. Both the RTS and the battery will be damaged.



NOTE: The RTS cable may be shortened if the full length is not needed. Be sure to reinstall the ferrite choke on the end of the RTS if a length of cable is removed. This choke ensures compliance with electromagnetic emissions standards.



PRUDENCE: Le TriStar MPPT ne compense pas la température des paramètres de charges si le RTS n'est pas utilisé.



PRUDENCE: Endommagement de l'équipement
Ne placez jamais la sonde de température dans un élément de batterie. Le RTS et la batterie seraient endommagés.



REMARQUE: Le câble de RTS peut être raccourci si la totalité de la longueur n'est pas nécessaire. Assurez-vous de réinstaller la bobine en ferrite sur l'extrémité du RTS si une longueur de câble est enlevée. Cette bobine assure la conformité avec les normes d'émissions électromagnétiques.

STEP 4: Grounding and Ground Fault Interruption



WARNING:

This unit is not provided with a GFDI device. This charge controller must be used with an external GFDI device as required by the Article 690 of the National Electrical Code for the installation location.



NOTE:

Conductors identified by the color combination green/yellow shall only be used for earthing conductors.



AVERTISSEMENT :

L'appareil n'est pas fourni avec un dispositif GFDI. Ce contrôleur de charge doit être utilisé avec un dispositif GFDI externe tel que requis par l'Article 690 du Code électrique national de la région de l'installation.

Use a copper wire to connect the grounding terminal in the wiring box to earth ground. The grounding terminal is identified by the ground symbol shown below that is stamped into the wiring box just below the terminal:




Figure 3-4. Ground Symbol

Do not connect the system negative conductor to this terminal. NEC requires the use of an external ground fault protection device (GFPD). The ProStar MPPT does not have internal ground fault protection. The system electrical negative should be bonded through a GFPD to earth ground at one (and only one) location. The grounding point may be located in the solar circuit or the battery circuit.

Per NEC 690.45 (A) and NEC Table 250.122, minimum sizes for copper grounding wire are:

- ProStar MPPT-25 10 AWG (5 mm²)
- ProStar MPPT-40 10 AWG (5 mm²)




WARNING: Risk of Fire

DO NOT bond system electrical negative to earth ground at the controller. Per NEC requirements, system negative must be bonded to earth ground through a GFPD at only one point.




AVERTISSEMENT : Risque d'incendie

NE LIEZ PAS le côté négatif du système à la mise à la terre au niveau du contrôleur. Selon les exigences du CNE, le côté négatif du système doit être mis à la terre par un GFPD à un seul point.



STEP 5: Load Connections

Turn the loads off, and connect the load wires to the load terminals. **DO NOT INSERT THE FUSE AT THIS TIME.**




STEP 6: Battery Connections

Be sure that DIP switches 2 and 3 are set for 12 or 24V, as described in Section 3.2

NOTE: Before connecting the battery, measure the open-circuit voltage. It must be over 10 volts to start the controller. If the system voltage Settings Switches are set to Auto-detect, battery voltage over 15.5V will be detected as a 24V nominal battery, and the unit will charge accordingly. The 12/24V auto selection is only done at start-up.

With the battery disconnect open, connect the battery (+) and (-) wires from the battery to controller. **DO NOT CLOSE THE DISCONNECT AT THIS TIME.**



STEP 7: Solar Connections



WARNING: Shock Hazard

The solar PV array can produce open-circuit voltages in excess of 120 Vdc when in sunlight. Verify that the solar input breaker or disconnect has been opened (disconnected) before installing the system wires.



AVERTISSEMENT: *Risque de décharge électrique*
Le réseau PV solaire peut produire des tensions de circuit ouvert supérieures à 120 Vdc à la lumière du soleil. Vérifiez que le coupe-circuit ou l'interrupteur d'entrée solaire a été ouvert (déconnexion) avant d'installer les câbles du système.

With the solar disconnect open, connect the solar (PV) array wires to the PS-MPPT solar terminals. Use caution, since the solar array will produce current whenever in sunlight. A solar disconnect is a convenient way to break the PV connection when necessary.

STEP 8: Power-Up and Verify System Operation



NOTE: *Carefully observe the LEDs after each connection. The LEDs will indicate proper polarity and a good connection.*

Close the battery breaker to power on the controller. Watch the the charging status, and then the three battery state-of-charge (SOC) LEDs blink in sequence (G-Y-R), confirming proper start-up. If they do not light, check the battery polarity (+/-) and battery voltage.

Next, the green, yellow or red LED will light depending on the battery state-of-charge (SOC). Confirm that one of these LEDs is on before going to the next step.

Close solar disconnect. If the solar input is connected while in sunlight, the charging LED indicator will light. Confirm proper connection by observing the charging LED.

Insert the load fuse, and turn the load on to confirm a proper connection.

If the load does not turn on, it could be for various reasons:

- the ProStar MPPT is in LVD (red LED on)
- there is a short circuit in the load (LEDs blinking R/G – Y)
- there is an overload condition (LEDs blinking R/Y - G)
- the load is not connected, not working, or turned off

After all connections have been completed, observe the LEDs to make sure the controller is operating normally for system conditions. If the optional digital meter is used, observe that the display is scrolling with proper voltage and current values. Also, a self- test can be performed with digital meter units.

4.1 TrakStar MPPT Technology

The ProStar MPPT utilizes Morningstar's TrakStar Maximum Power Point Tracking technology to extract maximum power from the solar module(s). The tracking algorithm is fully automatic and does not require user adjustment. Trakstar technology will track the array maximum power point voltage (V_{mp}) as it varies with weather conditions, ensuring that maximum power is harvested from the array through the course of the day.

Current Boost:

In many cases, TrakStar MPPT technology will "boost" the solar charge current. For example, a system may have 2 amps of solar current flowing into the ProStar MPPT and 5 amps of charge current flowing out to the battery. The ProStar MPPT does not create current! Rest assured that the power into the ProStar MPPT is the same as the power out of the ProStar MPPT. Since power is the product of voltage and current (Volts x Amps), the following is true*:

- (1) Power Into the ProStar MPPT = Power Out of the ProStar MPPT
- (2) Volts In x Amps In = Volts Out x Amps Out

* assuming 100% efficiency i.e. if no losses in wiring and conversion existed.

If the solar module's V_{mp} is greater than the battery voltage, it follows that the battery current must be proportionally greater than the solar input current so that input and output power are balanced. The greater the difference between the maximum power voltage and battery voltage, the greater the current boost. Current boost can be substantial in systems where the solar array is of a higher nominal voltage than the battery as described in the next section.

High Voltage Strings and Grid-tied Modules

Another benefit of TrakStar MPPT technology is the ability to charge 12 or 24 volt batteries with solar arrays of higher nominal voltages. A 12 volt battery bank can be charged with a 12, 24, 36 or 48V nominal off-grid solar array. Certain grid-tie solar modules may also be used as long as the solar array open circuit voltage (V_{oc}) rating will not exceed the ProStar MPPT 120V maximum input voltage rating at worst-case (lowest) module temperature. The solar module documentation should provide V_{oc} vs. temperature data. Higher solar input voltage results in lower solar input current for a given input power. High voltage solar input strings allow for smaller gauge solar wiring. This is especially helpful for systems with long wiring runs between the solar array and the ProStar MPPT.

An Advantage Over Traditional Controllers

Traditional controllers connect the solar module directly to the battery when recharging. This requires that the solar module operate in a voltage range that is below the module's V_{mp} . In a 12V system, for example, the battery voltage may range from 10 - 15 Vdc but the module's V_{mp} is typically around 17V. Figure 4.1 shows a typical current vs. voltage output curve for a nominal 12V off-grid module.




Figure 4.1. Nominal 12 volt solar module I-V curve and output power graph

4.2 Battery Charging Information

4-Stage Charging

The ProStar MPPT has a 4-stage battery charging algorithm for rapid, efficient, and safe battery charging. Figure 4-2 shows the sequence of stages.




Figure 4.2. ProStar MPPT Charging Algorithm

Bulk Charge Stage

During Bulk charging, the battery is not at 100% state of charge and battery voltage has not yet charged to the Absorption voltage set-point. The controller will deliver 100% of available solar power to recharge the battery.

Absorption Stage

When the battery has recharged to the Absorption voltage set-point, constant-voltage regulation is used to maintain battery voltage at the Absorption set-point. This prevents heating and excessive battery gassing. The battery is allowed to come to full state of charge at the Absorption voltage set-point. The green SOC LED will blink once per second during Absorption charging.

4.0

The battery must remain in the Absorption charging stage for a cumulative 120 - 150 minutes, depending on battery type, before transition to the Float stage will occur. However, Absorption time will be extended by 30 minutes if the battery discharges below 50 Volts the previous night.

The Absorption set-point is temperature compensated if the RTS is connected.

Float Stage

After the battery is fully charged in the Absorption stage, the ProStar MPPT reduces the battery voltage to the Float voltage set-point. When the battery is fully recharged, there can be no more chemical reactions and all the charging current is turned into heat and gasing. The float stage provides a very low rate of maintenance charging while reducing the heating and gasing of a fully charged battery. The purpose of float is to protect the battery from long-term overcharge. The green SOC LED will blink once every two (2) seconds during Float charging.

Once in Float stage, loads can continue to draw power from the battery. In the event that the system load(s) exceed the solar charge current, the controller will no longer be able to maintain the battery at the Float set-point. Should the battery voltage remain below the Float set-point for a cumulative 60 minute period, the controller will exit Float stage and return to Bulk charging.

The Float set-point is temperature compensated if the RTS is connected.

Equalization Stage



WARNING: Risk of Explosion

Equalizing vented batteries produces explosive gases. The battery bank must be properly ventilated.



CAUTION: Equipment Damage

Equalization increases the battery voltage to levels that may damage sensitive DC loads. Verify all system loads are rated for the temperature compensated Equalize voltage before beginning an Equalization charge.



CAUTION: Equipment Damage

Excessive overcharging and gassing too vigorously can damage the battery plates and cause shedding of active material from the plates. An equalization that is too high or for too long can be damaging. Review the requirements for the particular battery being used in your system.



AVERTISSEMENT : Risque d'explosion

Les batteries à évent et compensation produisent des gaz explosifs. Le groupe de batteries doit être correctement ventilé.



PRUDENCE : Endommagement de l'équipement

La compensation augmente la tension des batteries à des niveaux pouvant endommager les charges sensibles en CC. Vérifiez que toutes les charges du système sont conçues pour la tension de compensation par température avant de commencer une charge de compensation.



PRUDENCE : Endommagement de l'équipement

Une surcharge excessive et un dégagement gazeux trop vigoureux peuvent endommager les plaques de batteries et provoquer l'élimination du matériau actif des plaques. Une compensation trop élevée ou trop longue peut provoquer des dégâts. Examinez les exigences pour la batterie particulière utilisée dans votre système.

Certain battery types benefit from a periodic boost charge to stir the electrolyte, level the cell voltages, and complete the chemical reactions. Equalization charging raises the battery voltage above the standard absorption voltage so that the electrolyte gases. The green SOC LED will blink rapidly two (2) times per second during equalization

charging. The duration of the equalize charge is determined by the selected battery type. See table 4-1 in this section for more details. The *Equalization Time* is defined as time spent at the equalization set-point. If there is insufficient charge current to reach the equalization voltage, the equalization will terminate after an additional 60 minutes to avoid overgassing or heating the battery. If the battery requires more time in equalization, an equalize can be requested using the TriStar Meter or push-button to continue for one or more additional equalization cycles.

The Equalization set-point is temperature compensated if the RTS is connected.

Why Equalize?

Routine equalization cycles are often vital to the performance and life of a battery - particularly in a solar system. During battery discharge, sulfuric acid is consumed and soft lead sulfate crystals form on the plates. If the battery remains in a partially discharged condition, the soft crystals will turn into hard crystals over time. This process, called "lead sulfation", causes the crystals to become harder over time and more difficult to convert back to soft active materials. Sulfation from chronic undercharging of the battery is the leading cause of battery failures in solar systems. In addition to reducing the battery capacity, sulfate build-up is the most common cause of buckling plates and cracked grids. Deep cycle batteries are particularly susceptible to lead sulfation.

Normal charging of the battery can convert the sulfate back to the soft active material if the battery is fully recharged. However, a solar battery is seldom completely recharged, so the soft lead sulfate crystals harden over a period of time. Only a long controlled overcharge, or equalization, at a higher voltage can reverse the hardening of sulfate crystals.

When to Equalize?

The ideal frequency of equalizations depends on the battery type (lead-calcium, lead-antimony, etc.), the depth of discharging, battery age, temperature, and other factors. One very broad guide is to equalize flooded batteries every 1 to 3 months or every 5 to 10 deep discharges. Some batteries, such as the L-16 group, will need more frequent equalizations.

The difference between the highest cell and lowest cell in a battery can also indicate the need for an equalization. Either the specific gravity or the cell voltage can be measured. The battery manufacturer can recommend the specific gravity or voltage values for your particular battery.

Preparation for Equalization

First, confirm that all of the system loads are rated for the equalization voltage. Consider that at 0°C (32°F) the equalization voltage will reach 16.75 volts for L-16 batteries with a temperature sensor installed. Disconnect any loads at risk of damage due to the high input voltage.

If Hydrocaps are used, be sure to remove them before starting an equalization. Replace the Hydrocaps with standard battery cell caps. The Hydrocaps can get very hot during an equalization. Also, if Hydrocaps are used, the equalization should be set for manual only (DIP switch #7 is Off).

After the equalization is finished, add distilled water to each cell to replace gasing losses. Check that the battery plates are covered.

Equalize a Sealed Battery?

The *Battery Charging Settings* table (see table 4-1 in this section) shows two sealed battery settings with an Equalization cycles. These are minimal “boost” cycles to level individual cells. This is not an equalization, and will not vent gas from sealed batteries that require up to 14.4V charging (12V battery). Many VRLA batteries, including AGM and gel, have charging requirements up to 14.4V (12V battery). Depending on the battery manufacturer’s recommendation,

the “boost” cycle for sealed cells can be disabled by setting the equalize setting switch to manual, if required.

Battery Charge Settings

Preset ProStar MPPT battery charging options are shown in tables 4-1 and 4-2 below. All voltage settings listed are for nominal 12 Volt batteries. Multiply the voltage settings by two (2) for 24 Volt batteries.



NOTE: These settings are general guidelines for use at the operator’s discretion. The ProStar MPPT can be programmed to satisfy a wide range of charging parameters, but only the battery manufacturer can recommend optimal settings for their products.

| DIP Switch Settings 4-5-6 | Battery Type | Absorp. Stage (volts) | Float Stage (volts) | Equalize Stage (volts) | Absorp. Time (mins) | Equalize Time (mins) | Equalize Timeout (mins) | Equalize Interval (days) |
|---------------------------|-----------------|-----------------------|---------------------|------------------------|---------------------|----------------------|-------------------------|--------------------------|
| off-off-off | 1 - Sealed* | 14.00 | 13.70 | | 150 | | | |
| off-off-on | 2 - Sealed* | 14.15 | 13.70 | 14.40 | 150 | 60 | 120 | 28 |
| off-on-off | 3 - Sealed* | 14.30 | 13.70 | 14.65 | 150 | 60 | 120 | 28 |
| off-on-on | 4 - AGM/Flooded | 14.40 | 13.70 | 15.10 | 180 | 120 | 180 | 28 |
| on-off-off | 5 - Flooded | 14.60 | 13.50 | 15.30 | 180 | 120 | 180 | 28 |
| on-off-on | 6 - Flooded | 14.70 | 13.50 | 15.40 | 180 | 180 | 240 | 28 |
| on-on-off | 7 - L-16 | 15.40 | 13.40 | 16.00 | 180 | 180 | 240 | 14 |
| on-on-on | 8 - Custom | Custom | Custom | Custom | Custom | Custom | Custom | Custom |

* "Sealed battery types include gel and AGM batteries

Table 4.1. Battery charging settings for each selectable battery type

| Shared Settings | Value | Units |
|------------------------------|----------------------|---------|
| Absorption Extension Voltage | 12.50 | volts |
| Absorption Extension Time | Absorption Time + 30 | minutes |
| Float Exit Time-out | 30 | minutes |
| Float Cancel Voltage | 12.30 | volts |
| Equalize Time-out | Equalize Time + 60 | minutes |

| Shared Settings | Value | Units |
|--------------------------------------|-------|------------------------|
| Temperature Compensation Coefficient | - 5 | millivolts / °C / cell |

Table 4.2. Battery settings that are shared among all battery types

The ProStar MPPT provides seven (7) standard battery charging settings that are selected with the settings switches (see Table 4.1 above). These standard charging settings are suitable for lead-acid batteries ranging from sealed (gel, AGM, maintenance-free) to Flooded and L-16 cells. In addition, an eighth charging setting provides for custom set-points using MSView™ PC software. Table 4-1 above summarizes the major parameters of the standard charging settings. The shared settings in Table 4-2 are common to all battery types. The following charging profiles graphically explain the shared settings:

Absorption Extension




Figure 4-3. Absorption Extension Charging Profile

If battery voltage discharges below 12.50 Volts (25.00 Volts @ 24V) the previous night, Absorption charging will be extended on the next charge cycle as shown in figure 4-3 above. 30 minutes will be added to the normal Absorption duration.

Float Time-out




Figure 4-4. Float Exit Time-out Charging Profile

After entering Float stage, the controller will only exit Float if the battery voltage remains below Float voltage for 60 cumulative minutes. In figure 4-4, a system load turns on at 4:00 hrs when the controller is in Float stage, runs for one hour, and turns off at 5:00 hrs. The load current draw is larger than the charge current, causing battery voltage to drop below Float voltage for 60 minutes. After the load turns off, the controller returns to Bulk charging and then Absorption stage once again. In this example, a load runs continuously for 60 min. However, because the Float exit timer is cumulative, multiple momentary load events that pull the battery voltage below Float voltage for a combined 60 minutes duration will also force an exit from Float stage.

Float Cancel Voltage




Figure 4.5. Float Cancellation Charging Profile

If the battery bank discharges below 12.30 Volts (24.60 Volts @ 24 V, 49.20 Volts @ 48 V) the previous night, Float charging stage will be cancelled for the next charge cycle. Figure 4-5 above, illustrates this concept. At 0:00 hrs (dawn), battery voltage is below the Float Cancel threshold voltage. The diagram shows where Float stage would have occurred if Float was not canceled.

Equalize Time-out




Figure 4.6. Equalize Time-out Charging Profile

The charging profile in figure 4-6 above, shows an *Equalize Timeout* event. The timeout timer begins as soon as battery voltage exceeds the Absorption voltage setpoint. If there is insufficient charging current or system loads are too large, the battery voltage may not reach the Equalize setpoint. Equalize Time-out is a safety feature that prevents high battery voltage for extended periods of time which may damage the battery.

4.3 Load Control Information

The primary purpose of the load control function is to disconnect system loads when the battery has discharged to a low state of charge and reconnect system loads when the battery is sufficiently recharged. System loads may be lights, pumps, motors, DC appliances, and other electronic devices. The total current draw of all loads must not exceed the ProStar MPPT 25 or 30 amp maximum load rating.



CAUTION: Do not wire an AC inverter of any size to the load terminals of the ProStar MPPT - damage to the load control circuit may result. Wire inverters directly to the battery or battery bank.



PRUDENCE: Ne pas raccorder un inverseur de toute taille de la bornes de charge MPPT ProStar - endommagement de la charge contrôle est susceptible d'entraîner. Onduleurs de fil directement à la batterie ou groupe de batteries.

Current Compensation:

All LVD and LVR set-points are current compensated. Under load, the battery voltage will sag in proportion to the current draw of the load. A short-term large load could cause a premature LVD without the current compensation feature. LVD and LVR set-points are adjusted lower per the following table.

| System Voltage | Current Compensation |
|----------------|------------------------|
| 12 Volt | -20 mV per amp of load |
| 24 Volt | -40 mV per amp of load |

Table 4-3. Current Compensation Values

LVD Warning:

As the battery discharges the Battery Status LEDs will transition from green to yellow and then from yellow to flashing red. The flashing red indication is a warning that a low voltage disconnect event will occur soon.

The amount of time between a green SOC indication and load disconnect will depend on many factors including:

- rate of discharge (amount of load draw)
- capacity of the battery
- health of the battery
- LVD set-point

If the battery discharges to the LVD set-point the load will disconnect and a solid red Battery Status LED indication will be displayed.

General Load Control Notes:

Do not wire multiple ProStar MPPT load outputs together in parallel to power DC loads with a current draw greater than 25 or 30A, depending on the ProStar MPPT model. Equal current sharing cannot be assured and an over-load condition will likely occur on one or more controllers.

Exercise caution when connecting loads with specific polarity to a live load circuit. A reverse polarity connection may damage the load. Always double check load connections before applying power.

4.4 LED Indications

KEY:

G = green

Y = yellow

R = red

G - Y - R = flashing sequentially

G / Y = flashing together

G / Y - R = G and Y flashing together, alternating with R flash

4.4.1. Power-up

Normal power-up: Status LED flashes **G**, then SOC LEDs flash **G - Y - R**, then SOC LEDs indicate battery charge status with a single battery status LED.

Failed bootload: Status LED flashes **G**, then SOC LEDs flash **G - Y** and stop on solid **Y**.

4.4.2 Status LED

The Status LED indicates charging status and any existing solar input error conditions. The Status LED is on when charging during the day and off at night. The Status LED will flash red whenever an error condition(s) exists. Table 4.4 lists the Status LED indications.

| Color | Indication | Operating State |
|-------|---|-----------------|
| None | Off (with heart-beat ¹) | Night |
| Green | On Solid (with heart-beat ²) | Charging |
| Red | Flashing | Error |
| Red | On Solid (with heart-beat ²) | Critical Error |

¹ heartbeat indication flickers the Status LED on briefly every 5 seconds

² heartbeat indication flickers the Status LED off briefly every 5 seconds

Table 4.4. Status LED Definitions

NOTES:

- 1) R flashing is generally a user addressable fault / error
- 2) R charging status LED ON with heartbeat blink OFF every 5 secs is a critical fault that generally requires service. See, "Solid Charging Status LED with Self-test (R-Y-G) SOC Faults", in Section 5.1.

4.4.3 State-of-Charge LEDs

Battery SOC LED Indications are shown in Table 4-5 below:

| Condition | Indication |
|--------------------------------|------------------------|
| Absorption | G flash - every sec |
| Float | G flash - every 2 secs |
| Equalize | G flash - 2 / sec |
| SOC > 13.5V | G solid |
| 13.5V > SOC > 13.0V | G / Y solid |
| 13.0V > SOC > 12.5V | Y solid |
| SOC < 12.5V | Y / R solid |
| Low voltage disconnect warning | R flash - every sec |
| Low voltage disconnect | R solid |

Table 4.5. Battery SOC LED Indications

4.5 Push-Button Use in Non-Metered Version

The version of the ProStar MPPT without meter display features a push-button that operates as follows depending on the DIP Switch 1 setting:

Normal Mode (DIP 1 OFF)

- One quick press and release will clear any faults or reminders that are present
- Press and hold for 5 seconds to initiate an Equalization (EQ), if unit is set to manual EQ.

Lighting Control Mode (DIP 1 ON)

- A quick press and release will clear any faults or reminders that are present. A second quick press will then conduct a lighting test. If no faults or reminders are present, the initial press will conduct a lighting test. A lighting test is used to verify correct wiring in the load circuit and/or verify the lighting components are operational.
- If no faults or reminders are active, press and hold for 5 seconds to initiate an Equalization (EQ) if the unit is set to manual EQ.

Reset PS-MPPT to Factory Settings

To restore factory settings: Disconnect PV; disconnect battery power; press and hold down the push-button; re-start the PS-MPPT by connecting the battery; keep the push-button depressed for 10 secs.

A Custom Edit Settings fault will occur. See p. 57 in Section 5 for details. The unit will then need to be re-powered to resume normal operation.

4.6 Alarms

Solar Overload

No LED indication. The ProStar MPPT will limit battery current to the 25 or 40 amp maximum rating. An over-sized solar array will not operate at peak power. The solar array should be less than the ProStar MPPT nominal max. input power rating for optimal performance. See Section 7.0 - Technical Specifications for more information.

High Temperature Current Limit

The ProStar MPPT will limit the solar input current if the heatsink temperature exceeds safe limits. Solar charge current will be tapered back (to 0 amps if needed) to reduce the heatsink temperature. The ProStar MPPT is designed to operate at full rated current at the maximum ambient temperature. This alarm indicates that there is insufficient

airflow and that the heatsink temperature is approaching unsafe limits. If the controller frequently reports this alarm condition, corrective action must be taken to provide better air flow or to relocate the controller to a cooler spot.

High Input Voltage Current Limit

The ProStar MPPT will limit the solar input current as the solar array Voc approaches the maximum input voltage rating. The array Voc should never exceed the 120 volt maximum input voltage - see the array voltage de-rating graph in Appendix.

Current Limit

The array power exceeds the rating of the controller. This alarm indicates that the ProStar MPPT is limiting battery current to the maximum current rating.

RTS Open

The Remote Temperature Sensor is not connected to the controller. Use of the RTS is recommended for proper battery charging.

Heatsink Temperature Sensor Open / Shorted

The heatsink temperature sensor is damaged. Return the controller to an authorized Morningstar dealer for service.

Battery Sense Out of Range / Disconnected

A battery sense wire is disconnected. Inspect the battery sense connections. This alarm is set when the voltage at the battery sense voltage differs by more than 5 volts from the voltage at the battery terminals.

Uncalibrated

The controller was not factory calibrated. Return the controller to an authorized Morningstar dealer for service.

4.7 Custom Settings

4.7.1 Programming with the Meter Display

The ProStar MPPT is available in metered and non-metered versions. The metered model allows:

- Custom programming, including lighting programs, directly from the unit.
- Extensive settings adjustment and information as shown partially in Figure 4-7 below:

Models:
PS-MPPT-25M
PS-MPPT-40M

Display Screens and Programming




Figure 4-7. Simplified Meter Map. For metered models, see the included complete meter map insert, also available in the ProStar MPPT support documents at:

www.morningstarcorp.com

4.0

4.7.2 Programming in MSView

Beyond the preset DIP switch options, the Prostar MPPT's charging profile and all other settings are customizable using MSView PC software available at:

www.morningstarcorp.com

With a connection to a PC, and using the ProStar MPPT Set-up Wizard, the software is capable of editing all charging and lighting parameters for upload to the controller. The Set-up Wizard, and topics within the Help tab describe programming procedures in detail.

All aspects of connection, programming and communications are covered in the Product Connectivity Manual:

[www.morningstarcorp.com/resources/white papers and documents](http://www.morningstarcorp.com/resources/white%20papers%20and%20documents)

Communications accessories / adapters should be housed in the optional Wire Box for ProStar MPPT.

4.7.3 Meter Display Operation

4.7.3.1 Directional Key Use and Operation / Navigating the Meter Map

The ProStar MPPT's meter map consists of two main axes: The horizontal top level daily monitoring screens, and the vertical Main Menu stacked screens. The four lighted triangular directional control keys allow movement to reach any desired point on the meter map. A lit key indicates a valid direction in the map. The current location is indicated on the display with a column heading, and a bold descriptor.

4.7.3.2 Adjusting the Meter Display

The display setting options, as shown in Figure 4-4, are adjustable by using the directional keys to locate and edit a desired setting or variable.

4.7.4 Using the Meter Display to Program Charging Set-points, Load Control, Communications, and Advanced Settings

Refer to the complete meter map insert for metered PS-MPPTs. From a top level monitoring screens, scroll down to the Main Menu - "Custom Programming" - screen. Select the desired category, and edit the variable or settings as as instructed in the meter display.

The Load Control category includes Normal (load disconnect) and Lighting programming. The Advanced Settings category includes more optional charging, MPPT, and load control settings.

4.7.5 Lighting Control / Programming Overview

The ProStar MPPT display has extensive lighting load programmability. With DIP switch 1 ON (up), a dusk-dawn lighting program is enabled, if lighting timing hasn't been programmed in MSView or using the meter; with DIP 1, 4, 5, 6 ON, and the unit programmed, custom timing will be in effect. With DIP 1 OFF (down), all lighting control functions are disabled.

Using either MSView or the meter display, four channels are available for setting timers that can work separately, or in combination. See Section 4.6.6 - Lighting Programming Using Meter Display - for more details.

4.7.6 Lighting Programming Using the Meter Display

Lighting programming capabilities are accessible with the meter via Custom Programming->Load Control->Lighting. Lighting settings editing is done via on-screen instructions.

- The Summary provides a graphical representation of the complete lighting configuration
- LVD / LVR can be specified for use when a lighting program is in operation

- Sunrise and Sunset Threshold settings allow the adjustment of percentages of the maximum seen solar array voltage for triggering day and night events
- There are four channels, each having two timers, which can be used independently, or in combination.
- Events and actions are used as references and controls. An event is one of eight points in a day e.g. sunrise or midnight. Each event can be edited to specify a time offset to trigger an action, which can be, "Do Nothing", "Lights On", or "Lights Off"
- The combination setting of each channel will specify whether the actions and events of each timer will function: not at all (no combination); when both timers' settings match (AND); for either timers' settings (OR)

4.8 Inspection and Maintenance

Table 4-6 below lists the recommended maintenance schedule to keep your ProStar MPPT performing optimally.



WARNING: *Electric Shock Hazard*

NO POWER OR ACCESSORY TERMINALS ARE ELECTRICALLY ISOLATED FROM DC INPUT, AND MAY BE ENERGIZED WITH HAZARDOUS SOLAR VOLTAGE. TEST BETWEEN TERMINALS AND GROUND BEFORE TOUCHING.



AVERTISSEMENT: *Risque de décharge électrique*

NON ALIMENTATION OU AUX BORNES D'ACCESSOIRES SONT ISOLÉS ÉLECTRIQUEMENT DEPUIS LE COURANT CONTINU D'ENTRÉE ET DOIT ÊTRE ALIMENTÉ À DANGEREUX TENSION SOLAIRE. ENTRE BORNES ET LA MASSE D'ESSAI AVANT DE TOUCHER.



WARNING: *Shock Hazard*

Disconnect all power sources to the controller before removing the wiring box cover. Never remove the cover when voltage exists on the ProStar MPPT power connections.



AVERTISSEMENT: *Risque de décharge électrique*

Un moyen de déconnexion de tous les poteaux d'alimentation doit être fourni. Ceux-ci se déconnecte doit être intégrée dans le câblage fixe. Ouvrir que toutes les source d'énergie se déconnecte avant de retirer le couvercle de la contrôleur, ou accès au câblage.

| Schedule | Maintenance Items |
|----------------------------|---|
| 2 weeks after installation | Re-tighten power terminal connections to specified torque values. |

| Schedule | Maintenance Items |
|------------------------------------|---|
| 3 months after installation | Re-tighten power terminal connections to specified torque values. |
| Monthly or After Each Equalization | <p>Inspect the battery bank. Look for cracked or bulging cases, and corroded terminals.</p> <p>For wet cell (flooded type) batteries, make sure the water level is correct. Wet cell water levels should be checked monthly or according to the manufacturer's recommendations.</p> |
| Annually | <p>Clean the heatsink fins with a clean, dry rag.</p> <p>Inspect all wiring for damage or fraying.</p> <p>Inspect for nesting insects.</p> <p>Re-tighten all wiring terminal connections to specified torque values.</p> <p>Inspect the system earth grounding for all components. Verify all grounding conductors are appropriately secured to earth ground.</p> |

Table 4-6. Maintenance Schedule

**WARNING:** *Electric Shock Hazard*

NO POWER OR ACCESSORY TERMINALS ARE ELECTRICALLY ISOLATED FROM DC INPUT, AND MAY BE ENERGIZED WITH HAZARDOUS SOLAR VOLTAGE. TEST BETWEEN TERMINALS AND GROUND BEFORE TOUCHING.

**AVERTISSEMENT:** *Risque de décharge électrique
NON ALIMENTATION OU AUX BORNES*

D'ACCESSOIRES SONT ISOLÉS ÉLECTRIQUEMENT DEPUIS LE COURANT CONTINU D'ENTRÉE ET DOIT ÊTRE ALIMENTÉ À DANGEREUX TENSION SOLAIRE. ENTRE BORNES ET LA MASSE D'ESSAI AVANT DE TOUCHER.

**WARNING:** *Shock Hazard*

A means of disconnecting all power supply poles must be provided. These disconnects must be incorporated in the fixed wiring. Open all power source disconnects before removing controller wiring cover, or accessing wiring.

**AVERTISSEMENT:** *Risque de décharge électrique*

Un moyen de déconnexion de tous les poteaux d'alimentation doit être fourni. Ceux-ci se déconnecte doit être intégrée dans le câblage fixe. Ouvrir que toutes les source d'énergie se déconnecte avant de retirer le couvercle de la contrôleur, ou accès au câblage.

5.1 LED Fault Indications

Load Over-current

Error Status LED: Flashing red. Battery status LEDs: R/Y-G sequencing. If the load current exceeds the maximum load current rating, the ProStar MPPT will disconnect the load. The greater the overload the faster the load will be disconnected. A small overload could take a few minutes to disconnect. The ProStar MPPT will attempt to reconnect the load two (2) times. Each attempt is approximately 10

seconds apart. If the overload remains after two (2) attempts, the load will remain disconnected until power is removed and re-applied.

Solar Short Circuit

Charging Status LED: OFF. Solar input power wires are short-circuited. Charging automatically resumes when the short is cleared.

Battery Reverse Polarity

No LED indication, the unit is not powered. No damage to the controller will result. Correct the miswire to resume normal operation.

Load Short Circuit

Error status LED: Flashing red. Battery status LEDs: R/G-Y sequencing. Fully protected against load wiring short-circuits. After two (2) automatic load reconnect attempts (10 seconds between each attempt), the fault must be cleared by removing and re-applying power.

High Solar Voltage Disconnect

Charging Status LED: R flashing. No battery status errors. If the solar input open-circuit voltage (Voc) exceeds the 120 volt maximum rating, the array will remain disconnected until the Voc falls safely below the maximum rating.

Remote Temperature Sensor (RTS)

Error status LED: Flashing red. Battery status LEDs: R/Y - G/Y sequencing. A bad RTS connection or a severed RTS wire has disconnected the temperature sensor during charging. Charging automatically resumes when the problem is fixed. To resume operation without an RTS, disconnect all power to the ProStar MPPT and then reconnect. If the controller is re-started with the failure still present, the controller may not detect that the battery sense is connected, and the LEDs will not indicate a fault. A metered model, an RM-1 meter, or MSView PC software can be used to determine if the RTS is working properly.

Battery Sense Cables Issue

Error status LED: Flashing red. Battery status LEDs: R/Y - G/Y sequencing. If a fault in the battery sense connection (such as a short-circuit, open circuit or loose terminal) occurs after the battery sense has been working, the LEDs will indicate a failure. To resume operation without an RTS, disconnect all power to the ProStar MPPT and then reconnect. If the controller is re-started with the failure still present, the controller may not detect that the battery sense is connected, and the LEDs will not indicate a fault. A TriStar meter or the PC software can be used to determine if the battery sense is working properly.

Battery / Load High Voltage Disconnect (HVD)

Error status LED: Flashing red. Battery status LEDs: R-G sequencing. This fault is set when battery voltage is above normal operating limits. The controller will disconnect the solar input and set a High Voltage Disconnect fault. This fault is commonly caused by other charging sources in the system, charging the battery above the ProStar MPPT regulation voltage. Recovery occurs at HVD re-connect threshold, and the fault will automatically clear. See Section 7 - Technical Specifications for values.

High Heatsink Temperature

Error status LED: Flashing red. Battery status LEDs: R-Y sequencing. The heatsink temperature has exceeded safe limits and the load is disconnected. The load will automatically reconnect when the heatsink cools to a safe temperature.

Battery Over-Current

Error status LED: Flashing red. Battery status LEDs: R/Y-G sequencing. While rare, if battery charging current exceeds approximately 130% of the controller's output current rating, this fault can occur. The fault is generally related to fast, large battery voltage transients (connecting a very heavy or capacitive load like an inverter) that are faster than the controller can regulate and it shuts off to protect

the circuitry. The controller will automatically re-start in 10 seconds.

Settings (DIP) Switch Changed

Error status LED: Flashing red. Battery status LEDs: R-Y-G sequencing. If a settings switch is changed while there is power to the controller, the LEDs will begin sequencing and the solar input will disconnect. The controller must be re-started to clear the fault and begin operation with the new settings.

Custom Settings Edit

Error status LED: Flashing red. Battery status LEDs: R-Y-G sequencing.

A value has been modified in custom settings memory.

The controller will stop charging and indicate a fault condition. After all settings have been modified, the controller must be reset by removing and then restoring power to the controller. The new programmed settings will be used after the power reset.

Firmware Update Failure

The firmware update was not successfully programmed. The controller will not indicate the full power-up LED sequence of G-Y-R when power to the controller is reset. Instead, the controller will display green, and then stop on yellow. The yellow LED will continue to be lit and the controller will not complete start up or begin charging. Retry the firmware update. The firmware must be successfully loaded before the controller will start up.

SOLID CHARGING STATUS LED with SELF-TEST (R-Y-G) SOC FAULTS

Verify that nothing has been mis-wired. If not, the error is likely critical. Contact an authorized Morningstar dealer for support.

| Fault | Charging Status LED | Battery SOC LEDs |
|-------------------------------------|------------------------------------|------------------|
| PV FET Short | Solid red | R-Y-G sequencing |
| Load FET Short | Solid red | R-Y-G sequencing |
| Load FET Open | Solid red | R-Y-G sequencing |
| Damaged local temperature sensor | Solid red (only if RTS is invalid) | R-Y-G sequencing |
| Damaged heatsink temperature sensor | Solid red | R-Y-G sequencing |
| Software | Solid red | R-Y-G sequencing |

RE-SETTABLE SELF-TEST (R-Y-G) SOC FAULTS

| Fault | | Battery SOC LEDs |
|----------------------|---|------------------|
| Custom Settings Edit | - | R-Y-G sequencing |
| DIP Switch Change | - | R-Y-G sequencing |

5.2 Battery Charging and Performance Issues

Problem:

No LED indications, controller does not appear to be powered

Solution:

With a multi-meter, check the voltage at the battery terminals on the ProStar MPPT. Battery voltage must be 10 vdc or greater. If the voltage on the battery terminals of the controller is between 10 and 35 vdc, and no LEDs are lit, contact your authorized Morningstar dealer for service. If no voltage is measured, check wiring connections, fuses, and breakers.

Problem:

The ProStar MPPT is not charging the battery.

Solution:

Check the three (3) battery SOC LEDs. If they are flashing in a sequence, see Section 4.5 LED indications of this manual to determine the cause. A metered model, an RM-1 meter, or MSView PC software will display active faults and alarms.

If the LED indications are normal, check the fuses, breakers, and wiring connections in the power source wiring. With a multi-meter, check the array voltage directly at the ProStar MPPT solar input terminals. Input voltage must be greater than battery voltage before charging will begin.

Problem:

Controller makes buzzing and humming noises.

Solution:

No action is required. This is expected due to magnetic resonance and circuit switching.

If troubleshooting does not correct the problem, please refer to Morningstar's Warranty Claim Procedure in Section 6.

6.0 WARRANTY & POLICIES

LIMITED WARRANTY Morningstar Solar Controllers and Inverters

All of Morningstar's products, with the exception of the SureSine™ 300 inverter and SHS™ controller, are warranted to be free from defects in material and workmanship for a period of FIVE (5) years from the date of shipment to the original end user. Morningstar's SureSine 300 Inverter and SHS products are warranted to be free from defects in material and workmanship for a period of TWO (2) years from the date of shipment to the original end user. Morningstar will, at its option, repair or replace any such defective products.

WARRANTY EXCLUSIONS AND LIMITATIONS:

This warranty does not apply under the following conditions:

- ◆ Damage by accident, negligence, abuse or improper use
- ◆ PV or load currents exceeding the ratings of the product
- ◆ Unauthorized product modification or attempted repair
- ◆ Damage occurring during shipment
- ◆ Damage results from acts of nature such as lightning and weather extremes

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, EXPRESS OR IMPLIED. MORNINGSTAR SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO MORNINGSTAR DISTRIBUTOR, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION OR EXTENSION TO THIS WARRANTY.

MORNINGSTAR IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWN-TIME, GOODWILL OR DAMAGE TO EQUIPMENT OR PROPERTY.

R15-8/15

MORNINGSTAR TECHNICAL SUPPORT POLICIES

Morningstar's Technical Support Group is dedicated to providing unparalleled customer support.

MS Support Scope:

1. Determining correct or failed functionality of a Morningstar product or system of Morningstar devices. It is expected that owners/operators will use manuals (including trouble shooting sections) before requesting technical support.
2. Providing product warranty replacements in accordance with the terms of Morningstar's warranty policy.
3. Assisting with the operability of all product / system features and functions described in Morningstar manuals and datasheets.

Please be advised:

◆ The Morningstar Technical Support Group generally provides referrals for requested system consultations or design/configuration/sizing services. Distributors, dealers, system designers, installers and vast online resources - including the String Calculator array design tool (at www.morningstarcorp.com) - are available to assist in these areas. Morningstar can help refer customers to a nearby authorized distributor, dealer, or installer if assistance is required in designing a renewable energy system that best suits your specific needs.

MORNINGSTAR TECHNICAL SUPPORT POLICIES (Cont.)

- ◆ **Please visit the Tech Support section at www.morningstarcorp.com for any documentation or specification needs before requesting support.** The site also offers an array sizing tool (String Selector), product comparison tool (Product Comparator) and articles on solar charging technologies and other design considerations.
- ◆ Although emergencies do arise when a phone call is necessary, e-mail is the best way to contact us, and will result in the quickest response. Please use the support request form [Contact Us](#) (preferred), or e-mail us directly at support@morningstarcorp.com

Thank you for your business, and we look forward to assisting you.

WARRANTY CLAIM PROCEDURE

1. Before proceeding, please refer to product manual, including Trouble Shooting section.
2. Contacting your authorized Morningstar distributor or dealer from whom you purchased the unit is the first step in the warranty process. Local dealers can often address warranty issues quickly.
3. If supplier is unable to address the issue, please contact Morningstar by e-mail (support@morningstarcorp.com) with:
 - (A) purchase location -- business or company name
 - (B) full model and serial numbers (SN is 8-digits on unit bar label)
 - (C) failure behavior, including LED indications
 - (D) array configuration, panel Pmax, Voc, Vmp, Isc, and nominal battery voltage; these specifications are needed to receive assistance.
 - (E) multi-meter available (for field troubleshooting)
4. After warranty replacement has been approved and new unit(s) received, please return failed unit(s) using pre-paid shipping label, and follow any product specific instructions if requested by Morningstar Warranty Dept.
5. If instructed by Morningstar, after warranty replacement shipment has been received, return of failed unit(s) is required before further warranty replacements can be considered for the original or future cases.

NOTE: Please do not return units without an RMA or case number. Doing so will increase the time required to resolve your claim.

| | PS-MPPT-25 PS-MPPT-25M | PS-MPPT-40 PS-MPPT-40M |
|--|---------------------------|---------------------------|
|--|---------------------------|---------------------------|

Electrical:

| | | |
|------------------------------|-----------------------------------|---------------|
| Nominal Battery Voltage | 12 volts or 24 volts | |
| Battery Voltage Range | 10-35 volts | |
| Voltage Accuracy | | |
| Max. Battery Current | 25 amps | 40 amps |
| Max. PV Open-Circuit Voltage | 120 volts | 120 volts |
| Load Current Rating | 25 amps | 30 amps |
| Self Consumption | < 25mA (no meter) | <40mA (meter) |
| LED Indications | (1) status, (3) battery SOC | |
| Transient Surge Protection | 4500 watts (solar, battery, load) | |
| Conversion Efficiency (peak) | 97.3% | 97.3% |

Mechanical:

Dimensions:

| | | |
|-----------------|---|--|
| Standard | 20.0(W) x 17.0(L) x 7.0(D) cm / 7.88(W) x 6.69(L) x 2.78(D) in. | |
| Wire Box Option | 20.0 (W) x 28.5 (L) x 9.05 (D) cm / 7.87(W) x 11.22(L) x 3.56(D) in. | |

Weight:

| | |
|--------------------------------------|--|
| Standard Version | 3.1 lb /1.4 kg |
| Standard Version with Wire Box | 3.4 lb /1.5 kg |
| Wire Size Range: | |
| Power Terminals | 2.5 - 35 mm ² / 14 - 2 AWG |
| Battery/Temp. Sense | 0.25 - 1.0 mm ² / 24 - 16 AWG |
| Knock-outs (wire box option only) | M20, 1/2", 1" (trade sizes) |
| Enclosure | IP20, Type 1 |

Battery Charging:

| | |
|--|-----------------------------------|
| 4-Stage Charging: | Bulk, Absorption, Float, Equalize |
| Temperature compensation Coefficient: | -30mV / 12 volt / °C |
| Temperature compensated set-points: | Absorption, Float, Equalize, HVD |

Battery Charging Set-points (@ 25°C):

[multiply voltages by (2) for 24 volt systems]

| DIP Switch Settings 4-5-6 | Battery Type | Absorp. Stage (volts) | Float Stage (volts) | Equalize Stage (volts) | Absorp. Time (mins) | Equalize Time (mins) | Equalize Timeout (mins) | Equalize Interval (days) |
|---------------------------|----------------|-----------------------|---------------------|------------------------|---------------------|----------------------|-------------------------|--------------------------|
| off-off-off | 1 - Sealed* | 14.00 | 13.70 | | 150 | | | |
| off-off-on | 2 - Sealed* | 14.15 | 13.70 | 14.40 | 150 | 60 | 120 | 28 |
| off-on-off | 3 - Sealed* | 14.30 | 13.70 | 14.65 | 150 | 60 | 120 | 28 |
| off-on-on | 4- AGM/Flooded | 14.40 | 13.70 | 15.10 | 180 | 120 | 180 | 28 |
| on-off-off | 5 - Flooded | 14.60 | 13.50 | 15.30 | 180 | 120 | 180 | 28 |
| on-off-on | 6 - Flooded | 14.70 | 13.50 | 15.40 | 180 | 180 | 240 | 28 |
| on-on-off | 7 - L-16 | 15.40 | 13.40 | 16.00 | 180 | 180 | 240 | 14 |
| on-on-on | 8 - Custom | Custom | Custom | Custom | Custom | Custom | Custom | Custom |

* "Sealed" battery type includes gel and AGM batteries

Current Compensation:

12 volt systems

-20 mV / A

24 volt systems

-40 mV / A

Compensated set-points

LVD

Compensation threshold

3A

Load and Solar Control (multiply voltages by (2) for 24 volt systems):

Default values (customizable)

LVD

11.4V

LVD

12.6V

Instant LVD

10.0V

HVD - load

15.3V (@ 25°C)

HVD - solar

15.2V (@ 25°C)

HVDR - load

14.5V (@ 25°C)

HVDR - solar

12.3V (@ 25°C)

LVD Warning

10 minutes

LVD Override

10 minutes

Maximum # LVD overrides
(not customizable)

No limit unless
V_{batt} < Instant LVD

Lighting Control (DIP 1 ON):

Lighting Timer Setting

Dusk-Dawn (default)

Lighting Test Timer

5 minutes

Data & Communications:

| | |
|--------------------|---------------------------------|
| Communication Port | MeterBus |
| Comm. Protocols | Morningstar MeterBus; MODBUS |
| Datalogging | 6-8 months, daily records |
| PC Software | MSView |

Digital Meter:

| | |
|-----------------------|---------------|
| Resolution | 128 x 64 |
| Viewing Area | 70mm x 40mm |
| Display Color | blue on white |
| Backlight | LED |
| Operating Temperature | -20C to +70C |
| Storage Temperature | -30C to +80C |


Environmental:

| | |
|-----------------------|--|
| Operating Temperature | -40C to +45C |
| Storage Temperature | -40C to +80C |
| Humidity | 100% n.c. |
| Tropicalization | Conformally coated PCBs; Marine-rated terminals |


Protections

Power-up against any active faults
Reverse Polarity - battery and array
Solar Short-Circuit
Solar High Voltage Disconnect
High Heatsink Temperature - Current De-rating
High Heatsink Temperature - Load Disconnect
Load Short-Circuit
Load Over-Current
Heatsink Temperature Limit
RTS Terminals
Battery Sense Terminals

APPENDIX A - Efficiency Graphs




ProStar MPPT Efficiency 24 Volt System




APPENDIX B - De-rating Graphs

Battery Current vs. Array Voltage (Vmp)



Battery Current vs. Ambient Temperature



APPENDIX C - Wire Sizing Charts

2% Voltage Drop Charts for 75°C Stranded Copper Wire

1-Way Wire Distance (feet), 12 Volt System

| Wire Size (AWG) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|-----------------|------|------|------|------|------|------|-------|-------|
| 2/0 * | 33.6 | 38.4 | 44.8 | 53.8 | 67.2 | 89.6 | 134.4 | 268.9 |
| 1/0 * | 26.6 | 30.4 | 35.5 | 42.6 | 53.3 | 71.0 | 106.6 | 213.1 |
| 2 | 16.8 | 19.1 | 22.3 | 26.8 | 33.5 | 44.7 | 67.0 | 134.0 |
| 4 | 10.6 | 12.1 | 14.1 | 16.9 | 21.1 | 28.1 | 42.2 | 84.4 |
| 6 | 6.6 | 7.6 | 8.8 | 10.6 | 13.2 | 17.7 | 26.5 | 53.0 |
| 8 | 4.2 | 4.8 | 5.6 | 6.7 | 8.4 | 11.1 | 16.7 | 33.4 |
| 10 | 2.6 | 3.0 | 3.5 | 4.2 | 5.2 | 7.0 | 6.6 | 21.0 |
| 12 | 1.6 | 1.9 | 2.2 | 2.6 | 3.3 | 4.4 | 6.6 | 13.1 |
| 14 | 1.0 | 1.2 | 1.4 | 1.7 | 2.1 | 2.8 | 4.1 | 8.3 |

Table C-1. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

1-Way Wire Distance (meters), 12 Volt System

| Wire Size (mm ²) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|------------------------------|-------|-------|-------|-------|-------|-------|-------|-------|
| 70 * | 10.24 | 11.71 | 13.66 | 16.39 | 20.49 | 27.32 | 40.98 | 81.95 |
| 50 * | 8.12 | 9.28 | 10.83 | 12.99 | 16.24 | 21.65 | 32.48 | 64.96 |
| 35 | 5.11 | 5.84 | 6.81 | 8.17 | 10.21 | 13.62 | 20.42 | 40.85 |
| 25 | 3.22 | 3.68 | 4.29 | 5.15 | 6.43 | 8.58 | 12.87 | 25.73 |
| 16 | 2.02 | 2.31 | 2.69 | 3.23 | 4.04 | 5.38 | 8.07 | 16.14 |
| 10 | 1.27 | 1.46 | 1.70 | 2.04 | 2.55 | 3.40 | 5.09 | 10.19 |
| 6 | 0.80 | 0.91 | 1.07 | 1.28 | 1.60 | 2.13 | 3.20 | 6.39 |
| 4 | 0.50 | 0.57 | 0.67 | 0.80 | 1.00 | 1.33 | 2.00 | 4.00 |
| 2.5 | 0.32 | 0.36 | 0.42 | 0.50 | 0.63 | 0.84 | 1.26 | 2.52 |

Table C-2. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

2% Voltage Drop Charts for 75°C Solid Copper Wire

1-Way Wire Distance (feet), 12 Volt System

| Wire Size (AWG) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|-----------------|------|------|------|------|------|-------|-------|-------|
| 2/0 * | 41.7 | 47.7 | 55.6 | 66.7 | 83.4 | 111.2 | 166.8 | 333.6 |
| 1/0 * | 33.1 | 37.8 | 44.1 | 52.9 | 66.1 | 88.2 | 132.3 | 264.6 |
| 2 | 20.8 | 23.8 | 27.7 | 33.3 | 41.6 | 55.4 | 83.2 | 166.3 |
| 4 | 13.1 | 14.9 | 17.4 | 20.9 | 26.2 | 34.9 | 52.3 | 104.6 |
| 6 | 8.2 | 9.4 | 11.0 | 13.2 | 16.5 | 21.9 | 32.9 | 65.8 |
| 8 | 5.2 | 5.9 | 6.9 | 8.3 | 10.3 | 13.8 | 20.7 | 41.4 |
| 10 | 3.3 | 3.7 | 4.3 | 5.2 | 6.5 | 8.7 | 13.0 | 26.0 |
| 12 | 2.0 | 2.3 | 2.7 | 3.3 | 4.1 | 5.5 | 8.2 | 16.4 |
| 14 | 1.3 | 1.5 | 1.7 | 2.1 | 2.6 | 3.4 | 5.1 | 10.3 |

Table C-3. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

1-Way Wire Distance (meters), 12 Volt System

| Wire Size (mm ²) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|------------------------------|-------|-------|-------|-------|-------|-------|-------|--------|
| 70 * | 12.71 | 14.53 | 16.95 | 20.34 | 25.42 | 33.90 | 50.85 | 101.69 |
| 50 * | 10.08 | 11.52 | 13.44 | 16.13 | 20.16 | 26.88 | 40.32 | 80.64 |
| 35 | 6.34 | 7.24 | 8.45 | 10.14 | 12.68 | 16.90 | 25.35 | 50.70 |
| 25 | 3.99 | 4.56 | 5.32 | 6.38 | 7.97 | 10.63 | 15.95 | 31.89 |
| 16 | 2.51 | 2.87 | 3.34 | 4.01 | 5.01 | 6.69 | 10.03 | 20.06 |
| 10 | 1.58 | 1.80 | 2.10 | 2.52 | 3.15 | 4.21 | 6.31 | 12.62 |
| 6 | 0.99 | 1.13 | 1.32 | 1.59 | 1.98 | 2.64 | 3.97 | 7.93 |
| 4 | 0.62 | 0.71 | 0.83 | 1.00 | 1.25 | 1.66 | 2.50 | 4.99 |
| 2.5 | 0.39 | 0.45 | 0.52 | 0.63 | 0.78 | 1.05 | 1.57 | 3.14 |

Table C-4. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

*Wires sizes larger than 2 AWG (35 mm²) must be terminated at a splicer block located outside of the ProStar MPPT wiring box. Use 2 AWG (35 mm²) or smaller wire to connect to the ProStar MPPT to the splicer block.

Notes:

- The specified wire length is for a pair of conductors from the solar or battery source to the controller (1-way distance)
- For 24 volt systems, multiply the 1-way length in the table by 2.
- Shaded cells in the table indicate that the current exceeds the ampacity of the wire for a given ambient temperature as defined in the following table:

| Wire Ampacity** Key | |
|----------------------------|---|
| | Exceeds wire ampacity at 60°C ambient temperature |
| | Exceeds wire ampacity at 50°C ambient temperature |
| | Exceeds wire ampacity at 40°C ambient temperature |
| | Exceeds wire ampacity at 30°C ambient temperature |

**Ampacity for not more than three current-carrying conductors in a raceway, cable, or earth (buried) - Per 2011 NEC

2% Voltage Drop Charts for 90°C Stranded Copper Wire

1-Way Wire Distance (feet), 12 Volt System

| Wire Size (AWG) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|-----------------|------|------|------|------|------|------|-------|-------|
| 2/0 * | 33.6 | 38.4 | 44.8 | 53.8 | 67.2 | 89.6 | 134.4 | 268.9 |
| 1/0 * | 26.6 | 30.4 | 35.5 | 42.6 | 53.3 | 71.0 | 106.6 | 213.1 |
| 2 | 16.8 | 19.1 | 22.3 | 26.8 | 33.5 | 44.7 | 67.0 | 134.0 |
| 4 | 10.6 | 12.1 | 14.1 | 16.9 | 21.1 | 28.1 | 42.2 | 84.4 |
| 6 | 6.6 | 7.6 | 8.8 | 10.6 | 13.2 | 17.7 | 26.5 | 53.0 |
| 8 | 4.2 | 4.8 | 5.6 | 6.7 | 8.4 | 11.1 | 16.7 | 33.4 |
| 10 | 2.6 | 3.0 | 3.5 | 4.2 | 5.2 | 7.0 | 10.5 | 21.0 |
| 12 | 1.6 | 1.9 | 2.2 | 2.6 | 3.3 | 4.4 | 6.6 | 13.1 |
| 14 | 1.0 | 1.2 | 1.4 | 1.7 | 2.1 | 2.8 | 4.1 | 8.3 |

Table C-5. Maximum 1-way wire distance for 12 Volt systems, stranded copper, 2% voltage drop

1-Way Wire Distance (meters), 12 Volt System

| Wire Size (mm ²) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|------------------------------|-------|-------|-------|-------|-------|-------|-------|-------|
| 70 * | 10.24 | 11.71 | 13.66 | 16.39 | 20.49 | 27.32 | 40.98 | 81.95 |
| 50 * | 8.12 | 9.28 | 10.83 | 12.99 | 16.24 | 21.65 | 32.48 | 64.96 |
| 35 | 5.11 | 5.84 | 6.81 | 8.17 | 10.21 | 13.62 | 20.42 | 40.85 |
| 25 | 3.22 | 3.68 | 4.29 | 5.15 | 6.43 | 8.58 | 12.87 | 25.73 |
| 16 | 2.02 | 2.31 | 2.69 | 3.23 | 4.04 | 5.38 | 8.07 | 16.14 |
| 10 | 1.27 | 1.46 | 1.70 | 2.04 | 2.55 | 3.40 | 5.09 | 10.19 |
| 6 | 0.80 | 0.91 | 1.07 | 1.28 | 1.60 | 2.13 | 3.20 | 6.39 |
| 4 | 0.50 | 0.57 | 0.67 | 0.80 | 1.00 | 1.33 | 2.00 | 4.00 |
| 2.5 | 0.32 | 0.36 | 0.42 | 0.50 | 0.63 | 0.84 | 1.26 | 2.52 |

Table C-6. Maximum 1-way wire distance for 12 Volt systems, stranded copper, 2% voltage drop

2% Voltage Drop Charts for 90°C Solid Copper Wire

1-Way Wire Distance (feet), 12 Volt System

| Wire Size (AWG) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|-----------------|------|------|------|------|------|-------|-------|-------|
| 2/0 * | 41.7 | 47.7 | 55.6 | 66.7 | 83.4 | 111.2 | 166.8 | 333.6 |
| 1/0 * | 33.1 | 37.8 | 44.1 | 52.9 | 66.1 | 88.2 | 132.3 | 264.6 |
| 2 | 20.8 | 23.8 | 27.7 | 33.3 | 41.6 | 55.4 | 83.2 | 166.3 |
| 4 | 13.1 | 14.9 | 17.4 | 20.9 | 26.2 | 34.9 | 52.3 | 104.6 |
| 6 | 8.2 | 9.4 | 11.0 | 13.2 | 16.5 | 21.9 | 32.9 | 65.8 |
| 8 | 5.2 | 5.9 | 6.9 | 8.3 | 10.3 | 13.8 | 20.7 | 41.4 |
| 10 | 3.3 | 3.7 | 4.3 | 5.2 | 6.5 | 8.7 | 13.0 | 26.0 |
| 12 | 2.0 | 2.3 | 2.7 | 3.3 | 4.1 | 5.5 | 8.2 | 16.4 |
| 14 | 1.3 | 1.5 | 1.7 | 2.1 | 2.6 | 3.4 | 5.1 | 10.3 |

Table C-7. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

1-Way Wire Distance (meters), 12 Volt System

| Wire Size (mm ²) | 40A | 35A | 30A | 25A | 20A | 15A | 10A | 5A |
|------------------------------|-------|-------|-------|-------|-------|-------|-------|--------|
| 70 * | 12.71 | 14.53 | 16.95 | 20.34 | 25.42 | 33.90 | 50.85 | 101.69 |
| 50 * | 10.08 | 11.52 | 13.44 | 16.13 | 20.16 | 26.88 | 40.32 | 80.64 |
| 35 | 6.34 | 7.24 | 8.45 | 10.14 | 12.68 | 16.90 | 25.35 | 50.70 |
| 25 | 3.99 | 4.56 | 5.32 | 6.38 | 7.97 | 10.63 | 15.95 | 31.89 |
| 16 | 2.51 | 2.87 | 3.34 | 4.01 | 5.01 | 6.69 | 10.03 | 20.06 |
| 10 | 1.58 | 1.80 | 2.10 | 2.52 | 3.15 | 4.21 | 6.31 | 12.62 |
| 6 | 0.99 | 1.13 | 1.32 | 1.59 | 1.98 | 2.64 | 3.97 | 7.93 |
| 4 | 0.62 | 0.71 | 0.83 | 1.00 | 1.25 | 1.66 | 2.50 | 4.99 |
| 2.5 | 0.39 | 0.45 | 0.52 | 0.63 | 0.78 | 1.05 | 1.57 | 3.14 |

Table C-8. Maximum 1-way wire distance for 12 Volt systems, solid copper, 2% voltage drop

*Wires sizes larger than 2 AWG (35 mm²) must be terminated at a splicer block located outside of the ProStar MPPT wiring box. Use 2 AWG (35 mm²) or smaller wire to connect to the ProStar MPPT to the splicer block.


Notes:

- The specified wire length is for a pair of conductors from the solar or battery source to the controller (1-way distance)
- For 24 volt systems, multiply the 1-way length in the table by 2.
- Shaded cells in the table indicate that the current exceeds the ampacity of the wire for a given ambient temperature as defined in the following table:

| Wire Ampacity** Key | |
|----------------------------|---|
| | Exceeds wire ampacity at 60°C ambient temperature |
| | Exceeds wire ampacity at 50°C ambient temperature |
| | Exceeds wire ampacity at 40°C ambient temperature |
| | Exceeds wire ampacity at 30°C ambient temperature |

***Ampacity for not more than three current-carrying conductors in a raceway, cable, or earth (buried) - Per 2011 NEC*

Certifications



- UL Listed (UL 1741, 62109) and cUL Listed (CSA-C22.2 No. 107.1)
- IEC 62109
- Complies with the US National Electric Code
- FCC Class B compliant

ENs Directives:

- Complies with ENs and LVD standards for CE marking
- Immunity: EN61000-6-2:1999
- Emissions: EN55022:1994 with A1 and A3 Class B1

ProStar™, ProStar MPPT™, MeterBus™ are trademarks of Morningstar Corporation

MODBUS™ and MODBUS TCP/IP™ are trademarks of Modbus IDA. www.modbus-ida.org

© 2015 Morningstar Corporation. All rights reserved.